

		igle - PNP	table
LE	SIZE	DRAWING NUMBER	REVISIO

9630-20-TSL-DSA-135-7487 02	DRAWING NUMBER		
	9630-20-TSL-DSA-135-7487		



ARM ANGLE ADJUSTMENT PROCEDURE

-OPENING ANGLE READOUT





- 1. ACTUATE CLAMP ARM TO FULLY OPEN POSITION (135°). THIS IS THE FACTORY SETTING.
- 2. TAKE AN M5 ALLEN WRENCH AND INSERT INTO BROACH ON BOTTOM OF POWER CLAMP.
- 3. TURN THE M5 ALLEN WRENCH COUNTER CLOCKWISE IF AN OPENING ANGLE OTHER THAN THE FACTORY SETTING IS REQUIRED.
- 4. REMOVE ALLEN WRENCH AND ACTUATE UNIT TO CHECK NEW OPENING ANGLE.



