

F/T Data Viewer Software Application Manual



Document #: 9610-05-1042

Foreword

Information contained in this document is the property of ATI Industrial Automation, Inc. and shall not be reproduced in whole or in part without prior written approval of ATI Industrial Automation, Inc. The information herein is subject to change without notice and should not be construed as a commitment on the part of ATI Industrial Automation, Inc. This manual is periodically revised to reflect and incorporate changes made to the F/T system.

ATI Industrial Automation, Inc. assumes no responsibility for any errors or omissions in this document.

Copyright© (2022) by ATI Industrial Automation, Inc., Apex, North Carolina USA. All Rights Reserved. Published in the USA.

ATI Force/Torque Sensing Systems are considered components/ semi-finished goods intended for use in larger system/ device/ finished good.

In consideration that ATI Industrial Automation, Inc. (ATI) products are intended for use with robotic and/or automated machines, ATI does not recommend the use of its products for applications wherein failure or malfunction of a ATI component or system threatens life or makes injury probable. Anyone who uses or incorporates ATI components within any potentially life threatening system must obtain ATI's prior consent based upon assurance to ATI that a malfunction of ATI's component does not pose direct or indirect threat of injury or death, and (even if such consent is given) shall indemnify ATI from any claim, loss, liability, and related expenses arising from any injury or death resulting from use of ATI components.

All trademarks belong to their respective owners. Windows[®] and Excel[®] are registered trademarks of Microsoft Corporation.

Note

Please read the manual before calling customer service, and have the following information available:

- 1. Serial number (e.g., FT01234)
- 2. Transducer model (e.g., Axia, etc.)
- 3. Calibration (e.g., US-15-50, SI-65-6, etc.)
- 4. Accurate and complete description of the concern or question
- 5. Computer and software information, for example: operating system, PC type, drivers, and application software

Be near the F/T system when calling (if possible).

Please contact an ATI representative for assistance, if needed:

Sale, Service and Information about ATI products:

ATI Industrial Automation 1031 Goodworth Drive Apex, NC 27539 USA *www.ati-ia.com* Tel: +1.919.772.0115 Fax: +1.919.772.8259

Application Engineering

Tel: +1.919.772.0115, Extension 511 Fax: +1.919.772.8259 E-mail: *ft_support@ati-ia.com*

24/7 Support Tel: +1.855.ATI-IA.00 (+1.855.284.4200)

Table of Contents

Fo	rewor	'd	2
Glo	ossar	у	5
1.	Safe	ety	6
	1.1	Explanation of Notifications	6
	1.2	General Safety Guidelines	6
2.	Proc	duct Overview	7
3.	Inst	allation	8
	3.1	Installing the F/T Data Viewer on a PC	8
4.	Initia	ate the F/T Data Viewer Application and Set Up the Sensor	9
	4.1	Initiate the F/T Data Viewer Application	9
	4.2	Set-Up Communication to an Ethernet Sensor	
		4.2.1 Before Connecting to the Sensor with the F/T Data Viewer	10
		4.2.2 After Starting the F/T Data Viewer	
	4.3	Set Up Communication to a Serial F/T Axia Sensor	
		4.3.1 Before Connecting to the Sensor with the F/T Data Viewer	
		4.3.2 After Starting the F/T Data Viewer	12
5.	Sen	sor Outputs	14
	5.1	Bias Data	15
	5.2	Sensor Output Display (F/T or Gages)	
		5.2.1 Display Gage Data	
		5.2.2 Display F/T Data	17
	5.3	Setting F/T Units	
	5.4	RDT Sample Rate and Filtering for NET F/T Sensors	
	5.5	RDT Sample Rate and Filtering for Serial F/T Sensors	19
	5.6	Logging Data	
		5.6.1 Logging .CSV File	23
6 .	Too	ls	
	6.1	ATI F/T Webpages	
	6.2	Sensor Information (Sensor Info)	
7.	Eve	nt Log	
	7.1	Clear the Event Log	27
8.	Cha	rt	
	8.1	Chart Type	
	8.2	Chart Maximum and Minimum Values	
	8.3	Graph Settings	29

Glossary

Term	Definitions			
ADC	Analog-to-digital converter			
ATI Ethernet Axia Sensor or ATI NET F/T Sensor	An ATI F/T sensor that uses Ethernet protocol.			
ATI NET F/T Sensor	An ATI Ethernet F/T sensor that is not an Axia80.			
ATI Serial Axia Sensor	An ATI F/T Axia sensor that uses RS485 protocol.			
Baud Rate	A number that is related to the speed of data transmission in a system. The data indicates the number of electrical oscillations per second that occurs within a data transmission.			
Bias	When the sensor software subtracts a reference value from the F/T data, before data is transmitted from the sensor. The action of biasing a sensor is commonly referred to as <i>to tare</i> or <i>to zero</i> the sensor.			
Comma Separated Value (CSV)	A type of file that stores tabular data in plain text. The data is in one or more fields that is separated by commas. CSV is the file extension name.			
COM Port (Communication Port)	A physical or virtual serial port interface on a device such as a PC or robot.			
Data Rate	How fast data can be output over a serial interface or network.			
DoF	Degrees of Freedom (refer to the following definition: Six Degrees of Freedom)			
FT or F/T	Force and Torque			
F/T Data Viewer software application	A downloadable application or program that demonstrates the capabilities of the ATI F/T software.			
Latency	On a computer network, this is the time for the network to receive a response to a request.			
N/A	Not Applicable			
PC	Personal Computer			
P/N	Part Number			
RDT	RDT (Raw Data Transfer) is the rate per second at which the sensor sends streaming RDT data to a host. RDT is a fast and simple Ethernet protocol for control and data transfer via UDP.			
Sample rate	How fast the ADCs are sampling inside the unit.			
Sensor	The component that converts a detected load into electrical signals.			
Six Degrees of Freedom	Fx, Fy, Fz, Tx, Ty, and Tz			
Status Bit	A unit of computer data that is sent from the ATI F/T sensor.			
Transducer	Every transducer is also (or has) a sensor but every sensor isn't a transducer. A transducer is more than a sensor. It consists of a sensor/ actuator along with signal conditioning circuits.			

1. Safety

The safety section describes general safety guidelines to be followed with this product, explanations of the notifications found in this manual, and safety precautions that apply to the product. Product specific notifications are imbedded within the sections of this manual (where they apply).

1.1 Explanation of Notifications

These notifications are used in all of ATI manuals and are not specific to this product. The user should heed all notifications from the robot manufacturer and/or the manufacturers of other components used in the product installation.

DANGER: Notification of information or instructions that if not followed will result in death or serious injury. The notification provides information about the nature of the hazardous situation, the consequences of not avoiding the hazard, and the method for avoiding the situation.



WARNING: Notification of information or instructions that if not followed could result in death or serious injury. The notification provides information about the nature of the hazardous situation, the consequences of not avoiding the hazard, and the method for avoiding the situation.



CAUTION: Notification of information or instructions that if not followed could result in moderate injury or will cause damage to equipment. The notification provides information about the nature of the hazardous situation, the consequences of not avoiding the hazard, and the method for avoiding the situation.

NOTICE: Notification of specific information or instructions about maintaining, operating, installing, or setting up the product that if not followed could result in damage to equipment. The notification can emphasize, but is not limited to: specific grease types, best operating practices, and maintenance tips.

1.2 General Safety Guidelines

The customer should verify that the sensor is rated for maximum loads and torques expected during operation. Because static forces are less than the dynamic forces from the acceleration or declaration of the robot, be aware of the dynamic loads caused by the robot.

2. Product Overview

The F/T Data Viewer software application presents live F/T data from an ATI sensor in a graphical interface on a customer's PC. In addition to viewing the data within the F/T Data Viewer, save data to a CSV file, bias data, change units, and apply sensor settings (RDT sampling rate and filtering). The software is compatible with Microsoft Windows[®] operating systems. The F/T Data Viewer application is compatible with the following ATI F/T sensors: Ethernet, Ethernet Axia, and Serial Axia. For more information about these sensors, refer to the applicable ATI manual in the following table:

Table 2.1—ATI F/	T Sensor Manuals
ATI F/T Sensor	ATI Manual Document#
Serial (RS485) Axia	9610-05-Serial Axia
Ethernet Axia	9620-05-C-Ethernet Axia
All Other Ethernet Sensors	9620-05-NET FT and 9620-05-Transducer Section

The main features of the F/T Data Viewer are a **Toolbar** on the top of the screen, a **Sensor Outputs** field on the left side of the screen, a **Chart** on the right side of the screen, and an **Event Log** field on the bottom of the screen.



Figure 2.1—F/T Data Viewer Main Screen

Manual, F/T Data Viewer, Software Application Document #9610-05-1042-03

3. Installation

To load the F/T Data Viewer on a PC, refer to the instructions in the following sections.

3.1 Installing the F/T Data Viewer on a PC

- 1. Access the F/T Data Viewer software application file from the ATI website *https://www.ati-ia.com/library/download.aspx*.
- 2. Right click on the F/T Data Viewer Installer icon, and select Install.

Figure 3.1—F/T Data Viewer Installer Icon



3. Follow the steps that the installer provides through the **F/T Data Viewer Setup Wizard** interface.

Figure 3.2—ATI Demo Setup Wizard



4. Initiate the F/T Data Viewer Application and Set Up the Sensor

4.1 Initiate the F/T Data Viewer Application

1. On the PC's desktop, click and open the FT Data Viewer icon.

Figure 4.1—Click and Open the FT Data Viewer Icon



2. The F/T Data Viewer opens in a limited mode until communication with the sensor is established. Unavailable features are grayed-out and cannot be clicked.

File Tools Settings Help	Charl Ture							
	< Line Ohat	Fx-		Py.		Pz -		Hide Max/Mir
AUTOMATION	-	Tx -		ту -		Tz -		
								1
Set Up Sensor								
Sensor Outputs								
Bart Reading Blant Logging								
Ar N								
Tx 🚺 Nm 🛛	z							low
Ty 📃 🔤 🗹	Fao							- N
Ta 🔤 🧧 Nim 🗹								1
Bias Urbras								
Hesel Prinks								
EventLog		Fx-N	Fy-N	 Fz - N 	 Tx - Nm 	 Ty - Nm 	 Tz - Nm 	
31 15 PMI Stated	11							

Figure 4.2—Limited Features Before the Sensor is Set-Up

- 3. Set-up the sensor:
 - a. For an Ethernet sensor, refer to Section 4.2—Set-Up Communication to an Ethernet Sensor.
 - b. For a Serial sensor, refer to Section 4.3—Set Up Communication to a Serial F/T Axia Sensor.

4.2 Set-Up Communication to an Ethernet Sensor

4.2.1 Before Connecting to the Sensor with the F/T Data Viewer

- 1. Verify that the Ethernet cable is installed to the user's PC and sensor.
- 2. Establish an Ethernet network connection to the sensor.
 - a. For instructions on how to set-up the PC's IP address and connect to the sensor, refer to the appropriate manual in *Table 2.1*: 9620-05-C-Ethernet Axia or *9620-05-NET FT*.

NOTICE: Ensure the Ethernet network connection between the PC and the sensor is properly configured before using the F/T Data Viewer application:

- To test the connection, type the IP address of the sensor into a web browser on the PC. If it does not open the sensor's internal web page, then the network connection is not configured properly.
- For instructions on how to properly set-up the PC's IP address and connect to the sensor refer to either the 9620-05-C-Ethernet Axia or 9620-05-NET FT manual.
- If the sensor's web page is accessible but F/T Data Viewer still cannot find the sensor, a firewall may be blocking F/T Data Viewer. See Section 9.3—Resolving Firewall Issues.

4.2.2 After Starting the F/T Data Viewer

1. Click Set Up Sensor. The Device Setup Wizard initiates.

Figure 4.3—Set Up Sensor



2. From the Select Device Type drop-down menu, select Net F/T.



3. Click Next.

4. Type the Sensor IP Address in the text field, or click the Search button to find a sensor. The Search function may activate a firewall; refer to Section 9.3—Resolving Firewall Issues.

evice Setup	Wizard	
Net FT	Device Setup	T AND
	Enter Sensor IP Address (Must be on local subnet)	
	10 1 1 122 50 00 20 05 10 15	Search

- 5. Click Next.
- 6. The F/T Data Viewer opens in full mode, which allows the user to access all available functions.

7. Click Start Reading to start streaming data from the sensor. For other features, refer to Section 5—Sensor Outputs.

4.3 Set Up Communication to a Serial F/T Axia Sensor

4.3.1 Before Connecting to the Sensor with the F/T Data Viewer

- 1. Connect the sensor's USB cable into the PC's USB port. Verify the sensor's Run and Status LEDs illuminate.
- 2. Determine which COM port the PC has assigned to the sensor. This information is listed in the Device Manager, under Ports. In the following example, the PC has assigned COM3 to the sensor.

Figure 4.6—Check COM Port Assignment in Device Manager



3. Verify that the USB driver for the sensor cable is installed.

NOTICE: This driver should be installed automatically with F/T Data Viewer, but some PCs may block installation. If installed, the device displays in the Device Manager under Ports as: "USB Serial Port." For the manual installation procedure, refer to the ATI manual *9610-05-Serial Axia*.

4.3.2 After Starting the F/T Data Viewer

1. Click Set Up Sensor. The Device Setup Wizard initiates.



2. From the Select Device Type drop-down menu, select Serial F/T.

Figure 4	.8—Select	the Device Type
P Device Setup Wi	zard	
Device Ty	pe Selection	ETTINPUSTRIAL
	Select Device Type	
	Serial FT	•
Cancel		Next

3. Click Next.

NOTICE: Ensure the value in the Baud Rate field matches the sensor's set baud rate.
To find the baud rate of the sensor, refer to the console commands in the 9610-05-Serial
Axia manual. ATI ships the sensor with a default baud rate that is 115200.

4. Select the COM Port and Baud Rate from the drop-down menus. The default baud rate setting from the factory is 115200. To know which of the computer's COM ports the sensor is connected to, refer to the 9610-05-Serial Axia manual.



Serial FT	Device Setu	p	Č	AUTOMATIC
	Enter Sensor	COMP	Port	
	COM6 Coloct Doud	▼ Data	Refresh	
	Select Baud	Rale		
	1000000	-		
	1000000	•		

- 5. The F/T Data Viewer opens in full mode, which allows the user to access all available functions.
- 6. Click **Start Reading** to start streaming data from the sensor. For other features, refer to *Section 5—Sensor Outputs*.

5. Sensor Outputs

On the left side of the **F/T Data Viewer** screen, in the **Sensor Outputs** field view F/T outputs in each of the six DoF or gage data. Next to the output fields, select the checkboxes of the desired axes to view on the view on the graph.

Additionally, in this field, start or stop readings, bias or unbias data, reset peak values for a new sample, and start or stop logging the data to an exported .csv file.



Figure 5.1—Sensor Outputs Field

5.1 Bias Data

Biasing is useful for eliminating the effects of gravity (tool weight) or other acting forces. When the bias function is used, the software collects data for the forces and torques that are currently acting on the sensor, and uses these readings as a reference for future readings. Future readings have this reference subtracted from them before they are transmitted. Biasing is commonly referred to as taring or zeroing.

In the following figure, the user clicked the **Bias** button in the **Sensor Outputs** field. Force and torque values converge towards zero.

NOTICE: When biasing, ensure the force and torque readings are steady-state. Biasing while the sensor is vibrating, accelerating, or decelerating can provide a poor reference for the user's application.

To remove the bias feature, click the Unbias button in the Sensor Outputs field.



Figure 5.2—Bias Functionality

5.2 Sensor Output Display (F/T or Gages)

5.2.1 Display Gage Data

NOTICE: Gage data is not plotted to the graphs.

To change the **Sensor Outputs** from the default display of F/T data to display gage data, complete the following steps:

- 1. On the toolbar, select **Settings**.
- 2. Select **Display Gages**, from the drop-down menu.

File Tool	s Settings	Help	
	Sens	or Settings	
	Unit	s	•
AI	Grap	h Settings	
-	Rese	t to Default	۲
	Disp	lay Gages	

Figure 5.3—Change Display Settings

In the **Sensor Output** field, the F/T display changes to the following:

Figure 5.4—Change Display Settings



Sensor Outputs

Stop	Reading	Start Logging
G0 [70487	
G1 [491734	
G2	557134	
G3 [168918	
G4 [205936	
G5 [27988	
Bia	s Unb	ias
Re	eset Peaks	

5.2.2 Display F/T Data

- 1. On the toolbar, select **Settings**.
- 2. Select **Display F/T**, from the drop-down menu.



5.3 Setting F/T Units

NOTICE: Users may not be able to change the units of some devices.

To change the F/T units, complete the following steps:

- 1. At the toolbar, select **Settings**.
- 2. Select **Units**, from the drop-down menu.
- 3. Select the desired force units/torque units, from the side-navigation menu.



Figure 5.6—Unit Settings

5.4 RDT Sample Rate and Filtering for NET F/T Sensors

CAUTION: Logging data at a high-speed data collection rate for extended periods of time could cause the application to stop running. Therefore, collect high-speed data over short time periods.

Within the F/T Data Viewer, to adjust an Ethernet F/T sensor's RDT rate and filtering settings, complete the following steps:

- 1. On the toolbar, select **Settings**.
- 2. Select Sensor Settings, from the drop-down menu.

Help
C
isor Settings
its 🕨
ph Settings
et to Default 🕨
play Gages
is

Figure 5.7—Sensor Settings

- 3. In the Sensor Settings window, type the desired RDT Rate in Hz (Hertz) in the RDT Rate field.
- 4. From the **Sensor Filtering** drop-down menu, select the desired filter.

Figure 5.8—Sensor Settings

🛃 Sensor Settings	1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		X
RDT Rate (Hz) 125	Sensor Filtering		
Cancel		Acce	pt

5. Click the **Accept** button to complete the changes, and close the window.

5.5 RDT Sample Rate and Filtering for Serial F/T Sensors

CAUTION: Logging data at a high-speed data collection rate for extended periods of time could cause the application to stop running. Therefore, collect high-speed data over short time periods.

Within the F/T Data Viewer, to adjust a Serial F/T sensor's RDT rate and filtering, complete the following steps:

- 1. On the toolbar, select **Settings**.
- 2. Select Sensor Settings, from the drop-down menu.

Figure 5.9—Sensor Settings



3. In the Sensor Settings window, type the desired RDT Rate in Hz (Hertz) in the RDT Rate field.

NOTICE: For ATI F/T Serial EDU (Educational-RS485-Axia80) sensors, the **Sensor Filtering** cannot be set. So, when using these sensors with this application, the **Sensor Filtering** drop-down menu is grayed-out.

4. Select the desired filter, from the Sensor Filtering drop-down menu.

NOTICE: The **Latency Timer** is a setting on the PC, used for serial communication. Longer latency timers cause a delay in the data shown in F/T Data Viewer. A short latency timer of 4 ms or less is recommended. The default for most PCs is a long latency timer.

Select a time in ms (milliseconds), from the Serial Axia Latency Timer drop-down menu.
 Figure 5.10—Sensor Settings Window

RDT Rate (Hz) Sensor Filtering 500 No Filter Serial Axia Latency Timer 1 ms

- 6. Click the Accept button to complete the changes, and close the window.

5.6 Logging Data

Export and save streamed data to a .CSV file. To complete this logging action, refer to the following steps:

- 1. On the toolbar, select **Tools**.
- 2. Select Logging Settings from the drop-down menu.

Figure 5.11—Tools: Logging Settings



- 3. In the Logging window, create or add data to a file:
 - a. Click the **New File** radio button, to create a new file.
 - b. (or) click the **Append** radio button, to add data to an existing file.
 - c. Click the 🗔 button.

Figure 5.12—Tools: Logging Settings

🔛 Logging Settings	×
D-50-13_FT001234.csv	○ New File ○ Append
Cancel	Accept

- d. In the Save As window, navigate to the directory for either a new or existing file.
- e. In the File name field, do one of the following:
 - Keep the default auto-filled name (date, time, and FT serial number).
 - Type a new file name.
 - Select an existing file.
- f. In the **Save as type** field, select **.csv**.
- g. Click the Save button.

NOTICE: If collecting large amounts of data, understand any limitations the spreadsheet or data analysis program may have on the number of rows it can accommodate.

Comput	er ► OSDisk (C:) ►	▼ *9	Search OSDisk	(C:)	_
ganize 🔻 🛛 New fold	ler)EE 🔻	(
Favorites	Name	Date modified	Туре	Size	
ATI_PDM	ACADLOCATION64	7/18/2018 4:04 PM	File folder		
💶 Desktop	ATI_PDM	7/19/2018 10:17 AM	File folder		
👃 Downloads	퉬 boot	8/19/2015 11:04 PM	File folder		
Recent Places	3 ColdFire	2/1/2019 11:50 AM	File folder		
	\mu cygwin	2/5/2019 10:36 AM	File folder		
Desktop	🎉 cygwin64	2/5/2019 10:34 AM	File folder		
🗎 Libraries	퉬 MinGW	4/17/2018 2:27 PM	File folder		
Documents	JA MININT	3/13/2017 3:09 PM	File folder		
J Music	g MSOCache	5/12/2011 11:44 PM	File folder		
E Pictures	퉳 National Instruments Downloads	10/25/2018 10:58	File folder		
🛃 Videos 👻	٠ [m			
File name: 2019	-03-22 10-52-07 FT001234				_
Save as type: CSV	Files (*.csv)				

Figure 5.13—Save As Window

NOTICE: Data can only be logged while data is in the process of being streamed. **Logging Settings** can be configured before data is streamed.

4. In the **Sensor Output** field, click the **Start Reading** button.

Figure 5.14—Start Running

Churl Type Une Chat	• ^{Fx-}		Fy -		Pz -		Hide MaxiMir
Une Chat	TK TK						Hide MaxMr
			14		12		
Face N							Tangar Ats
	• Fx+N	• Py - N	• Fz · N	Tx - Nm	• Ty - Nm	• Tz - Nm	
	France N	(Yeorg) • FX-N	. <i>Гус.</i> М	• Fx-N • Fy-N • Fz-N	¥ 1992 • Рх-И • Ру-И • Рх-И • То-Ил	• 7x-N • Fy-N • 7x-N • Ta-Nm • Ty-Im	• Fx-N • Fy-N • Fz-N • Tx-Nm • Tz-Nm



Manual, F/T Data Viewer, Software Application Document #9610-05-1042-03

5. Click the **Start Logging** button.

Figure 5.15—Start Logging

	Churt Type	Fx - Max. 8.96451 N Min: 1.68267 N	10.53.24.907 10.53.25.907	Fy - Max178.0 Mirc 106.2	45 N 10.53.25.176 663 N 10.63.26.415	Fz - Max109.595 N 10.53.19.822 Min: 128.1948 N 10.53.25.027	Junio March
ALL AUTOMATION		Tx - Max: -2.48365 Nr Min: -3.38991 Nr	m 10.53.26.108 1 10.53.28.388	ly - Max 2.455 Min: 1.6392	6 Nm 10:53:26.011 15 Nm 10:53:29.794	1z - Max: -3.63549 Nm 10.53.23.535 Min: -3.73581 Nm 10.53.25.027	
ensor Outputs	204.09+						T ^{23.62}
Stor Reading 4.005 N [2]	153.67						- 17.72
-102.645 N (2) -111.763 N (2)	102.45						11.81
3.004 No. 10 2.008 No. 10 3.009 No. 10	51.22-						-5.91
ins Unities	2 0.00		Ŷ				0.00 Inter-N
sec Pesks	51.22						5.91
NatLogging	-102.45-						11.81
	-153.67-						
	204.80						2162
EventLog		• Px - N	• Fy-N	• Fz-N	 Tx - Nm 	Ty - Nm Tz - Nm	

6. Click the **Stop Logging** button to end data collection.

Figure 5.16—Stop Logging



5.6.1 Logging .CSV File

When the output file is opened, information is stored in the CSV file as follows:

The Home Inset Page Lage	ut. Tamular	Data Bank	w. Ver	SOUD	NORKS ROAM	Arroba	6-51()(1255)	6 (Read-Ce	sly1 - Microsoft	Lice										- 0
Culeri	+ II + A	2 = = -	- 20	S-map 1	ent	General			1 118	Normal				7.	1	120	X Autoisian	. 57 /	A	
Parte B / H -	I mai de		ar ar	(III sterne)	A Center +		1.142.2	Canda	ional Farmat	Good	N	ect/al		Insert	Delete	Format	B 18-	Sort & F	nd là	
· Fromat Raintest				and research	a second re-		0	Fermat	ing - as Table -	area .							CONT.	Filter + Se	r helt	
Operand 14	rant		Lights				8-8r			59941	_			_	5.851			and .		_
W29 - K	0																			_
A		C	D	1	F.	0	н	1	1.	ε	1	M	N		0	7	Q		5	
1 Start Time: 1/7/2019 3:07:41 PM																				
3 ROT Sample Rate: 125																				
3 Force Units: N																				
4 Counts per Unit Force: 3000000																				
5 Torque Units: Nm																				
6 Counts per Unit Torque: 1000000																				
7 Status (hex)	RDTSequence	F/T Sequence	FR	FY	R	Tx	Ty	Tz	Title											
8 0+0	168	2207	-3.00384	-3.5233	25.49584	-0.07192	-0.01227	0.831315	15:07:41.205											
9 Ox0	109	2268	-2.95878	-3.51191	25.50646	-0.07125	-0.0124	0.631345	15:07:41.213	7										
0.040	170	2369	-2.58294	-5.55954	25.49195	-0.07703	-0.01294	0.833064	15:07:41.774	1										
11 0x0	171	2270	-1.00174	-3.51054	25.50549	-0.07155	-0.01714	0.8177%	15:07:41.212											
12 GHD	172	2272	-2.98742	-8.54493	25.50342	-0.0733	-0.03227	0.83134/	15/07/41.240	2										
18 040	1/1	22/2	-2.56765	-1.59149	25.50867	-0.07293	-0.01209	0.812923	15/07/01/249	l										
14 0+0	174	2278	2.95722	3.52871	25.5077	0.07147	0.01225	0.832408	15:07:41.254											
15 OVD	175	2274	-2.57266	-3.53853	25.49022	-0.07173	-0.01225	0.832077	15:07:41.264											
36 Ov0	176	2275	-2.55066	-3.56354	25.52657	-0.07187	-0.01296	0.832328	15:07:41.27	1										
17 Ox0	177	2276	-2.99342	-3.55978	25.48394	-0.07292	-0.01174	0.832548	15:07:41.200											
8 Cell	3.78	2277	-2.95995	-1.56556	25.51009	-0.07262	-0.01212	0.8111321	15:07:41.252											
IN OWD	175	2228	-2.98603	-3,53461	25.49235	-0.0716	-0.0113	0.831897	15:07:41.294											
20 OND	180	2279	-2.55/41	-3.55904	25.5087	-0.07343	-0.0134	0.841/11	15/07/61 201	1										
11 DWD	183	2290	-2.96052	-8.51.798	25.50122	-0.0/295	-0.01225	0.83159)	1945/041.311											
22 Ov0	182	2281	2.98648	3.5306	25.50955	0.07163	0.01167	0.831984	15:07:41.320	1										
13 Ov0	183	2282	2.97379	3.56721	25.48976	0.07345	0.01228	0.631877	15:07:41.32											
N4 OWD	154	2263	2.55483	-3.56124	25.49863	-0.07185	-0.01269	0.830282	15:07:41.336											
5 0+0	185	2254	-2.95009	-3.53401	25.50197	-0.07101	-0.01239	0.831364	15:07:41.343											
25 0+0	156	2285	-2.92794	-3.5384	25.50155	-0.07192	-0.01228	0.831334	15:07:41.35	1										
77 OwD	187	2286	-2.95421	-1.51995	25.517	-0.07095	-0.01196	0.611202	15:07:41.15											
28 0+0	188	2287	-2.98344	-3.51218	25.50815	-0.07215	-0.01181	0.831377	15:07:41.143	Q										
040 050	189	2766	-2.93085	-3.54562	25.5377	-0.07248	-0.01285	0.830508	150791.37	5										
and the second second second second second	100	1586	D ATMO	3.83565	TE ANNAL	0.07334	0.01363	A 8596.81	32,07,41,587											-

Figure 5.17—.CSV Output File Opened by a Spreadsheet Program

Row 1: Start Time: The date and time when the measurement was started.

Row 2: **RDT Sample Rate**: The speed (in samples per second) at which the measurement data is sent from the sensor. This rate can be set in Settings

(refer to Section 5.4—RDT Sample Rate and Filtering for NET F/T Sensors or Section 5.5—RDT Sample Rate and Filtering for Serial F/T Sensors).

Note: If the sample rate is changed after F/T Data Viewer application starts, this value will not be updated.

- Row 3: Force Units: These are the force units selected in the Settings (refer to *Section 5.3—Setting F/T Units*).
- Row 4 : **Counts per Unit Force:** All force values (Fx, Fy, Fz) in the CSV file must be divided by this number to get the force values in the selected unit.
- Row 5: **Torque Units**: These are the torque units selected in the **Settings** (refer to *Section 5.3—Setting F/T Units*).
- Row 6: **Counts per Unit Torque**: All torque values (Tx, Ty, Tz) in the CSV file must be divided by this number to get the torque values in the selected unit.
- Row 8 : Header Row: This row displays the title for each column of data or sensor condition.

		Table 5.1	—CSV File (Colun	nn He	ading	js			
Column:	Α	В	С	D	Е	F	G	Н	I	J
Name:	Status (hex)	RDT Sequence	F/T Sequence	Fx	Fy	Fz	Тх	Ту	Tz	Time
Column A:	Status (represer	(hex) is the 32- nted by this row	bit system statu of the CSV fil	ıs cod le.	e asso	ciated	with tl	he data	a pack	et
	Each bir A non-z For a de manual	t signals a certa zero status code etailed descripti in <i>Table 2.1</i> .	in diagnostic c normally mean on of the statue	onditi ns that s code	on (no the F , refer	rmally T syst to the	this c tem ne applic	ode is eds att able	zero). tentior	1.
Column B:	RDT S data tha	equence is a m t is sent from th	umber that star ne sensor to the	ts at o host o	ne and compu	is inc ter.	remen	ted wi	th eacl	h set of
	To find	the elapsed me	asurement time	e, use t	he fol	lowing	g form	ula:		
	Elapsed	d Measurement	$Time = \frac{RDTS}{RD}$	Sequen T Sam	nce Nu aple Ra	mber ute				
	Missing the trou	sequences ind bleshooting sec	icate that data j tion in the app	packag licable	ges we e senso	re lost or man	. To av ual in	void lo <i>Table</i>	st sam 2.1.	ples, to
Column C:	F/T Sec	quence is a nun	nber that is incl	rement	ted wit	th each	n new	F/T m	easure	ment.
Column D:	Fx : the	Fx axis readin	g in units.							
Column E:	Fy : the	Fy axis readin	g in units.							
Column F:	Fz : the	Fz axis reading	g in units.							
Column G:	Tx : the	Tx axis readin	g in units.							
Column H:	Ty : the	Ty axis reading	g in units.							
Column I:	Tz : the	Tz axis readin	g in units.							
Column J:	Time : T Etherne resolution	when the F/T D t F/T. This time on of the comp	ata Viewer app stamp is creat uter.	olication ed by	on rece the co	eived t mpute	he data r and i	a row s limit	from t ted to t	he the clock

Manual, F/T Data Viewer, Software Application Document #9610-05-1042-03

6. Tools

While using the F/T Data Viewer, the following tools are available:

- Logging Settings (refer to Section 5.6—Logging Data)
- Clear the Event Log (refer to *Section 7.1—Clear the Event Log*)
- ATI F/T Webpages (refer to Section 6.2—Sensor Information (Sensor Info))
- Sensor Information (refer to Section 6.2—Sensor Information (Sensor Info))

6.1 ATI F/T Webpages

The ATI F/T Webpages provide additional information and settings for an ATI F/T Ethernet sensor. To access the ATI F/T webpages from the F/T Data Viewer, complete the following steps:

- 1. On the toolbar, select **Tools**.
- 2. Select **View Webpage**, from the drop-down menu.

Figure 6.1—View Webpage



3. Use the menu on the left side of the screen to navigate through the ATI F/T Webpage. For more information about the features, refer to the applicable manual in *Table 2.1*.

Figure 6.2—ATI NET F/T Webpage (shown for reference only)



6.2 Sensor Information (Sensor Info)

Complete the following steps, to view the sensor's serial number, calibration, F/T units, Counts per Force/ Counts per Torque, sampling rates, and protocol:

- 1. On the toolbar, select **Tools**.
- 2. Select Sensor Info, from the drop-down menu.

Figure 6.3—View Webpage



3. View information provided in the **Sensor Info** window.



🖳 Sensor Info	3
Serial Number: FT001234	
Calibration: FT001234	
Calibration Type: Num-4	
Force Units: N	
Torque Units: Nm	
Counts per Force: 1000000	
Counts per Torque: 1000000	
Calibrated Sensing Range: 2147, 2147, 2147, 2147, 2147, 2147	
DHCP Enabled: True	
IP Address: 10.1.1.133	
MAC Address: d8:80:39:c5:18:1f	
RDT Enabled: True	
RDT Rate: 125	
RDT Buffer Size: 1	
	- I
ОК	

Figure 6.5—Serial F/T Sensor Info Example

📴 Sensor Info
Serial Number: FT001234 Calibration Type: Num-4 Force Units: 1 Torque Units: 2 Counts per Force: 1000000
Counts per Torque: 1000000 Torque Units: 2147.494, 2147.494, 2147.494, 2147.494, 2147.494, 2147.494 ADC Rate: 976 RDT Rate: 500 RDT Buffer Size: 1 MAC Address: d8:80:39:c4:e8:69
ок

4. Click **OK** to close the window.

7. Event Log

At the bottom of the main screen, an Event Log field populates with errors or notifications.

F/T Data Vever Serial Number F7001234	Centor Address COM6							- • ×
File Tools Settings Help								
	Chart Type	Fx-		Fy -		#z -		100000000
INDUSTRIAL	4 Line Chat	- Tx -		74 -		τ.		Hide MaxMin
AUTOMATION	<u> </u>			0.058.0				1
Sensor Outputs								
Start Reading								
FA N SZ								
Fy N K								
n= ** 38								
Tix SE								
77								
								qqu
Bias Unbias	Fee							
Reset Pasks								1.1
StartLogging								
EventLog		Fx-N	 Fy-N 	 Fz-N 	 Tx - Nm 	 Ty - Nm 	 Tz - Nm 	
(70) 30 34 AMI Stated	10							
0								

Figure 7.1—Event Log

7.1 Clear the Event Log

To erase messages in the **Event Log**, refer to the following steps:

- 1. On the toolbar, select **Tools**.
- 2. Select **Clear Event Log** from the drop-down menu.





Manual, F/T Data Viewer, Software Application Document #9610-05-1042-03

8. Chart

Optional chart types and graph settings that are available on the F/T Data Viewer are covered in the following sections.

8.1 Chart Type

On the main screen, from the **Chart Type** drop-down menu, select one of three chart types: Line Chart, Bar Chart, or a Multichart (refer to *Figure 8.1* through *Figure 8.3*).



Figure 8.1—Line Chart

Figure 8.2—Bar Chart





Image: Control of the state of the	t Tasiti Settings Histo	Chart Type Fe - Mar. 5 17455	N 110623700 Py-	Mar. 6 55470 N 11:05:25 715	Fg. May 0.05091 N 11-05-17-630	1
Mar Autory PAG	AT ANTOMATION	Tx - Max 0.28767 Max 0.93223	Nm 11.05.25.550 Tr -	Max: 0.00688.7km 11:05:18.550 Max: 4.52458.7km 11:05:27.202	Tz Max: 0.10028 Nm. 11.05.20.689 Min: 0.34395 Nm. 11.05.25.589	Hote MaxMin
Table with the constraint of the constraint	Inter Cutputs Inter Reading (346) N (2) (326) N (2) (3	2243 1771 1874 1876 1876 1876 1876 1877 1876	n	2342 1771- 1139- 1400- 1	TX .	
72 72 72 72 72 72 72 72 72 72 72 72 72 7	440 % 440 % 460 % 8 % 8 % 8 % 8 % 8 % 8 %	204 127- 118- 118- 200 200 200 200 200 200 200 200 200 20	r	2147 - 1100 -	τ	
8 00. 100-	Bert Legging	17 19 - 2013 - 10	12	2012 1177- 1181- 1	72	
enting • Fe-II • Fy-II • Fr-III • Te-IIII • Te-IIII	Eventing	• Fe-10	• Py-N • Pr	N • Te-Nm	• Ty-tim • Ty-tim	

8.2 Chart Maximum and Minimum Values

Above each chart, the maximum values for the forces and torques in x, y, and z axes are displayed. These values are the maximum values that have occurred during a sampling session. The line chart also displays these values as faintly dotted, colored lines. Below each chart, there is a color key for the corresponding measured forces and torques in all three axes.

To hide the maximum and minimum values, click the **Hide Max/Min** button on the upper-right corner of the screen. This feature is functional as the sensor is reading the F/T data.



Figure 8.4—Show or Hide Maximum

8.3 Graph Settings

To format the graph settings, complete the following steps:

- 1. On the toolbar, select **Settings**.
- 2. Select Graph Settings from the drop-down menu.

Figure 8.5—Graph Settings



The **Graph Settings** window opens. Here, adjust graph settings that apply to all the chart types. Click the **Apply** button in the lower-right corner. The window closes, and the settings are displayed.

Even after closing and then reopening the F/T Data Viewer application or swapping sensors, the graph settings are saved from the last session. To reset the settings to the default display, refer to *Section 8.4—Reset Graph Settings Back to Default*,

Max Num Points	Line Types	3	Line	Width
200 Fx	Solid	~	2	~
Fy	Solid	~	2	~
Sample Rate (Hz) Fz	Solid	~	2	~
Tx	Solid	~	2	~
inimum Scaling Limit Ty	Solid	~	2	~
Percentage of Max Rating)	Solid	~	2	~
xis Marks Y Axis Marks Major Tick Marks Major Tick M Minor Tick Marks Minor Tick M Major Grid Lines Major Grid L Minor Grid Lines Minor Grid L	arks arks ines ines	Samp Graph 1	les pe (avera	r Point on age):

Figure 8.6—Graph Settings Window (Samples)

Max Num Points:	The user types a desired number of sample points.
Sample Rate (Hz):	The speed at which the chart pulls data from the sensor. This rate is independent of the sensor's RDT sampling rate. In this field, the user types a number in Hz (hertz).
Line Types:	For F/T data shown on each axis, the user can select these line types from the drop- down menu: dash, dash dot, dash dot, dot, or solid.
Line Width:	The F/T data shown on each axis. The user can select the line width (1 to 10 points) from the drop-down menu.
Minimum Scaling Li	nit: In the text box, the user can type a percentage so that the y-axis is set in incremental units which are the smallest percentage of the maximum rating. Setting a scaling limit prevents environmental factors like noise from obstructing the F/T data that is displayed.
Samples per Point on	Graph: In the text box, a user can type number of points, which are taken from the data collection, to average and merge into one point on the graph.
X and Y Axis Marks:	The user can set incremental tick marks and grid lines along the X and Y axis. All or none of the boxes may be selected.

8.4 Reset Graph Settings Back to Default

To reset the graph settings or colors back to the default display, complete the following steps:

- 1. On the toolbar, select **Settings**.
- 2. Select **Reset to Default...** from the drop-down menu.
- 3. Select either Graph Settings or Graph Colors from the side navigational menu.
- 4. Select Settings and then Graph Settings.
- 5. Review the new settings.
- 6. Click Apply.

Figure 8.7—Reset Graph Settings or Graph Colors to Default Display



9. Troubleshooting

Information in this section is a reference point for questions or concerns that might arise in the field.

9.1 Troubleshooting Resources

A number of troubleshooting resources are within the F/T Data Viewer Application:

- About : a window screen with technical specifications about the F/T Data Viewer Application
- F/T Manuals : a link to the sensor manuals on the ATI webpage
- ATI Home Page : a link to the ATI webpage

To access these resources, refer to the following steps:

1. On the toolbar, select **Help**.



2. Select a resource from the drop-down menu.

9.2 Latency

A user can observe increased latency if the data in the chart on the main screen is a step pattern rather than a smooth curve. To resolve this problem, adjust the computer's latency settings with one of two methods.

9.2.1 Method One (Preferred)

Adjust PC latency settings using the F/T Data Viewer.

- 1. Open the **Settings** menu.
- 2. Select Sensor Settings.
- 3. Select a new value from the **Serial Axia Latency Timer** drop-down window. The recommended latency setting is 3 to 4 ms.
- 4. Click Accept.

9.2.2 Method Two

Adjust PC latency settings using PC menus.

- 1. In the computer's control panel, go to the **Device Manager**.
- 2. Select Ports(COM&LPT).
- 3. Double-click on the device that is the sensor.
- 4. In the Port Settings window, select Advanced.
- 5. Lower the setting on the Latency Timer until the graph shows a smooth curve.

9.3 Resolving Firewall Issues

A user's PC or Ethernet network may use a Firewall which blocks the F/T Data Viewer program from communicating with Ethernet F/T and Ethernet Axia sensors. To avoid the most common firewall issues, follow these steps:

- 1. When installing F/T Data Viewer, select the option to install only "Only for me", not "Anyone who uses this computer (all users)".
- 2. When the F/T Data Viewer searches for an Ethernet sensor's IP address for the first time after install, Windows Firewall or another firewall service may prompt a pop-up window to allow the F/T Data Viewer on the network. For best results, select all checkboxes to allow F/T Data Viewer to communicate.

Net FT Device Setup		Fx - Tx -	Fy - Ту -
Select Sensor IP Ad (Must be on local Searching	dress subnet)	Windows Security Alert	ender Firewall has blocked some features of this
Back	Next	Windows Defender Firewall ha domain networks. Name: Publisher Path:	s blocked some features of FTDataViewer on all public, private and TTDataViewer ATI Industrial Automation C:'program Res (x68) Vali industrial automation/If data
Nm 🖂	-	Allow FTDataViewer to commu	viewer/ftdataviewer.exe nicate on these networks:
Nm 🗸		Private networks, such	as a workplace network as my home or work network
Nm V Nm V Ias Unbias		Domain networks, such Private networks, such Public networks, such public networks, such a because these network What are the risks of allowing	as a workplace network as my home or work network s those in arports and coffee shops (not recommended s often have little or no security) an ago through a frewal?

Figure 9.2—Firewall

- 3. After allowing F/T Data Viewer through the firewall, close F/T Data Viewer and then re-open it.
- 4. Re-open the search for Ethernet sensor IP address; refer to *Section 4.2—Set-Up Communication to an Ethernet Sensor*.

9.4 Customer Service

In addition to these troubleshooting resources, customer service is available:

Note

Please read the manual before calling customer service. Before calling, have the following information available:

- 1. Serial number (e.g., FT01234)
- 2. Sensor model (e.g., Axia, etc.)
- 3. Calibration (e.g., US-15-50, SI-65-6, etc.)
- 4. Accurate and complete description of the question or concern
- 5. Computer and software information, for example: operating system, PC type, drivers, and application software

If possible, be near the F/T system when calling.

Please contact an ATI representative for assistance, if needed:

ATI Industrial Automation 1031 Goodworth Drive Apex, NC 27539 USA www.ati-ia.com

Application Engineering

Tel: +1.919.772.0115, Extension 511 Fax: +1.919.772.8259 E-mail: *ft_support@ati-ia.com*

24/7 Support Tel: +1.855.ATI-IA.00 (+1.855.284.4200)

10. Terms and Conditions of Sale

The following Terms and Conditions are a supplement to and include a portion of ATI's Standard Terms and Conditions, which are on file at ATI and available upon request.

ATI warrants to Purchaser that force torque sensor products purchased hereunder will be free from defects in material and workmanship under normal use for a period of one (1) year from the date of shipment. The warranty period for repairs made under a RMA shall be for the duration of the original warranty, or ninety (90) days from the date of repaired product shipment, whichever is longer. ATI will have no liability under this warranty unless: (a) ATI is given written notice of the claimed defect and a description thereof with thirty (30) days after Purchaser discovers the defect and in any event, not later than the last day of the warranty period and (b) the defective item is received by ATI not later than (10) days after the last day of the warranty period. ATI's entire liability and Purchaser's sole remedy under this warranty is limited to repair or replacement, at ATI's election, of the defective part or item or, at ATI's election, refund of the price paid for the item. The foregoing warranty does not apply to any defect or failure resulting from improper installation, operation, maintenance, or repair by anyone other than ATI.

ATI will in no event be liable for incidental, consequential, or special damages of any kind, even if ATI has been advised of the possibility of such damages. ATI's aggregate liability will in no event exceed the amount paid by the purchaser for the item which is the subject of claim or dispute. ATI will have no liability of any kind for failure of any equipment or other items not supplied by ATI.

No action against ATI, regardless of form, arising out of or in any way connected with products or services supplied hereunder, may be brought more than one year after the cause of action accrued.

No representation or agreement varying or extending the warranty and limitation of remedy provisions contained herein is authorized by ATI, and may not be relied upon as having been authorized by ATI, unless in writing and signed by an executive officer of ATI.

Unless otherwise agreed in writing by ATI, all designs, drawings, data, inventions, software, and other technology made or developed by ATI in the course of providing products and services hereunder, and all rights therein under any patent, copyright, or other law protecting intellectual property, shall be and remain ATI's property. The sale of products or services hereunder does not convey any expressed or implied license under any patent, copyright, or other intellectual property right owned or controlled by ATI, whether relating to the products sold or any other matter, except for the license expressly granted below.

In the course of supplying products and services hereunder, ATI may provide or disclose to Purchaser confidential and proprietary information of ATI relating to the design, operation, or other aspects of ATI's products. As between ATI and Purchaser, ownership of such information, including without limitation any computer software provided to Purchaser by ATI, shall remain in ATI and such information is licensed to Purchaser only for Purchaser's use in operating the products supplied by ATI hereunder in Purchaser's internal business operations.

Without ATI's prior written permission, Purchaser will not use such information for any other purpose of provide or otherwise make such information available to any third party. Purchaser agrees to take all reasonable precautions to prevent any unauthorized use or disclosure of such information.

Purchaser will not be liable hereunder with respect to disclosure or use of information which: (a) is in the public domain when received from ATI, (b) is thereafter published or otherwise enters the public domain through no fault of Purchaser, (c) is in Purchaser's possession prior to receipt from ATI, (d) is lawfully obtained by Purchaser from a third party entitled to disclose it, or (f) is required to be disclosed by judicial order or other governmental authority, provided that, with respect to such to maintain the confidentiality of such information.