



## Wireless Force/Torque Sensor System



Document #: 9620-05-Wireless FT

***Engineered Products for Robotic Productivity***

Pinnacle Park • 1031 Goodworth Drive • Apex, NC 27539 USA • Tel: +1.919.772.0115 • Fax: +1.919.772.8259 • [www.ati-ia.com](http://www.ati-ia.com)

## Foreword

Information contained in this document is the property of ATI Industrial Automation, Inc. and shall not be reproduced in whole or in part without prior written approval of ATI Industrial Automation, Inc. The information herein is subject to change without notice and should not be construed as a commitment of ATI Industrial Automation, Inc. This manual is periodically revised to reflect and incorporate changes made to the F/T system.

ATI Industrial Automation, Inc. assumes no responsibility for any errors or omissions in this document.

Copyright © by ATI Industrial Automation, Inc., Apex, North Carolina USA. All Rights Reserved. Published in the USA.

In consideration that ATI Industrial Automation, Inc. (ATI) products are intended for use with robotic and/or automated machines, ATI does not recommend the use of its products for applications wherein failure or malfunction of an ATI component or system threatens life or makes injury probable. Anyone who uses or incorporates ATI components within any potentially life-threatening system must obtain ATI's prior consent based upon assurance to ATI that a malfunction of ATI's component does not pose direct or indirect threat of injury or death, and (even if such consent is given) shall indemnify ATI from any claim, loss, liability, and related expenses arising from any injury or death resulting from use of ATI components.

All trademarks belong to their respective owners.

Windows™, Windows 7®, Window XP® are a registered trademark of Microsoft Corporation.

MicroSD™ is a trademark of SD-3C, LLC

Wi-Fi™ Direct is a trademark of the Wi-Fi Alliance

### Note

Please read the manual before calling customer service. Before calling, have the following information available:

1. Serial number (e.g., FT01234)
2. Transducer model (e.g., Nano17, Gamma, Theta, etc.)
3. Calibration (e.g., US-15-50, SI-65-6, etc.)
4. Accurate and complete description of the question or problem
5. Computer and software information. Operating system, PC type, drivers, application software, and other relevant information about your configuration.

If possible, be near the F/T system when calling.

### How to Reach Us

Sale, Service and Information about ATI products:

**ATI Industrial Automation**

1031 Goodworth Drive

Apex, NC 27539 USA

[www.ati-ia.com](http://www.ati-ia.com)

Tel: +1.919.772.0115

Fax: +1.919.772.8259

**Application Engineering**

Tel: +1.919.772.0115

Fax: +1.919.772.8259

E-mail: [ft\\_support@ati-ia.com](mailto:ft_support@ati-ia.com)

## Table of Contents

|   |           |
|---|-----------|
| <b>Foreword</b> .....   | <b>2</b>  |
| <b>Glossary</b> .....   | <b>6</b>  |
| <b>1. Safety</b> .....  | <b>7</b>  |
| 1.1 Explanation of Notifications .....  | 7         |
| 1.2 General Safety Guidelines .....   | 7         |
| 1.3 Safety Precautions .....  | 7         |
| <b>2. System Overview</b> .....   | <b>8</b>  |
| 2.1 Three Transducer Wireless F/T .....   | 9         |
| 2.2 Six Transducer Wireless F/T .....   | 10        |
| 2.3 Antenna .....   | 11        |
| 2.4 Micro USB Connector .....   | 11        |
| 2.5 MicroSD Card Slot .....   | 11        |
| 2.6 External Power Adapter .....  | 11        |
| 2.7 USB Cable .....   | 11        |
| 2.8 Mounting features .....   | 11        |
| 2.8.1 Removable Belt Clip .....   | 11        |
| 2.8.2 Threaded Holes .....  | 11        |
| 2.9 Removable Battery .....   | 11        |
| 2.10 Controls and Indicators .....  | 12        |
| 2.10.1 Power Button .....   | 12        |
| 2.10.2 Power Button Indicator .....   | 12        |
| 2.10.3 Transducer Status Indicators .....   | 12        |
| 2.10.4 Wireless Status Indicator .....  | 12        |
| 2.10.5 Battery Status Indicator .....   | 13        |
| 2.10.6 External Power Indicator .....   | 13        |
| <b>3. Initial Configuration and Installation of the Wireless F/T System</b> ..... | <b>14</b> |
| 3.1 Preparing your Wireless F/T for Configuration .....                           | 14        |
| 3.2 Initial Configuration .....   | 15        |
| 3.3 The Wireless F/T Java Demo Application .....                                  | 17        |
| 3.3.1 Creating a test profile .....   | 17        |
| 3.3.2 Connecting to the Wireless F/T .....  | 19        |
| 3.3.3 Data Collection .....   | 21        |
| 3.3.3.1 Collecting and Storing Data on a PC or Network File .....                 | 21        |
| 3.3.3.2 Collecting and Storing Data on a MicroSD Card .....                       | 22        |

|            |   |           |
|------------|---|-----------|
| <b>3.4</b> | <b>Mounting the Wireless F/T Unit</b> .....                           | <b>22</b> |
| 3.4.1      | Belt Clip Installation.....   | 22        |
| 3.4.2      | Fixed Installation .....  | 22        |
| <b>3.5</b> | <b>External Power Adapter Installation</b> .....                      | <b>22</b> |
| <b>4.</b>  | <b>Installing the Transducer</b> .....                                | <b>23</b> |
| <b>5.</b>  | <b>Command Interface</b> .....  | <b>24</b> |
| 5.1        | Communication Interfaces .....  | 24        |
| 5.2        | Commands.....   | 24        |
| 5.3        | Basic Wireless F/T Commands .....                                     | 24        |
| 5.4        | Commands For Modifying Wireless Settings .....                        | 27        |
| 5.5        | Commands Related to the Transducer Output.....                        | 34        |
| 5.6        | Commands Related to the Functionality of the MicroSD Card Reader..... | 37        |
| 5.7        | Commands Related to NTP Time Synchronization:.....                    | 39        |
| 5.8        | UDP Interface.....  | 41        |
| 5.9        | UDP Command Format .....  | 41        |
| 5.10       | Data Packet.....  | 43        |
| 5.10.1     | Calculating F/T values for Data Packages .....                        | 45        |
| 5.11       | Processor Firmware Update Procedure.....                              | 46        |
| <b>6.</b>  | <b>Maintenance</b> .....  | <b>47</b> |
| 6.1        | Preventive Maintenance .....  | 47        |
| 6.2        | Battery Recharging and Replacement .....                              | 47        |
| 6.2.1      | Charging Battery Internally.....                                      | 47        |
| 6.2.2      | Charging Battery Externally.....                                      | 47        |
| <b>7.</b>  | <b>Troubleshooting</b> .....  | <b>48</b> |
| <b>8.</b>  | <b>Serviceable Parts</b> .....  | <b>48</b> |
| <b>9.</b>  | <b>Specifications</b> .....   | <b>49</b> |
| 9.1        | Wireless Characteristics.....   | 49        |
| 9.2        | Power Requirements.....   | 49        |
| 9.2.1      | Wireless Power Levels.....  | 49        |
| 9.3        | Physical Characteristics.....   | 50        |
| 9.4        | Transducer Inputs .....   | 50        |
| 9.4.1      | Analog Transducer Data Filtering.....                                 | 51        |
| <b>10.</b> | <b>Regulatory Information</b> .....                                   | <b>52</b> |
| 10.1       | FCC Statement.....  | 52        |
| 10.2       | Canadian Compliance Statement .....                                   | 52        |

- 11. Drawings ..... 54**
  - 11.1 Wireless Net F/T for 3 Transducers ..... 54**
  - 11.2 Wireless Net F/T for 6 Transducers ..... 55**
- 12. Terms and Conditions of Sale ..... 56**
  - B.1 Initial Configuration Using a Telnet Program ..... 59**
  - C.1 Introduction ..... 63**
  - C.2 Definitions ..... 63**
  - C.3 Wireless F/T Digital Input Sampling ..... 63**
  - C.4 Wireless F/T Analog Input Sampling ..... 63**
  - C.5 Wireless F/T Analog Input Calibration ..... 65**
    - C.5.1 Internal Calibration ..... 65
    - C.5.2 External Calibration ..... 66
  - C.6 Troubleshooting ..... 68**
  - D.1 Converting NTP Format to Seconds ..... 69**
  - D.2 Excel Conversion Example ..... 69**

## Glossary

| Terms                   | Definitions   |
|-------------------------|---|
| ADC                     | Analog to Digital Converter.  |
| Big-endian              | Indicates the most significant byte of a value is stored first.   |
| DHCP                    | Dynamic Host Configuration Protocol (DHCP) is an automatic method for Ethernet equipment to obtain an IP address. The WNet system can obtain its IP address using DHCP on networks that support this protocol.  |
| Ethernet Network Switch | Ethernet network switches are electronic devices that connect multiple Ethernet cables to an Ethernet network while directing the flow of traffic.  |
| F/T                     | Force/Torque.   |
| Gateway Settings        | The address of the router that handles a network's Ethernet traffic.  |
| IEEE                    | The Institute of Electrical and Electronics Engineer, inc.  |
| IP Address              | An Internet Protocol Address (IP Address) is an electronic address assigned to an Ethernet device so that it may send and receive Ethernet data. IP addresses may be either manually selected by the user or automatically assigned by the DHCP protocol. |
| IPv4                    | Internet Protocol version 4 (IPv4) is a standard used for specifying the electronic address of an Ethernet device. The Wireless F/T supports only IPv4.   |
| MAC Address             | Media Access Control Addresses (MAC Addresses) are the unique addresses given to every Ethernet device when it is manufactured, to be used as an electronic Ethernet serial number.   |
| Network Order           | The order in which data values are placed on a network. The WNet's network order is big-endian  |
| RDT                     | Raw Data Transfer (RDT) is a fast and simple WNet protocol for control and data transfer via UDP.   |
| RSSI                    | Received Signal Strength Indicator.   |
| Scaling Factor          | A Counts per Force or Counts per Torque value that is obtained from the calibration file.   |
| Sensor System           | The assembly consisting of all components from the transducer to the WNet box.  |
| SSID                    | The name of a wireless local area network.  |
| Subnet Mask             | A string of numbers used to indicate which portion of a network's IP addresses is common to all devices on the local network.   |
| TCP                     | Transmission Control Protocol (TCP) is a method of exchanging information frequently used over Ethernet.  |
| UDP                     | User Datagram Protocol (UDP) is a low-level method of transmitting data over Ethernet. While UDP is faster than TCP, unlike TCP lost UDP data is not resent.  |
| USB                     | Universal Serial Bus (USB). The WNet's USB port conforms to this computer peripheral cabling standard.  |
| WLAN                    | Wireless Local Area Network (WLAN). The WNet system conforms to the IEEE 802.11 WLAN standard.  |
| WNet                    | Wireless F/T  |

## 1. Safety

The safety section describes general safety guidelines to be followed with this product, explanations of the notifications found in this manual, and safety precautions that apply to the product. More specific notifications are imbedded within the sections of the manual where they apply.

### 1.1 Explanation of Notifications

The following notifications are specific to the product(s) covered by this manual. It is expected that the user heed all notifications from the robot manufacturer and/or the manufacturers of other components used in the installation.



**CAUTION:** Notification of information or instructions that if not followed could result in moderate injury or will cause damage to equipment. The notification provides information about the nature of the hazardous situation, the consequences of not avoiding the hazard, and the method for avoiding the situation.



**ATTENTION:** Le non-respect des informations ou des instructions contenues dans la notice peut entraîner des blessures moyennement graves ou causer des dommages à l'équipement. La notice fournit des informations sur la nature de la situation dangereuse, les conséquences si le danger n'est pas évité, et la méthode pour éviter la situation.

**NOTICE:** Notification of specific information or instructions about maintaining, operating, installation, or setup of the product that if not followed could result in damage to equipment. The notification can emphasize, but is not limited to: specific grease types, good operating practices, and maintenance tips.

### 1.2 General Safety Guidelines

The customer should verify that the transducer selected is rated for maximum loads and moments expected during operation. Refer to F/T Transducer Manual (9620-05-Transducer Section—Installation and Operation Manual) or contact ATI Industrial Automation for assistance. Particular attention should be paid to dynamic loads caused by robot acceleration and deceleration. These forces can be many times the value of static forces in high acceleration or deceleration situations.

### 1.3 Safety Precautions



**CAUTION:** Do not remove any fasteners or disassemble the Wireless F/T. This will cause irreparable damage to the Wireless F/T and void the warranty. Leave all fasteners in place and do not disassemble the Wireless F/T.




**ATTENTION:** Ne pas retirer les attaches ni démonter le Wireless F/T. Ceci causera des dommages irréparables au Wireless F/T et annulera la garantie. Laisser toutes les attaches en place et ne pas démonter le Wireless F/T.

## 2. System Overview

The Wireless F/T can measure six degrees of freedom forces and torques ( $F_x$ ,  $F_y$ ,  $F_z$ ,  $T_x$ ,  $T_y$ , and  $T_z$ ) from multiple transducers and streams the data to an existing wireless access point on the network. This data can be used for data collection, real-time motion control, or user-defined signal processing by the user's host device. The Wireless F/T can also store the data on a memory card.

The range and performance of the Wireless F/T device is derived from the IEEE 802.11 standard. Actual performance may vary due to conditions, wireless infrastructure, and other variables. Refer to [Section 9—Specifications](#) for more details.

**Figure 2.1—Signal Path to a Computer, Using a Wireless Access Point**



The Wireless F/T is a small wireless device for controlling up to six ATI Multi-Axis Force/Torque transducers. The device supports ATI's TW-type transducers such as the Nano and Mini. Transducers with integrated electronics are not supported. The device is equipped with a MicroSD card slot used to collect and store data. The Wireless F/T is contained in an impact, splash, and dust resistant housing.


The Wireless F/T unit is provided with an external antenna that can be pivoted 90° so the unit can be used in small confined spaces. Fixed mounting is accommodated with the four robust threaded inserts on the back plate of the housing. The unit is provided with a removable belt clip for mobile applications. The Wireless F/T can be powered by a rechargeable battery, or can be powered with the 5 VDC external power adapter using the USB connector. The battery can be charged internally or externally.

The Wireless F/T includes a rechargeable battery, antenna, external power adapter, USB cable, and removable belt clip. Optional desktop battery charger and international power cords are available, refer to [Section 8—Serviceable Parts](#) for more details.

## 2.1 Three Transducer Wireless F/T

The three Transducer Wireless F/T model can interface with up to three ATI Multi-Axis Force/Torque transducers simultaneously. Each of the three transducer connectors has a transducer status indicator. The device has a rechargeable battery that can power the device for approximately two hours at full measurement rate with all three transducers enabled. The battery life is extended significantly when using fewer transducers.


Figure 2.2—Three Transducer Wireless F/T



## 2.2 Six Transducer Wireless F/T

The six Transducer Wireless F/T model can interface with up to six ATI Multi-Axis Force/Torque transducers simultaneously. Each of the six transducer connectors has a transducer status indicator. The device has a rechargeable battery that can power the device for approximately one hour at full measurement rate with all six transducers enabled. The battery life is extended significantly when using fewer transducers.

Figure 2.3—Six Transducer Wireless F/T



## 2.3 Antenna

The Wireless F/T Unit has been certified for use with the antenna provided. The antenna can pivot 90° to allow the Wireless F/T unit to fit into small confined spaces.

## 2.4 Micro USB Connector

The Wireless F/T unit has a Micro USB connector that can be used to power the unit and charge the battery using the external power adapter.

## 2.5 MicroSD Card Slot

The Wireless F/T unit has a MicroSD card slot that can be used to store data on a customer supplied MicroSD card. The file system supports files sizes up to 4 G bytes. If using a MicroSD card to store data, the system will create a subdirectory \ATI and a *Fn.dat* data file on the MicroSD card. If multiple sessions are saved on the MicroSD card the system will sequence the data file *F1.dat*, *F2.dat* ... etc. Refer to [Section 5—Command Interface](#) for more information.

## 2.6 External Power Adapter

The external power adapter is a 5 V 10 W plug mounted power supply that can operate the unit and charge the battery. The adapter operates on 100 to 240 VAC and provides a USB Micro-A output connector. Removable plug adapters are available for use with various power socket types.

## 2.7 USB Cable

The USB cable connects the external power adapter to the Wireless F/T unit by way of its USB Type A and Micro-B USB connectors.

## 2.8 Mounting features

Refer to [Section 11—Drawings](#) for information on mounting features.

### 2.8.1 Removable Belt Clip

The Wireless F/T unit has a removable belt clip for easy mounting and removal from human or humanoid robot applications.

### 2.8.2 Threaded Holes

Four threaded holes are available when the belt clip is removed.

## 2.9 Removable Battery

A rechargeable lithium-polymer battery is provided with the Wireless F/T unit. The battery can be charged inside the Wireless F/T using the external power adapter through the micro USB connector or using the optional desktop battery charger. Refer to [Section 6.2—Battery Recharging and Replacement](#) for more information.

## 2.10 Controls and Indicators

The Wireless F/T has controls and integrated status indicators. The Status indicator information is periodically transmitted over the wireless network to the host device. See [Figure 2.2](#)—three Transducer Wireless F/T model or [Figure 2.3](#)—six Transducer Wireless F/T model for location of controls and indicators.

### 2.10.1 Power Button

The Power Button turns the unit on and off, has an integrated system status indicator, and supports auto power-off. The Power Button supports the following functionality:

| Table 2.1—Power Button Functionality |                          |
|--------------------------------------|--------------------------|
| Press Duration                       | Description              |
| Momentary                            | Powers on the unit.      |
| (2) Seconds                          | Powers off the unit.     |
| (10) Seconds                         | Power cycles the system. |

Power cycling the system will reset the DHCP, IP address, subnet mask, gateway settings, and authenticated user password to the last saved settings.

### 2.10.2 Power Button Indicator

This indicator is located within the recessed Power Button.

| Table 2.2—System Status Indicator |  |
|-----------------------------------|--|
| Behavior                          | Description  |
| Off                               | Indicates the system is either off or in charging-only mode. |
| Steady Blue                       | Indicates the system is on.                                  |

### 2.10.3 Transducer Status Indicators

The Wireless F/T has a transducer status indicator on the top of the device, beside its corresponding connector.

| Table 2.3—Transducer Status Indicators |  |
|--|--|
| Behavior                               | Description  |
| Steady Green                           | Indicates normal transducer operation.   |
| Steady Red                             | Indicates a fault with the transducer.   |
| Off                                    | Indicates the transducer is off, the entire unit is off, or the unit is in charging-only mode. |

### 2.10.4 Wireless Status Indicator

The wireless status indicator is on the front of the Wireless F/T below the antenna connector.

| Table 2.4—Wireless Status Indicator |   |
|-------------------------------------|---|
| Behavior                            | Description   |
| Steady Green                        | Indicates the unit is connected to an Access Point and there are no current wireless errors.                                |
| Flashing Green                      | Indicates the unit is attempting to connect to an Access Point.   |
| Steady Red                          | Indicates the unit is connected to an Access Point, and an error has been recently detected.                                |
| Flashing Red                        | Indicates the wireless subsystem is recovering from a lock-up condition. Refer to <a href="#">Section 7—Troubleshooting</a> |
| Off                                 | Indicates the unit is either off or in charging-only mode.  |

### 2.10.5 Battery Status Indicator

The battery indicator is on the front of the device next to the battery compartment.

| Table 2.5—Battery Status Indicator |   |
|------------------------------------|---|
| Behavior                           | Description   |
| Steady Green                       | Indicates the battery is charged.   |
| Flashing Green                     | Indicates the battery is charging.  |
| Flashing Red                       | Indicates the battery charge is below 25%.  |
| Steady Red                         | Indicates a battery fault, such as the battery voltage is too low, or the battery is too warm, or is missing. |
| Off                                | Indicates the unit is off.  |

### 2.10.6 External Power Indicator

The external power indicator is on the front of the unit next to the left-side located USB connector.

| Table 2.6—External Power Status Indicator |   |
|---|---|
| Behavior                                  | Description   |
| Steady Green                              | Indicates the external power source connected to the USB port is operating normally.              |
| Steady Red                                | Indicates the external power source connected to the USB port is not supplying proper voltage.    |
| Off                                       | Indicates there is no external power adapter connected to the USB port, or it is not functioning. |

### 3. Initial Configuration and Installation of the Wireless F/T System


This section explains how to configure the basic functionality of your Wireless F/T system. The Wireless F/T system consist of several components: Wireless F/T unit, transducer(s), external power adapter and plugs, USB cable, and software. The Wireless F/T unit must be set up and configured before installing the transducer so that forces can be monitored during installation.

#### 3.1 Preparing your Wireless F/T for Configuration

1. Unpack the system components from the container.
2. Use a flat head screw driver to open the battery door (Note: ¼ turn clockwise to open and ¼ turn counterclockwise to close). Insert the battery with the label facing the front of the Wireless F/T Unit, then close and secure the battery door.
3. Connect the USB cable to the Wireless F/T unit and the external power adapter provided. Plug the power adapter into the wall.
4. Wait for the battery charge status indicator to transition from flashing to solid green indicating the battery is fully charged. Note: This could take a few hours with a factory-new battery.
5. Attach the antenna to the Wireless F/T Unit.
6. Connect the transducer cable to the connector on the Wireless F/T unit. Ensuring each Transducer and the corresponding Wireless F/T connector position are labeled with the same serial number, refer to [Figure 2.2](#) or [Figure 2.3](#). (Note: Transducer cable will need to be rotated until the alignment notch is oriented properly). Tighten the connector finger tight.
7. Disconnect the USB cable from the power supply and plug into USB port on the computer to be used to configure the Wireless F/T unit. Refer to [Figure 3.1](#). Note: A computer connected to the USB port may not provide sufficient power to keep the battery fully charged.

**NOTICE:** You will need Java version 1.7 or higher on your PC to run the provided Wireless F/T Java Demo. This can be downloaded at <http://www.java.com/> while you wait for the battery to charge.

**Figure 3.1—Connect the USB cable from the Wireless unit to the Computer**




## 3.2 Initial Configuration

The Wireless F/T must be configured for your wireless network before you can communicate with the device. The following procedure provides the steps needed to properly configure the Wireless F/T.

1. After connecting the Wireless F/T to the computer with the provided USB cable, it will begin to obtain the proper COM port drivers. This may take a few minutes. If they do not install on their own, install the Virtual Communication Port Driver per the instructions for your operating system found at: <http://www.ftdichip.com/Support/Documents/InstallGuides.htm>
2. Power on the Wireless F/T unit by momentarily depressing the power button on the top of the device. The device initiates a power up sequence and the Wireless Status Indicator LED begins flashing green as it scans for wireless networks.
3. Visit the ATI website (<http://www.ati-ia.com/library/download.aspx>) to locate the setup.exe file.
4. Copy or download the file to the directory desired and double click to open the program.
5. Follow the instructions within the Setup Wizard to install the Wireless F/T Settings Editor.

Figure 3.2—Setup Wizard



6. Locate the Wireless F/T Setup Editor in the ATI Industrial Automation folder under All Programs on your Windows Start bar and double click to open the program.

Figure 3.3—Wireless F/T Setup program




7. Select the COM port corresponding to your Wireless F/T and press the connect button. You may need to press the “Refresh” button if no COM ports are shown.
8. Obtain your WLAN Network Name (SSID), password, and frequency band (bandwidth 2.4 GHz or

5 GHz) from your network administrator. If your wireless network is not shown, press the “Refresh” button. Note: This will result in the Wireless F/T unit resetting while it attempts to locate nearby wireless networks. If you are switching between the 2.4 GHz and 5 GHz bands, you will need to input the Network Name manually as the Wireless F/T cannot scan one band for networks while connected to the other, consequently the networks will not show in the pull down list.


**NOTICE:** For 5 GHz Band, due to the Indoor/Outdoor rating of the Wireless F/T, the device is only allowed to connect to channels 149, 153, 157, 161, and 165. Many 5 GHz routers will default to a restricted “indoor only” channel. If you have connection issues, you may need to check your router settings and ensure it is connected to one of the channels listed above.

Figure 3.4—Network (SSID) Settings



9. Select the “IP Settings” tab. Note that in this example DHCP is enabled. If a static IP address is desired, deselect DHCP and enter the Device IP dedicated to the Wireless F/T, the access point Default Gateway, and Subnet Mask into the fields shown in [Figure 3.5](#).

Figure 3.5—IP Settings



10. When you have made all the appropriate changes to the device settings, press the “OK” button to apply the changes. The window will automatically close at this point and the Wireless F/T will reset upon exit.
11. Once the Wireless F/T has been powered up completely, the Wireless Status Indicator LED will transition from flashing to solid green if it has properly connected to your wireless network. If the device does not connect properly, verify the network settings entered above.

**NOTICE:** The Wireless F/T can transmit a large volume of data across a wireless network. It is suggested that you use a dedicated wireless access point so that you do not affect other wireless devices on your network. A dedicated high strength local wireless network will result in the most reliable connection.

### 3.3 The Wireless F/T Java Demo Application

#### 3.3.1 Creating a test profile

The following steps are provided to create a test profile on the Wireless F/T Java Demo application.


1. Visit the ATI website (<http://www.ati-ia.com/library/download.aspx>) and locate the WirelessFTJavaDemo.jar file.
2. Copy or download the file to the directory desired and double click to open the program.
3. Use the Wireless F/T Profile Wizard to create a new profile for the device by pressing the “Create new...” button.

Figure 3.6—Profile Creation




4. Use this initial welcome page to add any notes that you’ll want to be able to reference when you review this profile in the future.

Figure 3.7—Welcome




5. Use this page to configure the basic settings of your Wireless F/T system.

**Figure 3.8—Transducer Settings**




6. Use this page to add any filters to your data and to select the proper calibration for each transducer (if a sensor contains multiple calibrations).

**Figure 3.9—Filters and Calibrations**



7. Your new Wireless F/T profile is now ready to use. Press the Finish button to exit.


**Figure 3.10—Your Profile is Ready**



### 3.3.2 Connecting to the Wireless F/T

1. Select the proper profile and press the Start button as shown in [Figure 3.6](#).
2. Press the "Discover..." button to find which Wireless F/T devices are currently on the network your PC is connected to.
3. Once you have selected the proper device, press the "Connect" button. The application will begin displaying streaming data from the active transducers connected to the Wireless F/T Unit.

Figure 3.11—Establish a Connection



- See [Section 3.3.3—Data Collection](#) for using the data collection features
- The data rate can be dynamically adjusted by inputting a value (between 10-4000) and clicking the “Apply Rate” button.
- The data type displayed can be switched to F/T data or Gage (diagnostic) data by clicking the corresponding buttons.
- The LED Status from the Wireless F/T unit will also be displayed in this left column.
- Red text for a transducer indicates that the transducer is loaded beyond its measurement range and is saturated.
- Data packet transmission statistics are provided. This is useful for determining an optimal packet rate and also gives an indication of wireless network strength.
- The “Bias” button for each transducer will set the current load level as the new zero point.
- The “Unbias” button will remove the offset (if Bias had been pressed).
- An onscreen log of messages is displayed at the bottom of the screen.

### 3.3.3 Data Collection

There are two ways data can be stored. Data can be collected and stored on a file on a PC or network directory, and/or it can be collected and stored on the customer’s MicroSD card plugged into the Wireless F/T unit.

#### 3.3.3.1 Collecting and Storing Data on a PC or Network File

To collect data to a file, click the “...” button to the left of the field and select a location and filename for your data. Refer to [Figure 3.11](#). Click the “Collect Data” button to begin. Once you have completed your test, click the “Stop” button to finish collecting data.

The measurement data is stored in comma-separated value format (CSV) so it can easily be read by spreadsheets and data-analysis programs. Name your file with a .CSV extension. If you are planning on collecting large amounts of data, it is a good idea to understand any limitations your spreadsheet or data analysis program may have on the number of rows it can use.

**Figure 3.12—Sample CSV Data File Opened in a Spreadsheet**

|    | A                       | B               | C           | D             | E             | F           | G                      | H                      | I                      | J                       | K                       | L                       |
|----|-------------------------|-----------------|-------------|---------------|---------------|-------------|------------------------|------------------------|------------------------|-------------------------|-------------------------|-------------------------|
|    | Wireless F/T Time Stamp | Sequence Number | Status Code | Status Code 2 | Battery Level | Sensor Mask | Transducer 1 ForceX/G0 | Transducer 1 ForceY/G1 | Transducer 1 ForceZ/G2 | Transducer 1 TorqueX/G3 | Transducer 1 TorqueY/G4 | Transducer 1 TorqueZ/G5 |
| 1  | 9199757                 | 35456           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26497                 | -19562                 | -25728                  | -25541                  | -25211                  |
| 2  | 9200007                 | 35457           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26508                 | -19571                 | -25740                  | -25549                  | -25217                  |
| 3  | 9200257                 | 35458           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26508                 | -19571                 | -25737                  | -25547                  | -25218                  |
| 4  | 9200507                 | 35459           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26506                 | -19570                 | -25734                  | -25545                  | -25213                  |
| 5  | 9200757                 | 35460           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26514                 | -19569                 | -25738                  | -25548                  | -25214                  |
| 6  | 9201007                 | 35461           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26504                 | -19566                 | -25733                  | -25546                  | -25213                  |
| 7  | 9201257                 | 35462           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26504                 | -19566                 | -25734                  | -25543                  | -25212                  |
| 8  | 9201507                 | 35463           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19568                 | -25733                  | -25543                  | -25215                  |
| 9  | 9201757                 | 35464           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26507                 | -19567                 | -25731                  | -25547                  | -25213                  |
| 10 | 9202007                 | 35465           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26503                 | -19565                 | -25727                  | -25543                  | -25212                  |
| 11 | 9202257                 | 35466           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19568                 | -25736                  | -25548                  | -25216                  |
| 12 | 9202507                 | 35467           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26509                 | -19568                 | -25733                  | -25549                  | -25217                  |
| 13 | 9202757                 | 35468           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19569                 | -25732                  | -25547                  | -25212                  |
| 14 | 9203007                 | 35469           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26508                 | -19568                 | -25735                  | -25548                  | -25216                  |
| 15 | 9203257                 | 35470           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26513                 | -19572                 | -25740                  | -25551                  | -25219                  |
| 16 | 9203507                 | 35471           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26508                 | -19570                 | -25739                  | -25545                  | -25217                  |
| 17 | 9203757                 | 35472           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26509                 | -19566                 | -25734                  | -25551                  | -25215                  |
| 18 | 9204007                 | 35473           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26501                 | -19565                 | -25732                  | -25550                  | -25218                  |
| 19 | 9204257                 | 35474           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26503                 | -19566                 | -25732                  | -25547                  | -25214                  |
| 20 | 9204507                 | 35475           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26504                 | -19565                 | -25733                  | -25549                  | -25214                  |
| 21 | 9204757                 | 35476           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19567                 | -25735                  | -25546                  | -25212                  |
| 22 | 9205007                 | 35477           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26506                 | -19568                 | -25738                  | -25550                  | -25216                  |
| 23 | 9205257                 | 35478           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19567                 | -25733                  | -25546                  | -25216                  |
| 24 | 9205507                 | 35479           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19565                 | -25734                  | -25548                  | -25215                  |
| 25 | 9205757                 | 35480           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26509                 | -19568                 | -25736                  | -25550                  | -25217                  |
| 26 | 9206007                 | 35481           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26503                 | -19568                 | -25731                  | -25544                  | -25213                  |
| 27 | 9206257                 | 35482           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26508                 | -19567                 | -25738                  | -25546                  | -25216                  |
| 28 | 9206507                 | 35483           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26510                 | -19568                 | -25735                  | -25548                  | -25219                  |
| 29 | 9206757                 | 35484           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26506                 | -19568                 | -25738                  | -25548                  | -25217                  |
| 30 | 9207007                 | 35485           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26499                 | -19564                 | -25734                  | -25545                  | -25212                  |
| 31 | 9207257                 | 35486           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26505                 | -19563                 | -25730                  | -25545                  | -25211                  |
| 32 | 9207507                 | 35487           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26504                 | -19567                 | -25732                  | -25542                  | -25212                  |
| 33 | 9207757                 | 35488           | 53f0aaa     | 0             | 6             | 7           | 32767                  | -26503                 | -19565                 | -25734                  | -25546                  | -25212                  |



## 4. Installing the Transducer


Information on the environment, mounting the transducer, interface plate design, and routing the transducer cable can be found in the F/T Transducer Installation and Operation manual (9620-Transducer Section). The transducer must be monitored during installation for gage saturation errors. Refer [Section 3.3.2—Connecting to the Wireless F/T](#) to monitor the transducer during installation.



**CAUTION:** Do not exceed the single-axis overload value of the transducer. Smaller transducers can easily be irreparably damaged by applying small loads using tools (moment arm increases applied loads) when mounting the transducer. Always monitor the transducer using the demo application for Gage saturation errors during installation. Stop applying force to the transducer and wait until the error clears to continue installation. If error does not clear, it may indicate loss of power or the overload value has been exceeded.



**ATTENTION:** Ne pas dépasser la valeur de surcharge de l'axe unique du transducteur. Les petits transducteurs peuvent être irrémédiablement endommagés suite à l'application de petites charges en utilisant des outils (le bras de levier augmente les charges appliquées) lors du montage du transducteur. Toujours surveiller le transducteur à l'aide de l'application de démonstration en cas d'erreurs de calibration saturée lors de l'installation. Cesser d'appliquer la force au transducteur et attendre que l'erreur disparaisse pour continuer l'installation. Si l'erreur ne disparaît pas, cela peut indiquer une perte de puissance ou un dépassement de la valeur de surcharge.



## 5. Command Interface

The Wireless F/T unit must be installed, setup and configured prior to using any command interfaces. Refer to [Section 3—Initial Configuration and Installation of the Wireless F/T System](#) for installation, setup, and configuration of the WNet unit.

### 5.1 Communication Interfaces

The Wireless F/T can be setup and configured using a text-based command prompt console interface.

The Console Interface can be accessed two ways:

- Over the USB connection by way of a virtual serial port
- Wirelessly by way of a Telnet connection. The unit listens on port 23.

### 5.2 Commands

These commands are available to any user, including commands to enter authenticated user and technician user modes. All users can read any information about the system, including values that only authenticated or technician users can write to.

The console interface is a text-based command prompt interface that allows the user to read and update system settings.

Enter most commands without operands to display current status.

### 5.3 Basic Wireless F/T Commands

#### **HELP, H, or ? – Prints help text**

These commands print a summary of the console commands supported by the Wireless F/T.

#### **BRIGHT *i* – Set Indicator brightness**

where:

*i* = integer from 0 to 100

This command sets the brightness level of the unit's indicators. Brightness ranges from 0 to 100, where 0 is completely dark and 100 is completely on.

#### **D *s* – Dump UDP Packets to Console**

where:

*s* = ON or OFF

This command controls the dumping of outgoing UDP data packets to the console. See [Section 5.10—Data Packet](#) for information on the packets.

| Command | Action   |
|---------|--|
| D ON    | Console receives dump of outgoing UDP packets              |
| D OFF   | Console dumping of outgoing UDP packets disabled           |
| D       | Toggles the dumping of outgoing UDP packets to the console |

>D

Dump Packet On

```
>8030cd06 000001be 06150216 00000000 0a 07 0000062f 00000c3d 0000040e f.  
8030cd27 000001bf 06150216 00000000 0a 07 00000630 00000c3d 0000040d f.  
8030cd47 000001c0 06150216 00000000 0a 07 0000062f 00000c3d 0000040c f.
```

·  
·  
·

**POWER s – Set Power Mode**

where:

s = ON, OFF, or CHARGE

This command controls the unit's power mode.

| Command      | Action  |
|--------------|---|
| POWER ON     | Turns unit on (just like pushing the power button).             |
| POWER OFF    | Turns unit completely off and not charging (no USB connection). |
| POWER CHARGE | Turns unit off but charging (USB connection to power source)    |

The POWER command will also report the unit's power status when issued without arguments.

```
>POWER
POWER On
>
```

**RESET – Reset Unit**

This command resets the unit. This will cause a disconnect from the console when connected via the virtual serial port. Any settings not saved with the SAVEALL command will be lost. If the unit is connected to a computer via USB, the unit will enter charging mode.

**SAVEALL – Save All Settings**

This command saves all settings so that they will survive a unit reset or power cycle.

```
>SAVEALL
All parameters saved to Serial Flash Primary
All parameters saved to Serial Flash Secondary
>
```

**T s – Transmit UDP Packets to WLAN**

This command controls the transmission of UDP data packets to the WLAN.

| Command | Action  |
|---------|---|
| T ON    | Enable transmission of UDP packets to the WLAN      |
| T OFF   | Disable transmission of UDP packets to the WLAN     |
| T       | Toggles the transmission of UDP packets to the WLAN |

**VERSIONS – Display Component Versions**

This command displays the versions of the four updatable components of the Wireless F/T. The following is an example of the command output:

```
>VERSIONS
Component  Version
-----  -
Firmware   2.1.3 - Jan  1 2010 10:10:37
WLAN Module 1.2.3.4.5.6
CPLD 0      02
CPLD 1      none
>
```

**XPWR s1 s2 – Transducer Power Control**

where:

s1 = 1, 2, 3, 4, 5, 6, or \*

s2 = ON or OFF

This command enables and disables transducers. Unneeded transducers may be powered down using the XPWR command to save battery power. The first argument to the XPWR command, s1, selects the transducer targeted. If the first argument is an asterisk, then the command applies to all transducers simultaneously. The second argument to the XPWR command, s2, determines the power state to be set.

| Command    | Action                  |
|------------|-------------------------|
| XPWR 1 ON  | Enables transducer 1    |
| XPWR * ON  | Enables all transducers |
| XPWR 2 OFF | Disables transducer 2   |

The XPWR command returns a line that summarizes the state change followed by the system prompt. Following this are outputs for each transducer that has a change in power state. The XPWR command will output Analog power = OFF in AUTO mode when power to all transducers has been turned off. When all transducers are off and a transducer is turned on, Analog power = ON in AUTO mode will be output.

```
>XPWR
Tr Auto   Now
-- ----   ---
 1 OFF    OFF
 2 OFF    OFF
 3 OFF    OFF
Analog power = OFF in AUTO mode
>XPWR 1 ON
Transducer 1 = ON
>Analog power = ON in AUTO mode
PWR:  2010 Jan  1 10:10:37 Transducer 1 ON
XPWR * ON
Transducer 123 = ON
>PWR:  2010 Jan  1 10:10:43 Transducer 2 ON
PWR:  2010 Jan  1 10:10:43 Transducer 3 ON
XPWR * OFF
Transducer 123 = OFF
>PWR:  2010 Jan  1 10:10:49 Transducer 1 OFF
Analog power = OFF in AUTO mode
PWR:  2010 Jan  1 10:10:49 Transducer 2 OFF
PWR:  2010 Jan  1 10:10:49 Transducer 3 OFF
```

The XPWR command will also generate a report of the current transducer power status when issued without arguments. The Auto column is XPWR command setting. The Now column shows the power port's actual state.

```
>XPWR
Tr Auto   Now
-- ----   ---
 1 ON     ON
 2 OFF    OFF
 3 ON     ON
Analog power = ON in AUTO mode
>
```

## 5.4 Commands For Modifying Wireless Settings

### **BAND** *s* – Selects WLAN Frequency Band

where:

$$s = 2.4 \text{ or } 5$$

This command selects whether the Wireless F/T uses the 2.4 GHz or the 5 GHz frequency band for WLAN communications. The new frequency band selection will take place after either a WLAN OFF/ON cycle or after a unit reset or unit power cycle, assuming the new BAND setting has been saved with the SAVEALL command.

| Command  | Action  |
|----------|---|
| BAND 2.4 | Selects the 2.4 GHz frequency band for the WLAN |
| BAND 5   | Selects the 5 GHz frequency band for the WLAN   |

The BAND command will also generate a report of the current WLAN frequency band when issued without arguments:

```
>BAND
Band = 5 GHz
>BAND 2.4
Change takes effect after reset: Band = 2.4 GHz
>WLAN OFF
WLAN: 2010 Jan 1 10:10:37 Power OFF
>WLAN ON
WLAN: 2010 Jan 1 10:10:41 Power ON
>WLAN: 2010 Jan 1 10:10:43 Got WLAN ready response
```

### **DESTIP** *n1.n2.n3.n4* – Set Default Destination IP Address

where:

*n1*, *n2*, *n3*, and *n4* are integers from 0 to 255 representing an IPV4 address

This command sets the WLAN destination IP address for outgoing UDP data packets. Note that this IP address will only stay in effect until modified, either by this command again, or by the receipt of a UDP command to send packets to some other IP address. The DESTIP command will also report the current destination IP address when issued without arguments.

```
>DESTIP
Destination IP = 192.168.1.22
>DESTIP 192.168.1.3
Destination IP was 192.168.1.22 = 192.168.1.3
>
```

### **DEVIP** *n1.n2.n3.n4* – Set Default Device IP Address

where:

*n1*, *n2*, *n3*, and *n4* are integers from 0 to 255 representing an IPV4 address

This command sets the default IP address of the unit. The default IP address is active when DHCP is not used. The DEVIP command will also report the default device IP address when issued without arguments.

```
>DEVIP
Device IP = 192.168.1.100
>DEVIP 192.168.1.101
Device IP was 192.168.1.100 = 192.168.1.101
>
```

**GATEIP *n1.n2.n3.n4* – Set Default Gateway IP Address**

where:

*n1, n2, n3, and n4* are integers from 0 to 255 representing an IPV4 address

This command sets the default gateway IP address for the WLAN. The default gateway IP address is active when DHCP is not used. The GATEIP command will also report the current default gateway IP address when issued without arguments.

```
>GATEIP
Gateway IP = 192.168.1.1
>GATEIP 192.168.1.2
Gateway IP was 192.168.1.1 = 192.168.1.2
>
```

**IP – Display IP Parameters**

This command prints the communication parameters. This can be useful for debugging WLAN connection issues. For example:

```
>IP
>ip
Parameter          Active          Default          MAC
-----
SSID                MY_WIFI1       MY_WIFI1
DESTIP              0.0.0.0        0.0.0.0
GATEIP              192.168.1.22   192.168.0.2     32-24-3F-6A-88-85
DEVIP               192.168.1.123  192.168.1.100   31-41-59-26-53-59
NET MASK            255.255.255.0  255.255.255.0
DNS Server 1        192.168.1.1
DNS Server 2        192.168.1.2
ANTENNA             External
BAND                 2.4 GHz
NET CHANNEL         1
NET DHCP             On
NET LOC              Balance Test #2
NET MODE             Normal CLIENT Mode
NET UDPACT           BUFFER
TXPWR                2
LOCALE               Europe
WLAN Connected      Yes
Channel number      3
Network type        Infra
Security level      WEP
DHCP Mode            DHCP
Open sockets        4
Sock State Type MyPort RemPort RemIP
-----
  1 Open  UDPout  49152  49152  0.0.0.0
  2 Open  UDPin   49152    0  0.0.0.0
  3 Open  TCPin    23    0  0.0.0.0
  4 Open  UDPin   51000    0  0.0.0.0
>
```

### NET AP – Display Detected WLAN Access Points

This command displays access points detected during the last scan of access points. If WLAN is OFF, NET AP will return the access points detected prior to setting WLAN to OFF. For example :

```
>NET AP
```

| ## | Ch | Secur | RSSI | SNR | NType | MAC               | SSID     |
|----|----|-------|------|-----|-------|-------------------|----------|
| 1  | 1  | WPA2  | -39  | -39 | Infra | 32-24-3F-6A-88-85 | MY_WIFI1 |
| 2  | 6  | WPA2  | -69  | -13 | Infra | 31-41-59-26-53-59 | MY_WIFI2 |

```
>
```

### NET CHANNEL *n* – Set WLAN Channel for AP or GO Modes

where:

*n* = integer from 1 to 13, 149, 153, 157, 161, or 165

This command selects the channel number that the unit will use if it becomes an Access Point (AP) or a WiFi Direct™ Group Owner (GO). The NET CHANNEL command will also report its current value when issued without arguments.

```
>NET CHANNEL 6
NET CHANNEL 6
>NET CHANNEL
NET CHANNEL 6
>
```

### NET DHCP *s* – Turns WLAN DHCP On or Off

where:

*s* = ON or OFF

This command turns DHCP support on and off. Enabling DHCP support allows the connected WLAN access point to automatically set the GATEIP, DEVIP, and NET MASK values if the access point supports DHCP. The NET DHCP command will also report its current value when issued without arguments.

```
>NET DHCP
NET DHCP Off
>NET DHCP ON
NET DHCP On
>
```

### NET DATE *yyyy/mm/dd* - Set System Date

where:

*yyyy* = integer; the current year

*mm* = integer; the current month from 1 to 12

*dd* = integer; the current day from 1 to 31

This command allows you to change the system date. If NTP synchronization is running, it will overwrite any changes made by using the NET DATE command. The NET DATE command will also report its current value when issued without arguments

Note: The system date and time will default to 2010 Jan 1 00:00:00 at power up or reset.

```
>NET DATE 2010/01/01
2010 Jan 1 10:10:37
>NET DATE
2010 Jan 1 10:10:38
>
```

**NET TIME** *hh:mm:ss* – Set System Time

where:

*hh* = integer; the current hour from 0 to 23

*mm* = integer; the current minute from 0 to 59

*ss* = integer; the current second from 0 to 59

This command allows you to change the system time. If NTP synchronization is running, it will overwrite any changes made by using the NET TIME command. The NET TIME command will also report its current value when issued without arguments.

Note: The system date and time will default to 2010 Jan 1 00:00:00 at power up or reset.

```
>NET TIME 10:10:37
2010 Jan 1 10:10:37
>NET TIME
2010 Jan 1 10:10:38
>
```

**NET DNS** *s* – Find IP Address(es) of Given URL

where:

*s* = a string of up to 89 ASCII characters making up a valid URL

This command allows you to find any IP addresses associated with a given URL. If the URL does not have an associated Internet IP address, the command will not generate a response. The NET DNS command can be used to determine if connected WLAN network has connectivity to the wider internet. For example:

```
>NET DNS fifa.com
>## IP-Address
-- -----
 1 184.26.143.136
 2 184.26.143.147
NET DNS BadAddress.com
>
```

**NET KEY** *s* – Set WLAN Network Key

where:

*s* = a string of up to 64 ASCII-encoded characters

This command sets the WLAN network key (sometimes called PSK) that is used with WEP, WPA, and WPA2 encryption. The WLAN network key, sometimes called network password, is required to connect to encrypted WLANs. The use of quotation marks is optional except when removing the network key (NET KEY ""). The WLAN system administrator should provide the required network key. The NET KEY command will also report its current value when issued without arguments.

```
>NET KEY
NET KEY = 'somepassword'
>NET KEY secretphrase
NET KEY = 'secretphrase'
>NET KEY ""
NET KEY = ''
>
```

**NET LOC "s" – Set Unit Location Description**

where:

s = a string of up to 39 ASCII-encoded characters

This command stores or recalls a location description. The location description is intended to help identify individual units when accessed remotely. The NET LOC command will also report its current value when issued without arguments.

```
>NET LOC "Balance Tester #2"  
LOCATION was 'Widget Maker' now 'Balance Tester #2'  
>NET LOC  
LOCATION = 'Balance Tester #2'  
>
```

**NET MASK n1.n2.n3.n4 – Set WLAN Subnet Mask**

where:

n1, n2, n3, and n4 are integers from 0 to 255 representing an IPV4 address

This command sets the default WLAN subnet mask. The subnet mask is used to determine what subnet an IP address belongs to. If DHCP is not used, the WLAN system administrator should provide the required subnet mask. The NET MASK command will also report its current value when issued without arguments.

```
>NET MASK 255.255.255.0  
Net Mask was 255.255.255.254 = 255.255.255.0  
>NET MASK  
Net Mask = 255.255.255.0  
>
```

**NET MODE s – Set WLAN Connection Mode**

where:

s = CLIENT or DIRECT

This command selects either client mode (connect to an existing wireless access point) or WiFi Direct™ mode.

| Command         | Action  |
|-----------------|---|
| NET MODE CLIENT | Selects WLAN access points as unit's wireless mode      |
| NET MODE DIRECT | Selects WiFi Direct devices as the unit's wireless mode |

```
>NET MODE  
NET MODE DIRECT or Autonomous GO  
>NET MODE CLIENT  
NET MODE Normal CLIENT Mode  
>
```

**NET UDPACT *s* – Packet Action During WLAN Flow Control**

where:

*s* = BUFFER or DROP

This command controls how the unit handles the transducer data when it needs to pause from sending data packets to the WLAN.

| Command           | Action  |
|-------------------|---|
| NET UDPACT BUFFER | Data will be buffered during the flow control period, and then sent when the period ends. Data will only be lost if the flow control period lasts longer than available buffer storage. This mode minimizes missing data, and is preferred for data logging applications. |
| NET UDPACT DROP   | Data will be dropped (deleted) during the flow control period. Data transmission will resume at the end of the flow control event. This mode minimizes latency, and is preferred for control applications   |

```
>NET UDPACT
NET UDPACT DROP
>NET UDPACT BUFFER
NET UDPACT BUFFER
>
```

**RESETIP – Restore All IP Settings to Factory Defaults**

This command restores all IP settings to the factory defaults. Any changes take effect with the next join to an access point.

```
>RESETIP
All IP settings restored to factory defaults
>
```

**RSSI - Display WLAN Received Signal Strength Indicator**

This command displays the wireless power for the unit's WLAN reception. RSSI (Received Signal Strength Indicator) is a measurement of the power present in a received radio signal. For example:

```
>RSSI
RSSI from MY_WIFI using External antenna: -45 dBm
>
```

**SSID *s* – Set Access Point SSID (WLAN Network Name)**

where:

*s* = a string of up to 32 ASCII characters

This command allows you to view and set the SSID. A new SSID setting will be effective after the next join to an access point. A SSID is the name of a WLAN. SSIDs are case-sensitive text strings. The WLAN system administrator should provide the required SSID. The SSID command will also report its current value when issued without arguments.

```
>SSID
SSID = 'OLD_WIFI'
>SSID MY_WIFI
SSID was 'OLD_WIFI' now 'MY_WIFI'
>
```

**WLAN s – Enable or Disable WLAN Communications**

where:

s = ON or OFF

The WLAN command turns on and off WLAN communications. Turning off WLAN communications will reduce battery consumption. The WLAN command will also report its current value when issued without arguments.

| Command  | Action                       |
|----------|------------------------------|
| WLAN ON  | Enables WLAN communications  |
| WLAN OFF | Disables WLAN communications |

```
>WLAN
WLAN: Power ON
>WLAN OFF
WLAN: 2010 Jan 1 10:10:37 Power OFF
>WLAN
WLAN: Power OFF
>WLAN ON
WLAN: 2010 Jan 1 10:10:39 Power ON
>WLAN: 2010 Jan 1 10:10:41 Got WLAN ready response
>
```

## 5.5 Commands Related to the Transducer Output

### **RATE** *n1* {*n2*} – Set Packet Rate with Optional Oversampling

where:

*n1* = integer from 5 to 4000, representing the packet send rate in Hertz

*n2* = {optional} integer from 1 to  $4000 \div n1$ , representing the oversample value.

This command allows you to set the rate at which data packets are sent to the destination IP address or the MicroSD card, and how many times to oversample.

The packet send rate's units are Hertz. Packet send rates can be from 5 to 4000 Hz. The upper limit is the highest rate possible under ideal conditions: only one transducer, oversampling set to 1, filtering disabled, no matrix multiply, no other WLAN traffic or interference, MicroSD logging disabled, and an application that can tolerate a large number of dropped packets.

The oversample value defaults to 1 if no value is entered for that argument. The packet send rate multiplied by the oversampling value cannot exceed 4000.

There are three major reasons to use oversampling :

- Resolution. Oversampling can be used to achieve higher effective resolution when noise is present. For example, to add the equivalent of one extra bit of resolution read the transducer twice and average the results.
- Noise filtering. If multiple samples are taken of the same quantity with uncorrelated noise added to each sample, then averaging *n* samples reduces the noise power by a factor of 1/*n*.
- Anti-aliasing. Oversampling can make it easier to implement analog anti-aliasing filters.

The fastest packet rate usable in an application depends on (in approximate order of expected significance):

- a. Processor speed on the receiving end. Examples:
  - A desktop system running Windows 7 with an Intel Core i5 CPU (3.10 GHz, 8 GB of RAM) had no problem keeping up with a 1200 Hz packet rate.
  - A laptop running Windows XP with an Intel Centrino Duo (1.66 GHz, 1 GB of RAM) had trouble keeping up with much more than a 100 Hz packet rate.
- b. Your application's tolerance for dropped packets.
- c. The number of active transducers in the system. Rates decrease as transducer data increases.

$$\text{Packet length} = 6 \times 4 \times \text{Number\_Of\_Transducers} + 18 \text{ bytes}$$

- d. If using UDP:
  - Any other wireless radio traffic.
  - Any radio frequency interference in your environment
  - Any other network traffic (for example in the router)
  - The mode: BUFFER mode (to minimize dropouts) or DROP mode (to minimize latency).
- e. If writing to a MicroSD card, its maximum write latency and other hardware characteristics.
- f. The amount of oversampling in use.
- g. Filter type
- h. Number of filter taps for filters other than IIR.
- i. Matrix Multiply enabling. If enabled, the maximum rate will be less than if disabled.

Best wireless performance will be achieved using a dedicated wireless access point free of other network traffic.

The factory default is to send packets at 10 Hz (every 100 mS), with an oversample rate of 32. This means that one out of every 32 packets is sent.

```
>rate
Packet rate = 10 Hz
ADC rate = 320 Hz
Oversample = 32
>rate 125 32
Packet rate = 125 Hz
ADC rate = 4000 Hz
Oversample = 32
>
```

**BIAS *s1 s2* – Set Transducer Bias**

*where:*

*s1* = 1, 2, 3, 4, 5, 6, or \*  
*s2* = ON or OFF

This command allows you to set or remove the bias point of any one or all transducers. The bias point is an offset to be applied to a transducer's output by the unit. Setting a transducer's bias point will make it read zero for the load applied at the time the bias was set.

```
>BIAS 1 OFF
Sensor bias cleared 1
>BIAS * ON
Sensor bias set 123
>
```

**TRANS *n* – Set Active Transducer**

*where:*

*n* = integer from 1 to 6

This command allows you to change the active transducer. The active transducer is the transducer for which the CALIB command applies. The TRANS command will also report which transducer is active and show each transducer's active calibration, when issued without arguments.

```
>TRANS 2
Active: Transducer = 2 Calibration = 1
>TRANS
Tr Active-Calibrations
-- -----
1 1
2 1 <-- Active Transducer
3 1
>
```

**CALIB *n* – Set Active Calibration**

where:

$$n = 1, 2, \text{ or } 3$$

This command allows you to change the active calibration. The active calibration is the one currently for data collection. The CALIB command will also report which transducer is active and show each transducer's active calibration, when issued without arguments.

```
>CALIB 3
Active: Transducer = 2 Calibration = 3
>CALIB
Tr Active-Calibrations
-- -----
1 1
2 3 <-- Active Transducer
3 1
>
```

**FILTER *s1 s2 n* – Set Filtering**

where:

$$s1 = 1, 2, 3, 4, 5, 6, \text{ or } *$$

$$s2 = \text{MEAN, MEDIAN, or IIR}$$

$$n = \text{integer from 1 to 31 for MEAN and MEDIAN, from 1 to 32767 for IIR}$$

This command allows you to set the low-pass filter type to be applied to transducer data. Low pass filtering can be applied to reduce unwanted noise in transducer data.

| Filter Type | Description   | <i>n</i> Range |
|-------------|---|----------------|
| Mean        | Running average filter of the last <i>n</i> samples | 1 to 31        |
| Median      | Running median filter with <i>n</i> samples         | 1 to 31        |
| IIR         | IIR filter with a time constant of <i>n</i>         | 1 to 32767     |

Note that a 31-sample MEAN filter running in all six transducers executes in about 65  $\mu$ S, while a 31-sample MEDIAN filter in all six transducers executes in about 480  $\mu$ S, on average. Consequently, the maximum possible packet rate, set by the RATE command, is lower for a *n*-sample MEDIAN filter than for an *n*-sample MEAN filter.

The FILTER command will also report the current filter settings for all transducers, when issued without arguments.

```
>FILTER 1 MEAN 8
Transducer 1 MEAN 8
>FILTER 2 MEDIAN 16
Transducer 2 MEDIAN 16
>FILTER 3 IIR 512
Transducer 3 IIR 512
>FILTER
Tr Filter Taps
-- -----
1 MEAN 8
2 MEDIAN 16
3 IIR TC 512
>
```

## 5.6 Commands Related to the Functionality of the MicroSD Card Reader

### SD - Print Memory Card Diagnostic Information

With no operands, this command prints a lengthy list of technical information about the user's memory card.

### SD [FORMAT] - Format Memory Card

This command allows you to format the MicroSD card. All existing data on the MicroSD card will be lost. The command will ask you to verify that you want to format the disk before it actually deletes any data. To cancel, type N then press <ENTER>. To proceed, type Y then press <ENTER>. Any data streaming over the WLAN will be interrupted while the format is taking place.

```
>SD FORMAT
SD: 2010 Jan 1 10:10:28 Are you sure? ALL data on the SD card will be
lost!
nSD: 2010 Jan 1 10:10:34 Format canceled
>SD FORMAT
SD: 2010 Jan 1 10:10:41 Are you sure? ALL data on the SD card will be
lost!
ySD: 2010 Jan 1 10:10:46 Formatting Drive 0:
Erasing sectors 200 to 1dcfff AU: 239 timeout: 30,875 mS
SD: 2010 Jan 1 10:10:48 Format complete
>
```

### SCD *s* - Change Memory Card Directory

where:

*s* = a string of ASCII characters that form a valid directory name

This command allows you to display and change the path on the memory card. The SCD command will report the current path when issued without arguments.

```
>SCD /ATI
0:/ATI
>SCD /
0:/
>
```

### SDEL *s* - Delete Memory Card File(s)

where:

*s* = a string of ASCII characters that form a valid file name

This command deletes the selected file(s) in the current directory on the user memory card.

```
>SDEL F3.dat
Erasing sectors 380 to 3df AU: 1 timeout: 1,125 mS
F3.DAT deleted
Files deleted: 1
>SDEL BadFileName
Files deleted: 0
>
```

### SDIR - Print Memory Card Directory

This command prints a directory of all files in the current path on the user memory card.

```
>SDIR
Directory of 0:/ATI
2010/01/01 10:10 <DIR>      .
2010/01/01 10:10 <DIR>      ..
2010/01/01 10:10          4  ATI.ini
2010/01/01 10:11       112,398  F1.dat
2010/01/01 10:14       33,792  F2.dat
```



## 5.7 Commands Related to NTP Time Synchronization:

Network Time Protocol is a protocol for synchronizing clocks between computer systems over packet-switched networks. The Wireless F/T uses NTP to synchronize its clock to that of a single user-selectable NTP server. Any other devices should be synchronized to the same NTP server. This NTP implementation has as its goal accuracy on the order of a millisecond, but it cannot be any more accurate than its time source. More information about NTP can be found at <http://www.ntp.org/>.

Every NTP command produces a short table containing its enable status, the current NTP server, the current time zone relative to UTC, and the daylight savings time status:

```

Parameter Value
-----
Enable      1
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
    
```

All packets generated by the Wireless F/T have a time stamp in units of milliseconds. NTP settings are controlled using the NTP commands.

### **NTP ENABLE n** – Controls NTP Synchronization

where:

$n = 0$  or  $1$

This command controls whether NTP synchronization is enabled or disabled. The NTP ENABLE command should not be used without an offset. Doing so will disable NTP synchronization.

| Command      | Action                       |
|--------------|------------------------------|
| NTP ENABLE 0 | Disables NTP synchronization |
| NTP ENABLE 1 | Enables NTP synchronization  |

After NTP synchronization is enabled, the unit will attempt to contact the time server previously set with the NTP SERVER command. If successful, the unit will output a table with NTP Field information. If unsuccessful, no NTP Field table will be output.

```

>NTP SERVER pool.ntp.org
Parameter Value
-----
Enable      0
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
>NTP ENABLE 1
Parameter Value
-----
Enable      1
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
>
NTP-Field      Value
-----
Server          pool.ntp.org
LeapSecInd      None
Version         3
Mode            Server
Stratum         2 => Secondary reference
PollInterval    2 ^ 4 seconds
Precision       2 ^ -22 seconds
RootDelay       0.000198 seconds
    
```

```
RootDispersion 0.022568 seconds
ReferenceId      216.229.0.179
Reference        2010 Jan  1 10:10:16.798053
Originate        2010 Jan  1 10:10:20.212445
Receive          2010 Jan  1 10:10:20.262260
Transmit         2010 Jan  1 10:10:20.262286
```

```
>NTP ENABLE 0
Parameter Value
-----
Enable      0
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
>
```

#### **NTP SERVER *s* – Set NTP Server URL or IP Address**

*where:*

*s* = a string of up to 89 characters representing a valid URL or IPV4 address

This command selects a NTP server to use. The NTP SERVER command should not be used without an argument. Doing so will set the NTP server to an indeterminate value. Generally, closer NTP servers will provide better the time synchronization, assuming the servers have similar accuracies. If you are trying to synchronize multiple pieces of equipment you should use the same time server for all of them. The server can be entered as a URL or as an IP address, but a URL is preferred.

```
>NTP SERVER pool.ntp.org
Parameter Value
-----
Enable      0
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
>
```

Your organization may already have its own NTP time server. You may want to install an NTP server in a PC or for additional accuracy buy a precision NTP server in dedicated hardware . Public NTP time servers are also available. NTP best practices discourage the use of Stratum 1 time servers by end-use devices, such as the Wireless F/T.

#### **NTP ZONE *s* – UTC Time-Zone Offset**

*where:*

*s* = string representing the time zone offset in hours and minutes.

This command sets the difference between local time and Coordinated Universal Time (UTC) time. The string, *s*, cannot have leading zeros. Negative offsets must be preceded by a dash. Valid examples are: 1000, 100, 0, 500, 800. The NTP ZONE command should not be used without an offset. Doing so will set the UTC time zone offset to zero. Information on UTC time-zone offsets can be found at [http://en.wikipedia.org/wiki/List\\_of\\_UTC\\_time\\_offsets](http://en.wikipedia.org/wiki/List_of_UTC_time_offsets).

```
>NTP ZONE -500
Parameter Value
-----
Enable      0
Server      pool.ntp.org
TimeZone    -5:00
DST         OFF
>
```

**NTP DST *s* – Daylight savings time**

where:

*s* = ON or OFF

This command sets whether daylight savings time is on or off.

```
>NTP DST ON
Parameter Value
-----
Enable      0
Server      pool.ntp.org
TimeZone    -5:00
DST         ON
>
```

**5.8 UDP Interface**

The Wireless F/T unit listens on UDP port 49152 for commands. Any streaming UDP packets are sent to the current Destination IP address until a UDP command is received. When the Wireless F/T unit receives a UDP command from any IP address, the UDP packets are sent to whichever port the request came from.

The UDP server uses binary format for commands and responses. All multi-byte values use big-endian, which is the same as network order.

**5.9 UDP Command Format**

All UDP commands to the WNET unit have the following format:

| Table 5.1—UDP Command Format |                  |                |   |
|------------------------------|------------------|----------------|---|
| Field Name                   | Format           | Length (bytes) | Comments  |
| length                       | unsigned short   | 2              | Total length of this message, including CRC               |
| sequence                     | unsigned char    | 1              | Sequence number. Used to identify missing messages.       |
| command                      | unsigned char    | 1              | Command number  |
| payload                      | unsigned char(s) | length - 6     | Command operands (if any)                                 |
| crc                          | unsigned short   | 2              | See Appendix A – UDP Command CRC Calculation, for details |

This format can be rendered into C as:

```
struct udp_RecvFrame_S
{
  unsigned short length;           // Total length of this message
  unsigned char  sequence;        // sequence number of this message
  unsigned char  command;         // command number
  unsigned char  parameters[0];   // command operands
} __attribute__((packed));
```

These commands are currently implemented:

| Table 5.2—Current Command Implementation |                              |   |
|--|------------------------------|---|
| Number                                   | Name                         | Comments  |
| 1  | Start streaming              | Start streaming for either a fixed or unlimited number of packets |
| 2  | Stop streaming               | Stops streaming   |
| 3  | Set packet transmission rate | Sets packet transmission rate. All transducers use the same rate. |
| 4  | Ping                         | Sends a no-payload Pong response back to the sender.              |
| 5  | Reset telnet socket          | Closes any open telnet socket.                                    |

1. Start Streaming.

This command starts the transmission of UDP data packets for either a fixed or unlimited number of packets.

| Table 5.3—UDP Command Format |               |                |  |
|------------------------------|---------------|----------------|--|
| Field Name                   | Format        | Length (bytes) | Comments                                 |
| count                        | unsigned long | 4              | Number of samples to send, 0 = unlimited |

2. Stop Streaming

This command stops the transmission of UDP data packets. There are no parameters.

3. Set Packet Transmission Rate

This command sets the UDP data packet transmission rate. The packet transmission rate will be truncated to the next lowest multiple of the Analog to Digital Converter (ADC) sampling rate. For example, if a packet transmission rate of 900  $\mu$ S is requested when the ADC sampling rate is 400  $\mu$ S, the packet transmission rate will be set to 800  $\mu$ S. The packet transmission rate will be set no lower than the ADC sampling rate. All Transducers use the same packet transmission rate. The change in packet transmission rate takes effect immediately.

| Table 5.4—UDP Command Format |               |                |                                     |
|------------------------------|---------------|----------------|-------------------------------------|
| Field Name                   | Format        | Length (bytes) | Comments                            |
| rate                         | unsigned long | 4              | Packet transmission rate in $\mu$ S |

4. Ping

This command sends a no-payload Pong response back to the sender.

5. Reset Telnet Socket

This command closes any open telnet socket. This command is useful to issue just before connecting to the unit, in case a previous session was not properly closed out.

## 5.10 Data Packet

Streaming UDP and SD card data packets have the following format:

| Table 5.5—UDP Command Format |                |                |   |
|------------------------------|----------------|----------------|---|
| Field Name                   | Format         | Length (bytes) | Comments  |
| timeStamp                    | unsigned long  | 4              | Internal time stamp in seconds (20-bits integer, 12-bits fraction). Seconds starts at 1/1/2010 if time synchronized, or since power up if not synchronized, modulo 20 bits. |
| sequence                     | unsigned long  | 4              | Sequence number. Used to identify missing messages.   |
| statusCode1                  | unsigned long  | 4              | Wireless F/T Status Word 1 for Transducers 1 to 3 (see below).  |
| statusCode2                  | unsigned long  | 4              | Wireless F/T Status Word 2 for Transducers 4 to 6 (see below).  |
| batteryLevel                 | unsigned char  | 1              | Indication of battery life remaining.   |
| transMask                    | unsigned char  | 1              | Transducer data in block mask: 0x01 = Transducer 1, 0x02 = T2, ...  |
| Tr Ch0 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 0 is ForceX.  |
| Tr Ch1 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 1 is ForceY.  |
| Tr Ch2 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 2 is ForceZ.  |
| Tr Ch3 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 3 is TorqueX.   |
| Tr Ch4 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 4 is TorqueY.   |
| Tr Ch5 (if present)          | signed long    | 4              | Data <sup>1</sup> for first Transducer: Channel 5 is Torque Z.  |
| Tr data (if present)         | 6 signed longs | 24             | Data <sup>1</sup> for next Transducer, Channels 0 to 5.   |
| Tr data(if present)          | 6 signed longs | 24             | Data <sup>1</sup> for next Transducer, Channels 0 to 5.   |
| Tr data (if present)         | 6 signed longs | 24             | Data <sup>1</sup> for next Transducer, Channels 0 to 5.   |
| Tr data (if present)         | 6 signed longs | 24             | Data <sup>1</sup> for next Transducer, Channels 0 to 5.   |
| Tr data (if present)         | 6 signed longs | 24             | Data <sup>1</sup> for next Transducer, Channels 0 to 5.   |

Notes:

1. To convert the data into real force and torque values, refer to [Section 5.10.1—Calculating F/T values for Data Packages](#).

For UDP, note that each individual UDP datagram may contain one or more of these packets.

For memory card files, note that F\*.dat files usually contain more than one of these packets.

| Table 5.6—Wireless F/T Status Word 1 |                |     |                        |     |                   |                |                          |     |
|--------------------------------------|----------------|-----|------------------------|-----|-------------------|----------------|--------------------------|-----|
| Bit                                  | 31             | 30  | 29                     | 28  | 27                | 26             | 25                       | 24  |
| Field                                | spare          |     | Bridge Voltage Too Low |     |                   | Saturated Data |                          |     |
|                                      |                |     | T3                     | T2  | T1                | T3             | T2                       | T1  |
|                                      |                |     |                        |     |                   |                |                          |     |
| Bit                                  | 23             | 22  | 21                     | 20  | 19                | 18             | 17                       | 16  |
| Field                                | Reserved       |     | T3                     |     | T2                |                | T1                       |     |
|                                      | 0              | 0   | Bridge                 | AFE | Bridge            | AFE            | Bridge                   | AFE |
|                                      |                |     |                        |     |                   |                |                          |     |
| Bit                                  | 15             | 14  | 13                     | 12  | 11                | 10             | 9                        | 8   |
| Field                                | Reserved       |     | Reserved               |     | Battery Indicator |                | External-Power Indicator |     |
|                                      | 0              | 0   | 0                      | 0   | Green             | Red            | Green                    | Red |
|                                      |                |     |                        |     |                   |                |                          |     |
| Bit                                  | 7              | 6   | 5                      | 4   | 3                 | 2              | 1                        | 0   |
| Field                                | WLAN Indicator |     | T3 Indicator           |     | T2 Indicator      |                | T1 Indicator             |     |
|                                      | Green          | Red | Green                  | Red | Green             | Red            | Green                    | Red |

| Table 5.7—Wireless F/T Status Word 2 |          |    |                        |     |              |                |              |     |
|--------------------------------------|----------|----|------------------------|-----|--------------|----------------|--------------|-----|
| Bit                                  | 31       | 30 | 29                     | 28  | 27           | 26             | 25           | 24  |
| Field                                | spare    |    | Bridge Voltage Too Low |     |              | Saturated Data |              |     |
|                                      |          |    | T6                     | T5  | T4           | T6             | T5           | T4  |
|                                      |          |    |                        |     |              |                |              |     |
| Bit                                  | 23       | 22 | 21                     | 20  | 19           | 18             | 17           | 16  |
| Field                                | Reserved |    | T6                     |     | T5           |                | T4           |     |
|                                      | 0        | 0  | Bridge                 | AFE | Bridge       | AFE            | Bridge       | AFE |
|                                      |          |    |                        |     |              |                |              |     |
| Bit                                  | 15       | 14 | 13                     | 12  | 11           | 10             | 9            | 8   |
| Field                                | Reserved |    | Reserved               |     | Reserved     |                | Reserved     |     |
|                                      | 0        | 0  | -                      | -   | -            | -              | -            | -   |
|                                      |          |    |                        |     |              |                |              |     |
| Bit                                  | 7        | 6  | 5                      | 4   | 3            | 2              | 1            | 0   |
| Field                                | Reserved |    | T6 Indicator           |     | T5 Indicator |                | T4 Indicator |     |
|                                      | -        | -  | Green                  | Red | Green        | Red            | Green        | Red |

The Bridge bits indicate if a transducer is powered. The AFE bits indicate if the Wireless F/T is ready to read that transducer's values.

The System indicator combines the results for all Digital Board faults.

The length of the packet depends on the number of transducers that are powered, and can be calculated using the following equation:

$$\text{PacketLength(in bytes)} = 18 + \text{NumberOfOneBits(transMask)} \times 24$$

This packet format can be rendered into C as:

```
#define NUMBER_OF_ANALOG_BOARDS 2
#define NUMBER_OF_TRANSducers 6
#define NUMBER_OF_STRAIN_GAGES 6

struct TxPacket_S
{
    unsigned long    timeStamp;
    unsigned long    sequence;
    unsigned long    statusCode[NUMBER_OF_ANALOG_BOARDS];
    unsigned char    batteryLevel;
    unsigned char    transMask;
    signed long      sg[NUMBER_OF_TRANSducers][NUMBER_OF_STRAIN_GAGES];
} __attribute__((packed));
```

More than one of these packets may be sent as in a single UDP datagram.


### 5.10.1 Calculating F/T values for Data Packages

To obtain the real force and torque values, each force value must be divided by Counts per Force factor, and each torque value must be divided by the Counts per Torque factor.

For example: If a calibration reports 1, 000, 000 counts per N and the  $F_z$  reports 4, 500, 000 counts, then the force applied in the Z axis, is 4.5 N.

The Counts per Force factor and Counts per Torque factor are also called scaling factors. The “CountsPerForce” and “CountsPerTorque” are obtained from the calibration file, which is available from an attachment sent via email when the product was shipped. The following figure shows the calibration file with XML Notepad. On the right side of the screen, the scaling factor is listed. XML Notepad can be downloaded for free from <https://www.microsoft.com/en-us/download/details.aspx?id=7973>. The calibration file can be opened with any text editor. Once the file is opened, look for the “CountsPerForce” XML tag.

Figure 5.2—“CountsPerForce” and “CountsPerTorque” in the Calibration File



## 5.11 Processor Firmware Update Procedure

The Wireless F/T device may be updated in the field. From a user's perspective, the procedure is the following:

1. Use the Java demo application on the PC to download the binary image appl.bin to the Wireless F/T unit.
2. Reset the Wireless F/T unit.

Note: if you are operating over WLAN, contact with the unit will be lost when the update procedure starts, and will not resume until it is complete. If you are operating through a serial port, you will be able to watch the process as it occurs.

## 6. Maintenance

Under normal conditions, no special maintenance is necessary, however it is recommended that periodic inspections be performed to assure long-lasting performance and to assure that unexpected damage has not occurred. Refer to [Section 6.1—Preventive Maintenance](#) for a schedule and items that should be visually inspected at regular intervals. Wireless F/T devices operating on battery power should be monitored periodically for battery status.

Spare parts are available from ATI Industrial Automation. Please call for recommendations.

### 6.1 Preventive Maintenance

The Wireless F/T is designed to provide a long life with regular maintenance. A visual inspection and preventive maintenance schedule is provided in the [Table 6.1](#). Assembly details are provided in [Section 11—Drawings](#).

| Table 6.1—Preventative Maintenance Checklist  |                     |
|---|---------------------|
| Repetitive motion Frequency   | Inspection Schedule |
| More than 1 per minute  | Weekly              |
| Less than 1 per minute  | Monthly             |
| <b>Cabling</b>  |                     |
| <input type="checkbox"/> Visually inspect the power supply and transducer cabling for wear or damage. If wear or damage is visible, replace cabling and adjust routing or protect cabling with a loose plastic spiral wrap. |                     |
| <input type="checkbox"/> Visually inspect cable connection for looseness, tighten connection or replace cable as needed   |                     |
| <b>Mounting Fasteners</b>   |                     |
| <input type="checkbox"/> Inspect mounting fasteners, verify they are tight and have the proper torque.  |                     |

### 6.2 Battery Recharging and Replacement

The batteries can be charged internally using the USB port above the battery compartment or externally in a battery charger.

#### 6.2.1 Charging Battery Internally

The battery can be charged internally using the external power adapter and a USB cable that connects the external power adapter to the Wireless F/T. **Note:** The computer connected to the USB port does not provide sufficient source to keep the battery charged.

#### 6.2.2 Charging Battery Externally

The battery can be charged externally and swapped out while a second battery is charging. It will result in a brief power-down condition.

1. Loosen the quarter-turn fastener on the battery compartment and open the door.
2. Slide the battery out and replace it with a fully charged battery.
3. Close the door and tighten the quarter-turn fastener.
4. Insert the battery in a battery charger.

## 7. Troubleshooting

The system contains few components and provides trouble-free operation once properly installed. The following table is provided to assist with troubleshooting the system.

| <b>Symptom</b>   | <b>Possible Cause</b>   | <b>Correction</b>   |
|--|---|---|
| Nonexistent or intermittent communication.                         | Low battery power   | Charge battery, (if battery does not retain a charge replace battery).  |
|  | Worn or damaged cabling   | Inspect and test power supply and transducer cabling and replace as needed.                                       |
|  | External power adapter failing or not functioning                                   | Replace external power adapter  |
|  | Obstruction between Wireless F/T and wireless access point                          | Remove obstruction or reposition Wireless F/T, or the wireless access point to obtain an unobstructed environment |
|  | Wireless network component failing or not functioning                               | Test components and replace as needed   |
|  | Wireless F/T failing or not functioning   | Test Wireless F/T and replace as needed   |
|  | Transducer not functioning  | Refer to the F/T Installation and Operation manual for troubleshooting information.                               |
|  | External antenna not present or not correct part                                    | Install correct external antenna  |
| WLAN and transducers do not work but USB communications work fine. | Unit is in CHARGE power mode, not ON power mode                                     | Momentarily press power button or issue POWER ON command  |
| Wireless status indicator is flashing red.                         | This typically happens when trying to transmit to a UDP address that does not exist | Verify the correct UDP address; if incorrect, update.   |

## 8. Serviceable Parts

| <b>Description</b>                           | <b>Part Number</b>    |
|--|-----------------------|
| Wireless F/T WNet-3                          | 9105-WNET3            |
| Wireless F/T WNet-6                          | 9105-WNET6            |
| Battery                                      | 5515-3.70000-01       |
| External Battery Charger                     | 9105-WNETEBC          |
| Antenna                                      | 9105-WNETANT          |
| Wireless F/T Power Supply, Wall Adapter Type | 9105-WNETPS           |
| USB A Male to USB B Male cable, 0.9m         | 9105-C-USAA-MINIB-0.9 |

## 9. Specifications

The specifications section covers characteristics of the Wireless F/T device. Other components such as transducer, cabling may be found in the specific product manual on our website. Drawings may also be found in the product catalog and on our website. 2-D and 3-D models are also available on our website.

Contact ATI for specific information and drawings regarding your installation. We encourage you to use our applications department to review your designs and answer your questions.

### 9.1 Wireless Characteristics

Wireless Local Area Network (WLAN) IEEE 802.11 b/g/n 2.4 GHz / 5.0 GHz

#### Typical Range (Antenna attached)

Office Type Environment 30 m (98 ft)  
 unobstructed environment 100 m (328 ft)

Note: Only certified with the antenna attached.

### 9.2 Power Requirements

#### Battery Power

Internal battery 3.7V Lithium-polymer rechargeable

Typical battery life (Max, streaming rate and transducers used)

WNet-3 2 hrs

WNet-6 1 hr

Power consumption 2A at 5 VDC

External power adapter 5VDC

#### 9.2.1 Wireless Power Levels

| Table 9.1—Wireless Power Levels |           |             |    |             |    |
|---------------------------------|-----------|-------------|----|-------------|----|
| Supported Channels              | Frequency | US Locale   |    | Euro Locale |    |
|                                 | GHz       | dBm $\pm$ 1 | mW | dBm $\pm$ 1 | mW |
| 1                               | 2.412     | 15          | 32 | 15          | 32 |
| 2                               | 2.417     | 15          | 32 | 15          | 32 |
| 3                               | 2.422     | 15          | 32 | 15          | 32 |
| 4                               | 2.427     | 15          | 32 | 15          | 32 |
| 5                               | 2.432     | 15          | 32 | 15          | 32 |
| 6                               | 2.437     | 15          | 32 | 15          | 32 |
| 7                               | 2.442     | 15          | 32 | 15          | 32 |
| 8                               | 2.447     | 15          | 32 | 15          | 32 |
| 9                               | 2.452     | 15          | 32 | 15          | 32 |
| 10                              | 2.457     | 15          | 32 | 15          | 32 |
| 11                              | 2.462     | 15          | 32 | 15          | 32 |
| 12                              | 2.467     | 15          | 32 | 15          | 32 |
| 13                              | 2.472     | 15          | 32 | 15          | 32 |
| 149                             | 5.745     | 12          | 16 | 7           | 5  |
| 153                             | 5.765     | 12          | 16 | 7           | 5  |
| 157                             | 5.785     | 12          | 16 | 7           | 5  |
| 161                             | 5.805     | 12          | 16 | 7           | 5  |
| 165                             | 5.825     | 12          | 16 | 7           | 5  |

### 9.3 Physical Characteristics

**Size**

Wireless WNet-3 (Excluding Antenna & mating connectors) 156 mm x 82 mm x 19.7 mm  
 (6.15 in x 3.23 in x 0.775 in)

Wireless WNet-6 (Excluding Antenna & mating connectors) 156 mm x 82 mm x 33 mm  
 (6.15 in x 3.22 in x 1.3 in)

Antenna 100 mm (3.9 in)

**Weight**

Wireless WNet-3 0.6 lbs (0.27 kg)

Wireless WNet-6 0.6 lbs (0.27 kg)

Mounting See Section 13—Drawings

Operating ambient Temperature (Non-Charging) 0°C to +50°C (Note: battery runtime may decrease above 35°C ambient).

Battery charging ambient temperature 0°C to +35°C

Storage ambient temperature -20°C to 45°C

Humidity 85% maximum, non-condensing

### 9.4 Transducer Inputs

Figure 9.1—8-Pin Connector Female, Transducer Connector




Table 9.2—Transducer Connector Specifications

| Table 9.2—Transducer Connector Specifications |                             |
|---|-----------------------------|
| Pin Assignments                               | Signal                      |
| Pins 1,2,4,5,7,8                              | Strain gage input           |
| Pin 3   | Ground                      |
| Pin 6   | 5V bridge supply (20mA max) |
| Maximum Ratings                               |                             |
| Absolute maximum strain gage input range      | -7 VDC to 7 VDC             |

### 9.4.1 Analog Transducer Data Filtering

Figure 9.2 shows the frequency response of the WNet hardware filter. The graph does not include the effects of any mechanical filtering (which occurs in any spring and mass system).

Figure 9.2—WNet Analog Filtering Frequency Response (typical)





Figure 9.3 shows the group delay of the WNet hardware filter. These delays do not show the wireless delays in your network or computer. The WNet transmits F/T data to a wireless device with a delay of 1333 $\mu$ S with no software filtering enabled.

Figure 9.3—WNet Analog Filtering Group Delays (calculated)



## 10. Regulatory Information

### 10.1 FCC Statement

#### Declaration of Conformity with FCC Rules for Electromagnetic Compatibility

We, ATI Industrial Automation of 1031 Goodworth Drive, Apex, NC 27539, declare under our sole responsibility that the Wireless Multi-Axis Force/Torque Transmitter models, WNET-NA-x, FTWN-NA-x, comply with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

#### IMPORTANT NOTICE:

#### Federal Communications Commission Notice

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at their own expense.

#### FCC Radiation Exposure Statement

The SAR limit for North America is 1.6 W/kg averaged over one gram of tissue. This product (FCC ID: 2ACKB-9105WNET) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.04 W/kg.

This device was tested for typical body-worn operations with the back of the device kept 0mm from the body. To maintain compliance with IC RF exposure requirements, use accessories that do not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with IC RF exposure requirements, and should be avoided.

#### Modifications

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### 10.2 Canadian Compliance Statement

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This device has been designed to operate with the antenna listed below, and having a maximum gain of 2 dBi. Antennas not included in this list or having a gain greater than 2 dBi are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

- Pulse Electronics wireless external dual band antenna part number W1043

Cet appareil a été désigné pour opérer avec l'antenne listée ci-dessous, et ayant un gain maximal de 2 dBi. Les antennes qui ne sont pas incluses dans cette liste ou qui ont un gain plus de 2 dBi sont strictement interdites d'être utilisées avec cet appareil. L'impédance de l'antenne requise est de 50 ohms.

- Antenne externe bi-bande sans fil, de la compagnie 'Pulse Electronics', numéro de pièce W1043.

## **IMPORTANT NOTICE:**

### **IC Radiation Exposure Statement**

The SAR limit for North America is 1.6 W/kg averaged over one gram of tissue. This product (IC ID: 12098A-9105WNET) has also been tested against this SAR limit. The highest SAR value reported under this standard during product certification for use when properly worn on the body is 1.04 W/kg.

This device was tested for typical body-worn operations with the back of the device kept 0mm from the body. To maintain compliance with IC RF exposure requirements, use accessories that do not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with IC RF exposure requirements, and should be avoided.

La limite SAR pour l'Amérique du Nord est de 1,6 W/kg en moyenne par gramme de tissu. Ce produit (ID IC: 12098A-9105WNET) a également été testé contre cette limite SAR.

La valeur SAR la plus élevée signalée sous cette norme lors de la certification du produit pour utilisation quand porté correctement sur le corps est de 1,04 W/kg.

Cet appareil a été testé pour des opérations portables typiques avec l'arrière de l'appareil maintenu à 0 mm du corps. Pour respecter les normes d'exposition RF IC, veuillez utiliser des accessoires qui ne contiennent pas de composants métalliques. L'utilisation d'accessoires ne satisfaisant pas à ces exigences peut ne pas se conformer aux exigences d'exposition RF IC et devrait être évitée.


### **IC Statement**

This Class A digital apparatus complies with Canadian ICES-003.


Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

# 11. Drawings

## 11.1 Wireless Net F/T for 3 Transducers



### 11.2 Wireless Net F/T for 6 Transducers



## 12. Terms and Conditions of Sale

The following Terms and Conditions are a supplement to and include a portion of ATI's Standard Terms and Conditions, which are on file at ATI and available upon request.

ATI warrants to Purchaser that force torque sensor products purchased hereunder will be free from defects in material and workmanship under normal use for a period of one year from the date of shipment. This warranty does not cover components subject to wear and tear under normal usage or those requiring periodic replacement. ATI will have no liability under this warranty unless: (a) ATI is given written notice of the claimed defect and a description thereof with thirty (30) days after Purchaser discovers the defect and in any event, not later than the last day of the warranty period and (b) the defective item is received by ATI not later than (10) days after the last day of the warranty period. ATI's entire liability and Purchaser's sole remedy under this warranty is limited to repair or replacement, at ATI's election, of the defective part or item or, at ATI's election, refund of the price paid for the item. The foregoing warranty does not apply to any defect or failure resulting from improper installation, operation, maintenance, or repair by anyone other than ATI.

ATI will in no event be liable for incidental, consequential, or special damages of any kind, even if ATI has been advised of the possibility of such damages. ATI's aggregate liability will in no event exceed the amount paid by the purchaser for the item which is the subject of claim or dispute. ATI will have no liability of any kind for failure of any equipment or other items not supplied by ATI.

No action against ATI, regardless of form, arising out of or in any way connected with products or services supplied hereunder, may be brought more than one year after the cause of action accrued.

No representation or agreement varying or extending the warranty and limitation of remedy provisions contained herein is authorized by ATI, and may not be relied upon as having been authorized by ATI, unless in writing and signed by an executive officer of ATI.

Unless otherwise agreed in writing by ATI, all designs, drawings, data, inventions, software, and other technology made or developed by ATI in the course of providing products and services hereunder, and all rights therein under any patent, copyright, or other law protecting intellectual property, shall be and remain ATI's property. The sale of products or services hereunder does not convey any expressed or implied license under any patent, copyright, or other intellectual property right owned or controlled by ATI, whether relating to the products sold or any other matter, except for the license expressly granted below.

In the course of supplying products and services hereunder, ATI may provide or disclose to Purchaser confidential and proprietary information of ATI relating to the design, operation, or other aspects of ATI's products. As between ATI and Purchaser, ownership of such information, including without limitation any computer software provided to Purchaser by ATI, shall remain in ATI and such information is licensed to Purchaser only for Purchaser's use in operating the products supplied by ATI hereunder in Purchaser's internal business operations.

Without ATI's prior written permission, Purchaser will not use such information for any other purpose or provide or otherwise make such information available to any third party. Purchaser agrees to take all reasonable precautions to prevent any unauthorized use or disclosure of such information.

Purchaser will not be liable hereunder with respect to disclosure or use of information which: (a) is in the public domain when received from ATI, (b) is thereafter published or otherwise enters the public domain through no fault of Purchaser, (c) is in Purchaser's possession prior to receipt from ATI, (d) is lawfully obtained by Purchaser from a third party entitled to disclose it, or (f) is required to be disclosed by judicial order or other governmental authority, provided that, with respect to such to maintain the confidentiality of such information.

## Appendix A – UDP Command CRC Calculation

All UDP commands sent to the Wireless F/T must include a two-byte CRC (Cyclic Redundancy Check) value. This value is used for error checking the command request and is based on the data in the command structure to be sent.

The following C code performs the calculation of the CRC value. To calculate the value, pass a pointer to the command structure along with the command length in bytes minus two to the function `crcBuf()`.

```
// If FAST is defined, then the CRC is determined using a lookup table instead of
calculations
#define FAST 1

// Both versions use the CRC-16-CCITT polynomial: x^16 + x^12 + x^5 + 1 = 0x11021

#if FAST
unsigned short crcByte(unsigned short crc, unsigned char ch) // lookup table version
(bigger & faster)
{
    static const unsigned short ccitt_crc16_table[256] =
    {
        0x0000, 0x1021, 0x2042, 0x3063, 0x4084, 0x50a5, 0x60c6, 0x70e7,
        0x8108, 0x9129, 0xa14a, 0xb16b, 0xc18c, 0xd1ad, 0xe1ce, 0xf1ef,
        0x1231, 0x0210, 0x3273, 0x2252, 0x52b5, 0x4294, 0x72f7, 0x62d6,
        0x9339, 0x8318, 0xb37b, 0xa35a, 0xd3bd, 0xc39c, 0xf3ff, 0xe3de,
        0x2462, 0x3443, 0x0420, 0x1401, 0x64e6, 0x74c7, 0x44a4, 0x5485,
        0xa56a, 0xb54b, 0x8528, 0x9509, 0xe5ee, 0xf5cf, 0xc5ac, 0xd58d,
        0x3653, 0x2672, 0x1611, 0x0630, 0x76d7, 0x66f6, 0x5695, 0x46b4,
        0xb75b, 0xa77a, 0x9719, 0x8738, 0xf7df, 0xe7fe, 0xd79d, 0xc7bc,
        0x48c4, 0x58e5, 0x6886, 0x78a7, 0x0840, 0x1861, 0x2802, 0x3823,
        0xc9cc, 0xd9ed, 0xe98e, 0xf9af, 0x8948, 0x9969, 0xa90a, 0xb92b,
        0x5af5, 0x4ad4, 0x7ab7, 0x6a96, 0x1a71, 0x0a50, 0x3a33, 0x2a12,
        0xdbfd, 0xcdbc, 0xfbbf, 0xeb9e, 0x9b79, 0x8b58, 0xbb3b, 0xab1a,
        0x6ca6, 0x7c87, 0x4ce4, 0x5cc5, 0x2c22, 0x3c03, 0x0c60, 0x1c41,
        0xedae, 0xfd8f, 0xcdec, 0xddcd, 0xad2a, 0xbd0b, 0x8d68, 0x9d49,
        0x7e97, 0x6eb6, 0x5ed5, 0x4ef4, 0x3e13, 0x2e32, 0x1e51, 0x0e70,
        0xff9f, 0xefbe, 0xdfdd, 0xcffc, 0xbf1b, 0xaf3a, 0x9f59, 0x8f78,
        0x9188, 0x81a9, 0xb1ca, 0xa1eb, 0xd10c, 0xc12d, 0xf14e, 0xe16f,
        0x1080, 0x00a1, 0x30c2, 0x20e3, 0x5004, 0x4025, 0x7046, 0x6067,
        0x83b9, 0x9398, 0xa3fb, 0xb3da, 0xc33d, 0xd31c, 0xe37f, 0xf35e,
        0x02b1, 0x1290, 0x22f3, 0x32d2, 0x4235, 0x5214, 0x6277, 0x7256,
        0xb5ea, 0xa5cb, 0x95a8, 0x8589, 0xf56e, 0xe54f, 0xd52c, 0xc50d,
        0x34e2, 0x24c3, 0x14a0, 0x0481, 0x7466, 0x6447, 0x5424, 0x4405,
        0xa7db, 0xb7fa, 0x8799, 0x97b8, 0xe75f, 0xf77e, 0xc71d, 0xd73c,
        0x26d3, 0x36f2, 0x0691, 0x16b0, 0x6657, 0x7676, 0x4615, 0x5634,
        0xd94c, 0xc96d, 0xf90e, 0xe92f, 0x99c8, 0x89e9, 0xb98a, 0xa9ab,
        0x5844, 0x4865, 0x7806, 0x6827, 0x18c0, 0x08e1, 0x3882, 0x28a3,
        0xcb7d, 0xdb5c, 0xeb3f, 0xfb1e, 0x8bf9, 0x9bd8, 0xabbb, 0xbb9a,
        0x4a75, 0x5a54, 0x6a37, 0x7a16, 0x0af1, 0x1ad0, 0x2ab3, 0x3a92,
        0xfd2e, 0xed0f, 0xdd6c, 0xcd4d, 0xbdaa, 0xad8b, 0x9de8, 0x8dc9,
        0x7c26, 0x6c07, 0x5c64, 0x4c45, 0x3ca2, 0x2c83, 0x1ce0, 0x0cc1,
        0xef1f, 0xff3e, 0xcf5d, 0xdf7c, 0xaf9b, 0xbfba, 0x8fd9, 0x9ff8,
        0x6e17, 0x7e36, 0x4e55, 0x5e74, 0x2e93, 0x3eb2, 0x0ed1, 0x1ef0
    };
};
return ccitt_crc16_table[((crc >> 8) ^ ch) & 0xff] ^ (crc << 8);
}
```

```
#else
unsigned short crcByte(unsigned short crc, unsigned char ch) // direct calculation
version (smaller & slower)
{
    unsigned short crc_new = (unsigned char)(crc >> 8) | (crc << 8);
    crc_new ^= ch;
    crc_new ^= (unsigned char)(crc_new & 0xff) >> 4;
    crc_new ^=  crc_new          << 12;
    crc_new ^= (crc_new & 0xff) << 5;
    return crc_new;
}
#endif

#define CRC_INIT 0x1234 // this is the seed value used for along with the buffer's
first byte
unsigned short crcBuf(const void * buff, unsigned long len)
{
    unsigned long i;
    unsigned short crc = CRC_INIT;
    const char * buf = buff;

    for(i = 0; i < len; i++)
    {
        crc = crcByte(crc, buf[i]);
    }

    return crc;
}
```


## Appendix B – Initial Configuration Using a Telnet Program (PuTTY)

### B.1 Initial Configuration Using a Telnet Program

The Wireless F/T must be configured before communicating with the device. The following procedure will help provide steps to configure the Wireless F/T.


1. Install Virtual Communication Port Driver from the following website: <http://www.ftdichip.com/Support/Documents/InstallGuides.htm>  
Select the instructions for the operating system running on the computer being used to configure the wireless F/T system. Follow the instructions to load the device driver on the computer.
2. Find the serial port number used by the Wireless unit by opening Device Manager (you can get to it by typing “Device Manager” in the Windows 7 Start Menu search bar), expanding the “Ports (COM & LPT)” section, and finding a connection labeled “USB Serial Port (COMx)” If there’s more than one serial port, you may have to disconnect the USB cable and see which COM port is removed in the device manager, then reconnect the USB cable. The example in the following figure shows Wireless F/T is connected to COM5.

Figure 14.1—Windows 7 Device Manager




3. Install a telnet terminal program like PuTTY. Visit <http://putty.org> to download the executable file (putty.exe) for the PuTTY program.
4. Open (PuTTY) terminal program by clicking on the (putty) icon and selecting Run from the pop up window.
5. In the Category pane click on Connection > Serial and fill in the following fields:
  - Serial line to connect to COM5 (Enter the Com port the Wireless unit is using)
  - Speed (baud) 115200
  - Data bits 8
  - Stop bits 1
  - Parity None
  - Flow control None

Figure 14.2—PuTTY Terminal Program



6. In the Category pane click on Session, The Serial Line should now be the COM port and Speed should be the values entered in the previous step. In the Saved Sessions field enter Wireless FT COM5 and select save. This will allow you to use this configuration at another time.


Figure 14.3—PuTTY Configuration



7. Connect to the console, e.g. by pressing “Open” in PuTTY. Information will appear as the unit attempts to connect to a wireless network.
8. In the COMx – PuTTY Window type “d” and press Enter key.
9. In the COMx – PuTTY Window type “t” and press Enter key. (Turns off the wireless connection on the unit).

10. Test that the unit is working by entering “IP” followed by the Enter key. This is the IP command, and will present the current IP settings. Refer to the following example screen.


**Figure 14.4—Test the Connection**



```
COM5 - PuTTY
ip
ANTENNA External
BAND 2.4 GHz
DHCP On Active:
DESTIP 10.1.1.254 10.1.1.177
GATEIP 10.1.1.20 10.1.1.20 08-60-6e-bd-ac-74
MYIP 10.1.0.51 10.1.2.80 00-23-a7-3b-7d-15
NETMASK 255.255.252.0 255.255.252.0
SSID WIRELESSFT
TXPWR 2
Telnet Listening 23
UDP Listening 49152
UDP Sending 10.1.1.177 : 49151
WifiVer 2.2.8.1.4.0
Module WLAN state: Connected to AP
>
```

11. Obtain the following information from your network administrator: IP Address to use for the unit, Subnet Mask, Default Gateway, SSID, whether the Wi-Fi network operates on 2.4 or 5 gigahertz spectrum, IP address of the computer you’re using to communicate with the unit.
12. Enter these commands in any order: (Commands are not case sensitive except where indicated)
  - a. “MYIP <unitip>”, e.g. “MYIP 192.168.1.50”
  - b. “NETMASK <subnetmask>”
  - c. “GATEIP <defaultgateway>”
  - d. “SSID <ssid>” Network<ssid> (Is case sensitive)
  - e. “BAND <x>” where x is “2.4” for 2.4 gigahertz or “5” for 5 gigahertz.
  - f. “DESTIP <yourcomputersip>”

Figure 14.5—Test the Connection



```
COM5 - PuTTY
ip
ANTENNA External
BAND 5 GHz
DHCP On Active:
DESTIP 10.1.1.177 10.1.1.177
GATEIP 192.168.0.1 10.1.1.20 08-60-6e-bd-ac-74
MYIP 10.1.1.2 10.1.2.80 00-23-a7-3b-7d-15
NETMASK 255.255.255.0 255.255.252.0
SSID WIRELESSFTDEMO
TXPWR 2
Telnet Listening 23
UDP Listening 49152
UDP Sending 10.1.1.177 : 49151
WifiVer 2.2.8.1.4.0
Module WLAN state: Connected to AP
>myip 10.1.0.51
My IP was 10.1.1.2 = 10.1.0.51
>gateip 10.1.1.20
Gateway IP was 192.168.0.1 = 10.1.1.20
>netmask 255.255.252.0
Net Mask was 255.255.255.0 = 255.255.252.0
>SSID WIRELESSFT
SSID was WIRELESSFTDEMO now WIRELESSFT
>BAND 2.4
Change takes effect after reset: Band = 2.4 GHz
>DESTIP 10.1.1.254
Destination IP was 10.1.1.177 = 10.1.1.254
>
```

13. Enter the “SAVEALL” command followed by the “RESET” command for the new settings to take effect.
14. Close the terminal program.
15. Press the On/Off switch for two seconds to power down. Then press again to power up. After initialization the unit will connect to the wireless network and begin streaming data.
16. Disconnect the USB cable from the Wireless F/T unit and the computer.

## Appendix C– Sampling Other Signals Using Wireless F/T inputs

### C.1 Introduction

This appendix explains how to sample arbitrary analog or digital signals using transducer inputs on a Wireless F/T interface. These requirements include design of a signal conditioning circuit and calibration of the Wireless F/T inputs for analog signal sampling. This feature could be used to help synchronize F/T data with other sensors by using an empty transducer input to record a digital trigger signal.

### C.2 Definitions

Internal Calibration – Wireless F/T analog signal calibration using only internal voltage references.

External Calibration – Wireless F/T analog signal calibration using external voltage references.

### C.3 Wireless F/T Digital Input Sampling


Wireless F/T inputs can safely handle 3.3V or 5V logic signals. These signals will saturate the ADC and provide basic digital signal readings. The Wireless F/T amplifier electronics include a 2nd order 1kHz low-pass filter which will restrict usable digital signals to ~250 Hz.

### C.4 Wireless F/T Analog Input Sampling

In order to sample an analog signal using a Wireless F/T you will probably need a signal conditioning circuit. The signal conditioning circuit must be designed to meet the requirements listed in [Table 15.1](#). The following page shows an example signal conditioning circuit designed to take  $\pm 10$  VDC in and output 2.5 VDC  $\pm 250$  mVDC. The voltage data output by the Wireless F/T will not include the 2.5V input offset.

| Table 15.1— Wireless F/T Input Specifications   |                               |
|---|-------------------------------|
| <b>Absolute Maximum Input Voltage</b>   | See <a href="#">Table 9.2</a> |
| <b>Nominal Input Voltage</b>  | 2.5 VDC                       |
| <b>Maximum Full Scale Input Signal Range</b>  | 2.5 VDC $\pm 250$ mVDC        |
| <b>Minimum Full Scale Input Signal Range</b>  | 2.5 VDC $\pm 30$ mVDC         |
| <b>Input Impedance</b>  | 5 M $\Omega$                  |
| <b>5V Supply Maximum Current</b>  | 20mA                          |
| Note:   |                               |
| 1. Exceeding this input voltage range could irreparably damage the Wireless F/T internal electronics. |                               |

Figure 15.1—Rotating Reference Frame



**ATI Industrial Automation**  
 1031 Goodworth Drive  
 Apex, NC 27539  
 Phone: 919-772-0115  
 Fax: 919-772-8259

**ATI INDUSTRIAL AUTOMATION**  
 ISO 9001 Registered  
 Engineered Products for Manufacturing Productivity

Property of ATI Industrial Automation, Inc. (ATI). Not to be reproduced in any manner except on order or with prior written authorization of ATI.

Title: Wireless FT Signal Conditioning

Size: ATI Part Number 140930-3  
 Customer: 290-05-1482  
 Drawn By: David Fleissner  
 Date: Thursday, February 26, 2015

Project Number: 140930-3  
 Checked By: Alexander Stotzer  
 Sheet 1 of 1


- Notes:
- The circuit as shown is designed for  $\pm 10V$  input range.
  - Input voltage range is limited by  $V+$ ,  $V-$ , and the op amps that are used.
  - Input protection can be removed if the input comes from a safe and low noise source.
  - The input buffer can be removed if the input protection is removed and a low impedance source is used.
  - Noise can be reduced by using a low noise external power supply with linear regulators and low noise op amps with low value resistors.
  - Switching regulator selection is crucial for noise performance. The switching regulator must adequately power the circuit while consuming  $< 20mA$  from the 5V source.
  - Switching regulator ripple voltage should be minimized.
  - The Wireless F/T inputs should never exceed  $-7VDC$  to  $+7VDC$ .
  - Anyone attempting to implement this design should be an expert at designing and troubleshooting analog electronics.

## C.5 Wireless F/T Analog Input Calibration

Calibrating the Wireless F/T to read in an analog voltage can be performed using the Wireless F/T Java demo. Calibration slot 3 will be pre-calibrated by ATI using the Internal Calibration method below.

Access the Voltage Calibration window in the Java demo by going to Advanced->Voltage Calibration.

**Figure 15.2—Access the Voltage Calibration Window**




The Wireless F/T Java demo offers two methods to perform an analog input calibration:

### C.5.1 Internal Calibration

The internal calibration method is performed only using the internal voltage references in the Wireless F/T. This calibration method is as simple as the press of a button and does not require external calibration equipment. However, expect some amount of gain error ( $\pm 1\%$  is common) when using the internal calibration method.


1. From the Voltage-Calibration window in the Wireless F/T Java demo click on the Auto-Calibrate button. The input range can be set using the Input Range box at the bottom of the window.

**Figure 15.3—Set Input Range - Internal Calibration**



2. Once the internal calibration is complete, close the Voltage-Calibration window, apply your 2.5V reference to the inputs of the Wireless F/T, and bias the transducer input you just calibrated.

**Figure 15.4—Apply the Input Range - Internal Calibration**




### C.5.2 External Calibration

The external calibration method is performed by using external voltage references to calibrate the Wireless F/T inputs. This calibration method is more difficult to set up than the internal calibration but results in a more accurate calibration. The accuracy of this calibration method is primarily limited by the stability and accuracy of the external reference voltages.


1. From the Voltage-Calibration window in the Wireless F/T Java demo click on the External-Calibrate button. The input range can be set using the Input Range box at the bottom of the window.

**Figure 15.5—Set Input Range - External Calibration**




2. Follow the instructions given in the Voltage-Calibration window.

**Figure 15.6—Select a Transducer to Calibrate - External Calibration**




**Figure 15.7—Select a Transducer Input to Calibrate - External Calibration**



3. Once the external calibration is complete, close the Voltage-Calibration window, apply your 2.5 V reference to the inputs of the Wireless F/T, and bias the transducer input you just calibrated. See the Wireless F/T manual for more details about biasing a transducer input.

**Figure 15.8—Apply the Input Range - External Calibration**



## C.6 Troubleshooting

**Figure 15.9— Troubleshooting**

| Symptom  | Possible Cause                                 | Correction   |
|--|--|--|
| Excessive noise                                    | Too much power supply ripple                   | Use power supply with lower ripple voltage   |
|  | Op amps oscillating                            | Place ceramic decoupling capacitors near op amp supply pins                                |
| 5V supply from Wireless F/T turns off unexpectedly | Drawing >20mA from 5V supply                   | Use power supply with higher efficiency at small loads                                     |
|  |  | Use 2.5V reference with lower supply current   |
|  |  | Use op amps with lower supply current  |
|  |  | Use external supply with higher current limit  |
| Unexpected readings after calibration              | Transducer input has not been biased           | Bias transducer input with 2.5V reference connected to input                               |
|  | External calibration had invalid input voltage | Repeat external calibration. Internal calibration can also be used to verify all hardware. |

## Appendix D– Interpreting the Timestamp in Wireless F/T Demo Log

The timestamp in the Wireless F/T data log is a shortened version of the NTP timestamp format. The timestamp is represented as an unsigned 32-bit number. The upper 20 bits are the number of seconds and the lower 12 bits are the fractions of a second. The timestamp represents a fractional number of seconds, from the reference time period used by the NTP server. If the Wireless F/T is not connected to an NTP server, then its clock will default to January 1, 2010.

### D.1 Converting NTP Format to Seconds

In post data processing, it is often useful to show the F/T data as a time series. To convert the Wireless F/T data log timestamp, to a useable value in seconds, treat the timestamp as a fixed point value with a q-point of 12.

In the datalog, sometimes the timestamp value represented as negative value. This is caused by Java interpreting the data as a signed 32-bit integer, rather than an unsigned 32-bit integer. To properly reflect the unsigned value, add 232 (4,294,967,296) to the negative number, before performing the fixed point conversion.

The conversion to seconds can be implemented as given in the equation below.

$$\text{Timestamp in Seconds} = (\text{unsigned 32 bit Timestamp}) * 2^{(-12)}$$

### D.2 Excel Conversion Example

Below is an example of how to easily add in the timestamp conversion to an excel sheet being used for analysis. The example assumes the timestamp is in column A.

Insert a new column into column B, and title it “Converted Timestamp [Sec]” in row 1. In row two of column B place the following formula.

**=IF(A2<0,A2+2^32,A2)\*2^(-12)**

Apply the formula from cell B2 to the rest of the cells in column B. Column B now contains the timestamp in seconds.

Optionally if you would like to get the elapsed time, subtract the value in B2 from all other values in the data set.

**Figure 16.1—Example Excel Sheet with Converted Timestamp and Elapsed Time**

|   | A          | B                    | C                  |
|---|------------|----------------------|--------------------|
| 1 | Time       | Converted Time [Sec] | Elapsed Time [Sec] |
| 2 | -964007418 | 813222.6265          | 0                  |
| 3 | -964007385 | 813222.6345          | 0.008056641        |
| 4 | -964007352 | 813222.6426          | 0.016113281        |
| 5 | -964007319 | 813222.6506          | 0.024169922        |
| 6 | -964007287 | 813222.6584          | 0.031982422        |
| 7 | -964007254 | 813222.6665          | 0.040039063        |
| 8 | -964007221 | 813222.6746          | 0.048095703        |
| 9 | -964007188 | 813222.6826          | 0.056152344        |