



PRODUCT NOTICE 2024-003

**Product End-of-Life / Last Buy**  
Obsolescence of Selected ATI Tool Changer SKUs

Regions Affected: **GLOBAL**

Dear Valued Partners,

At ATI, we strive to continuously evaluate and update our product line to meet evolving customer needs around the world. In some cases, this means consolidating or discontinuing older products to focus our efforts on newer products to provide an enhanced customer/user experience. Following this, we are announcing the following changes to our portfolio.

General Description of Affected Product(s)
Numerous older or low-selling models of robot tool changers, and their associated utility modules (for example control modules, or pass-through modules for fluid, signal, air, power, etc.), plus related accessories, and affected tool changer configurations, for both the Standard QC and Heavy-Duty QC product lines.
All affected part numbers are listed in the accompanying spreadsheet.
Your Account Manager can provide a tailored list of part numbers affecting your company, with order history.

**TIMELINE OF EVENTS**

The following timeline pertains to all items identified in this notice. These dates are subject to change based on availability of remaining inventory.

Event	Description	Date
Last Time Buy	Deadline to place Last Time Buy orders.	<b>July 1, 2024</b>
Must Ship By	Deadline customer must accept shipment.	<b>September 30, 2024</b>

**WARRANTY INFORMATION**

Subject to the following conditions, ATI warrants its manufactured products as being free of defective materials and faulty workmanship during the applicable warranty period. The standard product warranty applies unless agreed to otherwise by ATI in writing; please refer to your order acknowledgement or consult your local sales representative for specific warranty details. In the event obsolete products are returned to ATI during the warranty period for service or repair, ATI will make commercially reasonable efforts to repair or replace items that ATI, in its sole discretion, finds defective.

ATI Industrial Automation is committed to providing innovative engineered robotic end-of-arm tooling and we appreciate your continued support of the ATI brand and product lines. Please contact your ATI Account Manager for questions, product transition options, or assistance.

Kind Regards,

*Baron V. Kendrick*

Standard Tool Changer Product Manager  
ATI Industrial Automation, A Novanta Company

## ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-1B-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
3700-20-10227	QC-11 Piston, TDC - Custom Length and Diameter
9005-20-1703	V300 Vacuum Module Master Adapter to J16
9005-20-1704	V300 Vacuum Module Tool Adapter to J16
9120-005M-000-000-1107	QC-5 Master with Interface Plate to BC50, (4)M6, Boss 41.15, Dowel 6 (Adept)
9120-005M-E20-000	Quick Change 5 Master, E20 Elec. Module
9120-005M-IP-1107	QC-5 Master Interface Plate to BC50, (4)M6, Boss 41.15, Dowel 6 (Adept)
9120-005M-IP-1930	IP for QC-5 Master to BC28.2, (6)M3, (2)D3 (Mini45 TAP)
9120-005T-E20-000	Quick Change 5 Tool, E20 Elec. Module
9120-007TZK4-0-0	QC-007 Base Tool Assembly, Slotted
9120-007TZK4-0-0-B	** Obsolete replaced by 9120-007ST-0-0-B**QC-007 Base Tool Assembly, Slotted, Black
9120-010M-000-000	QC-10 Master, no options
9120-010M-000-000-SQ-4532	QC-10 Master, SIP-Q to BC31.5 (4)M5 Boss20 D5
9120-010M-A15-000	QC-10 Master with 15-pin, 3A/50V, high-density D-sub connector
9120-010M-A15-000-SQ-4532	QC10 Master with A15, SIP-Q to BC31.5, (4)M5, Boss 20, Dowel 5
9120-010M-E10-000	QC-10 Master, E10 Elec. Module
9120-010M-SEALS	QC10 Master Seal Kit
9120-010T-000-000	QC-10 Tool, no options
9120-010T-A15-000	QC-10 Tool w/ A15 Electrical Module
9120-010T-A15E-000	QC-10 Tool with A15-E Module
9120-010T-E10-000	QC-10 Tool, E10 Elec. Module
9120-011-ASY-2000-M	QC-11 Master Kit with (1) 9120-011MZ6-000-000-B, (1) 9120-E10MZF2-010, and (6) 4010-0000026-01
9120-011M-HYB19-000	QC-11 Master plate with HYB19 Module
9120-011M-HYB19-000-SQ-0000	QC-11 Master with Lock/Unlock sensing kit w/out interface plate, includes 4mm PNP sensors with 10" cables with HYB19 Module
9120-011M-IP-1883	IP for QC-11 Master to BC31.5, (4)M5, Boss 12, Dowel 5
9120-011M-KR5A-000	QC-11 Master with KR5A electrical module
9120-011M-KR5C-000	QC-11 Master with KR5C electrical module
9120-011M-SIP-Q-1928	SIP Kit for QC-10/11M to BC31.5, (4)M4, Boss 12, Dowel 5
9120-011MZH1-000-000	QC-11 Master, Stainless Steel
9120-011MZH1-KR5B-000-SQ-8604	QC-11 Master, SS, KR5B, PNP sensors with plate to BC31.5, (4)M5, Boss 20, Dowel 5
9120-011T-HYB19-000	QC-11 Tool plate with HYB19 Module
9120-011TZK4W14-000-000-B	QC-11 Tool Body, Black - Axial Ports - Integrated Tool Stand Slots
9120-018M-2387-RD26-0-0-SG2	QC-18 Master Assy, w/ 24VDC Motor Module 2387, RD26 module, Integrated Controls, PNP DC Sensors, M5 RTL
9120-020HMZB1F2T1-000-PM5-SQ-6247	QC-20 Hollow Wrist Mount Master with Tungsten Carbide Balls, Stainless Steel Fasteners, TDC Locking Mechanism and SQ-6247
9120-020M-000-PM5-SQ-1697	QC-20 Master, 12 air ports, no options & SIP Q to BC50,(4) of (6)M6,Boss31.5,D6
9120-020M-000-PM5-SQ-1820	QC-20 Master, no options, PNP lock/unlock with SIP 1820
9120-020M-D15BLA-PM5	QC-20 Master, D15 BLA-style, M5 pneumatic pass-through ports
9120-020M-IP-1706	QC-20/QC-21 Master IP Blank
9120-020M-IP-1763	QC-20/21M Interface Plate kit to BC50, (4) of (6)M6, Boss 31.5, Dowel 6
9120-020M-K12-PM5-SQ-1820	QC-20 Master with K12 Module (Potted), PNP lock/unlock with SIP 1820
9120-020M-K26P-PM5-SQ-1697	QC-20 Master with K26P module, PNP sensors, IP to BC50, (6)M6, Boss 31.5, Dowel 6
9120-020M-KF19-P16-SQ-1820	QC-20 Master, 16 Ports, w/KF19 with SIP to 4mm PNP to BC 56, (6)M4, Recess62, Dowel 4
9120-020M-KF19-PM5-SQ-1697	QC-20 Master with KF19, SIP-Q and plate with BC50, (6)M6, Recess 31.5, Dowel 6
9120-020M-L19-PM5	QC-20 Master, 12 air ports, L19
9120-020M-L19-PM5-1823	QC-20 Master with 19-pin, 3A/50V, miniature MS quick-disconnect connector w/IP to BC56, (8)M4, Recess 62,D4 (no pass-thru)
9120-020M-L19-PM5-B	QC-20 Master, 12 air ports, L19, Black
9120-020M-L26-PM5-B	QC-20 Master Black w/ 26-pin, 3A/50V
9120-020M-SIP-Q-1697	QC-20/21 lock/unlock sensor robot IP 4mm PNP w/10" cbl.w/Nano connect BC50,(4) of (6)M6,Boss31.5,D6
9120-020M-SIP-Q-1820	QC-20/21 Lock/unlock sensor robot interface plate 4mm PNP to BC 56, (6)M4, Recess62, Dowel 4 (No Pass-thru)
9120-020M-SIP-Q-1891	SIP for QC-20/21M to (4)M8, 60mm x 60mm Pattern
9120-020M22-000-PM5-B	Custom QC-20 Master, Tungsten Carbide Balls, Food Grade Grease (DuPont Molykote G-4500), TDC of Cam, Male Coupling, Alignment Pins, Black Body
9120-020T-L19-PM5	QC-20 Tool, 12 air ports, L19
9120-020T-L19-PM5-B	QC-20 Tool, 12 air ports, L19, Black
9120-020TZF2T1-000-PM5	QC-20 Tool with (12) M5 pneumatic pass-through ports, Stainless Steel Fasteners and TDC Coating
9120-020TZT1-000-PM5-B	Custom QC-20 Tool, TDC of Bearing Race, Black
9120-021HM-K12-RX12-SQ-6160	QC-21 Hollow Wrist Mount Master, with PNP 3 Wire DC Sensors w/K12, RX12 modules, and 6160 IP
9120-021M-000-000-R	QC-21 Master with (8) Rc 1/8 BSPT ports
9120-021M-000-000-SQ-1697	QC-21 Master, no options with SIP to BC50,(4) of (6)M6, Boss31.5, D6
9120-021M-000-000-SQ-1772	QC-21 Master, no options with SIP to BC25, (4)M5, (2)Dowel 3 (4 mm Sensors)
9120-021M-000-000-SQ-1820	QC-21 Master with -1820 SIP
9120-021M-000-000-SQN-2942-R	QC-21 Master with (8) Rc 1/8 BSPT ports, NPN sensors, and Plate to BC40, (4) M6, Boss 25, Dowel 6
9120-021M-D15-H06	QC-21 Master with D15, H06 Modules
9120-021ME-SIP-Q-1697	QC-21 Master Euro SIP to ABB IRB 2400/16 B.C. 50mm
9120-021M-K12-000-SQ-1697	QC21 Master with K12 Euro Fast Connector and lock/unlock sensor robot IP 4mm PNP w/10" cbl.w/Nano connect BC50,(4) of (6)M6,Boss31.5,D6
9120-021M-K26-000-SQ-1820-R	QC-21 Master with (8) Rc 1/8 BSPT ports w/ K26 module with SIP to BC 56, (6)M4, Recess62, Dowel 4
9120-021M-KF19-000-SQ-1697	QC-21 Master with KF19 and -1697 SIP
9120-021M-KF19-000-SQ-1772	QC-21 Master with KF19 module and SIP to BC25, (4)M5, (2)Dowel 3 (4 mm Sensors)
9120-021M-KF19-000-SQ-1820	QC-21 Master with KF19 electrical module with SIP-Q to BC 56, (6)M4, Recess62, Dowel 4 (No Hollow Wrist Pass-thru)
9120-021M-L26-H03-E	QC-21 Master w/L26 and H03 (3000V) modules - Euro
9120-021M-SIP-Q-1910	SIP for QC-20/21 Master to (4)M5 Tap, 14 x 90mm Sqr, STL (Sepro BP120)
9120-021MZ7-000-000-E	Custom QC-21 Master, Euro, with Tungsten Carbide Balls, SS Fasteners (F2), Food Grade Grease (Molykote G-4500), TDC Locking Mechanism and Alignment Pins, Viton Seals
9120-021MZH9-000-000-E	QC-21 Euro Master, Electroless Nickel Plated Housing
9120-021T-000-000-R	QC-21 Tool with (8) Rc 1/8 BSPT ports
9120-021T-000-H03	QC-21 Tool Side with H03 Module
9120-021T-K12-RX12	QC-21 Tool with K12, RX12 modules
9120-021T-K26-000-R	QC-21 Tool with (8) Rc 1/8 BSPT ports with K26 module
9120-021T-KM14S1-000	QC-21 Tool with KM14S1 module
9120-021T-L26-H03-E	QC-21 Tool w/L26 and H03 (3000V) modules - Euro
9120-021TZH9-000-000-E	Custom QC-21 Euro Tool, Electroless Nickel Plated Housing (H9)
9120-026M-000-PM5-B	QC-26 Master, Black
9120-026M-000-PM5-SQN-1912-B	QC-26 Master with -1912 SIP and NPN switches
9120-026M-D15-PM5-B	QC-26 Master with D15 Module, Black
9120-026T-000-PM5-B	QC-26 Tool, Black
9120-026T-D15-PM5-B	QC-26 Tool with D15 Module, Black
9120-027HM-000-000-S0-E	*** LAST BUY UNTIL 06-30-2024; AFTER USE INTERCHANGEABLE 9120-027HM-000-000-S01-E INSTEAD *** QC-27 Hollow Wrist Base Assembly, 24mm Thru Hole, Black, 8 Integrated Air Ports, No Sensors (FOR SCHUNK, DOUBLE CHECK PART #)
9120-027HM-000-000-SQ1-E	QC-27 Hollow Wrist Master, Black, with 4mm push Tube Fittings, PNP 3 Wire Sensors, Flying Lead
9120-027M-K5A-000-SQ-E	QC-27 Master with K5A module and PNP 3-Wire Sensors, Black

### ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-028M-000-000-SQ	QC-28 Master with PNP Sensors, no other options
9120-028M-000-KJ19A-SQ	QC-28 Master with PNP Sensors with KJ19A electrical module
9120-028MZ1-S19W-GB8A-S19-SQ	QC-28 Master with PNP 3-Wire Sensors, 4mm Push Tube Fittings, M19 Mounting Pattern, custom porting with S19W, GB8A, S19 modules.
9120-036Z3M-0-0-0-TDC-SS	QC-36Z3 SS Master with 130mm Thru Hole, TDC Locking Mechanism, Carbide Balls, No Sensors
9120-036Z3T-0-0-0-TDC-SS	QC-36Z3 SS Tool with 130mm Thru Hole, TDC Bearing Race
9120-040M-000-000-R	QC-40 Master - R Ports
9120-040M-000-000-SD-2875	QC-40 Master w/4mm PNP, BC100, 6M8, Boss63, D8 with 5m Cables
9120-040M-D15A-000-R	QC-40 Master with R ports with BLA D15A modules
9120-040M-IP-1880	IP for QC-40Q to BC56, (8)M4, Recess 62, Dowel 4 (2-Plate Assy)
9120-040M-L19-000	QC-40 Master, L19 electrical module and adapter plate
9120-040M-L19-000-SD-2910	QC-40 Master with L19 module and SIP-D-2910
9120-040M-L19-000-SF-1758	QC-40 Master, L19 electrical module and SIP to (4)M8, (4)M6, (2)D6, Rect Pattern (Star TW-1800)
9120-040M-L19-P18	QC-40 Master with L19 and P18 modules
9120-040M-L19-P186	QC-40 Master with L19 and P186 modules
9120-040M-L19-P186-SF-1758	QC-40 Master with L19 and P186 modules and SIP to (4)M8, (4)M6, (2)D6, Rect Pattern (Star TW-1800)
9120-040M-R19-000-SD-0000-E	QC-40 Master with R19 electrical module and SIP-D, no plate, Euro
9120-040M-R19-000-SF-1867-R	QC-40 Master, R19, R Ports, NPN sensors, IP to SR176 stem
9120-040M-R19-000-SG-0000-E	QC-40 Master with R19 electrical module and SIP-G, no plate, Euro
9120-040M-R19V-000-E-V	QC-40 Euro Master with Viton seals with R19 Module w/Viton Seal
9120-040M-R19W-000-SG-2877	QC-40 Master with R19W module and SIP-G-2864
9120-040M-R19W-X7G-SG-1855-E	QC-40 Master with R19W, X7G modules, SIP-G-1855, Euro
9120-040M-R19W-X7G-SG-2875-E	QC-40 Master with R19W, X7G modules, SIP-G-2875, Euro
9120-040M-R26-000-SD-2875	QC-40 Master with R26 Module, 4mm PNP, BC100, 6M8, Boss63, D8 with 5m Cables
9120-040M-R26W-000-SG-0000-E	QC-40 Master with R26W module & mounted PNP sensor kit, Euro
9120-040M-R26W-000-SG-2807	QC-40 Master with R26W, SIP-G and plate with BC100, (6)M10, Boss 63, Dowel 8
9120-040M-RD26-000	QC-40 Master with RD26 electrical module
9120-040M-RF19-000-SF-2910-R	QC-40 Master w/RF19 Electrical Module with SIP-F to 80 mm BC, (6) M8, 50 mm boss, 8 mm dowel
9120-040M-RF19RX12-P05	QC-40 Master with RF19, RX12 and P05 modules
9120-040M-RF19W-000-SG-2864	QC-40 Master with RF19W Module and -2864 SIP
9120-040M-RF19W-P05-SG-2875	QC-40 Master with RF19W, P05 and SIP-G to BC100, (6)M8, Boss63, Dowel 8
9120-040M-RF19W-P05-SG-2877	QC-40 Master with RF19W, P05 and SIP-G to BC40, (4)M6, 6mm Dowel, 25mm Boss Fanuc(M6i)
9120-040M-SIP-D-2875	QC-40 SIP w/4mm PNP, BC100, 6M8, Boss63, D8 with 5m Cables
9120-040M-SIP-D-2896	QC-40 Lock/Unlock SIP w/PNP quick-disconnect proximity sensors w/5m cables to BC40, (4) M6, Boss 25, Dowel 6
9120-040M-SIP-E-2672	Sensor Interface Plate for QC-40 Master
9120-040M-T19WH-P18-SG-4232	QC-40 Master with T19WH, P18 with SIP G to BC100, (8)M5, Recess85
9120-040M-X7D-000	QC40 Master with X7D modules
9120-040QM-000-SE31-SB-9368	QC-40Q Master with SE31 module with M12 connectors, PNP Quick disconnect Lock/Unlock sensors w/Hardwired 5m Cables with IP to BC100, (6)M10, Boss63, Dowel 8, with flats
9120-040QM-000-X7SG-SG	QC-40Q Master Assembly, w/ X7SG, PNP Quick Disconnect Lock/Unlock Sensors
9120-040QM-000-X7SG-SG-E	QC-40Q Master Assembly, X7SG module, PNP Quick Disconnect Lock/Unlock Sensors, Euro
9120-040QM-MT8-000-SD-1880	QC-40Q Master Assembly, with MT8 and IP to BC56, (6) of (8)M4, Recess 62, Dowel 4 (2-Plate Assy)
9120-040QM-R19W-X7D-SG	QC-40Q Master with R19W and X7D modules and PNP Lock/Unlock Sensors
9120-040QM-R26W-MT9-SG-E	QC-40Q Master, R26W, MT9, PNP sensors, Euro
9120-040QM-REP7-REP7-SD	QC-40Q Master Assembly, (2) REP7 modules, PNP Quick Disconnect Lock/Unlock Sensors, 5m Cables
9120-040QM-REP7RES10-RF19W-SG-E	QC-40Q Master Assembly, with REP7, RES10, RF19W modules, PNP Quick Disconnect Lock/Unlock Sensors, Euro
9120-040QM-SE32-FN2-SB-1862	QC40Q Master, SE32, FN2, PNP Sensor, 1862 Interface Plate
9120-040QM-TPS-000-SD	QC-40Q Master Assembly, TPS module, PNP Quick Disconnect Lock/Unlock Sensors, 5m Cables
9120-040QM-X7D-X7D-SG	QC-40Q Master Assb, (2) X7D modules, PNP Quick Disc Lock/Unlock Sensors
9120-040T-000-000-R	QC-40 Tool - R Ports
9120-040T-000-SE31	QC-40 Tool with SE31 module
9120-040T-000-X7D	QC-40 Tool with X7D module
9120-040T-D15A-000-R	QC-40 Tool with R Ports with BLA D15A module
9120-040T-L19-000	QC-40 Tool, L19 electrical module with adaptor plate
9120-040T-L19-P18	QC-40 Tool with L19 and P18 modules
9120-040T-L19-P186	QC-40 Tool with L19 and P186 modules
9120-040T-R19-000-R	QC-40 Tool with RF19 Electrical Module, R Ports
9120-040T-REP7-REP7	QC-40 Tool, (2) REP7 modules
9120-040T-REP7RES10-RF14-E	QC-40 Tool with REP7, RES10, RF14 modules, Euro
9120-040T-RF19-000-R	QC-40 Tool with RF19 Electrical Module with M16 Connector, R Ports
9120-040T-SE32-FN2	QC40 Tool with SE32 and FN2 module
9120-040T-TPS-000	QC-40 Tool with TPS module
9120-040T-X7D-000	QC-40 Tool with X7D module
9120-040T-X7D-X7D	QC-40 Tool with (2) X7D module
9120-040TZF2T1-000-000	QC-40TZ Tool with F2 and T1 Options
9120-040TZF2T1-RF19PD-P141AZH4	QC-40TZ Tool with F2 and T1 Options with RF19PD module and P141A Tool Assembly, SS Housing
9120-040TZF2T1U1-R19-000	QC-40 Tool, SS Fasteners, TDC, Viton Seals with Standard R19 Electrical Module
9120-040TZF2T1U1-RJ419-000	QC-40 Custom Tool, F2, T1, U1 w/ RJ419 Electrical Module
9120-041M-000-000-SD-1916	QC-41 Master, no options, with Lock/Unlock Robot Sensor Interface Plate to BC50, (4)M6, Boss 31.5, Dowel 6
9120-041M-000-000-SD-2907	QC-41 Master with SIP w/PNP Sensors to BC80, Boss 50
9120-041M-000-000-SD-2915	QC-41 Master with Sensor Interface Plate to to BC100, (6)M8, (2)Dowel 8
9120-041ME-SIP-G-2807	QC-41 Master Euro Lock/unlock Sensor Interface Plate to BC100, (6)M10, Boss 63, Dowel 8
9120-041M-FN2-000-1156	QC-41 Master with (2) Self-Sealing Air/Fluid Ports, 3/8 NPT, SS w/IP to BC100, (6)M8, (2)Dowel 8, M8 Thru
9120-041M-IP-1156	Interface Plate for QC-40/41M to BC100, (6)M8, (2)Dowel 8, M8 Thru
9120-041M-J16-000-SE-0000	QC-41 Master with J16 module, NPN lock/unlock sensing kit without interface plate
9120-041M-R19-000-1156	QC-41 Master with R19 module with IP to BC100, (6)M8, (2)Dowel 8, M8 Thru
9120-041M-R19-000-SD-1814	QC-41 Master with R19 module & SIP to BC50, (6)M6, Recess 31.5, Dowel 6 and 5m cables
9120-041M-R19W-000-SG-1814	QC-41 Master with RF19W, SIP-G and plate to BC50, (6)M6, Boss 31.5, Dowel 6
9120-041M-R32-000-SD-2915	QC-41 Master with R32 Module and Sensor Interface Plate to to BC100, (6)M8, (2)Dowel 8
9120-041M-RF19-000-SD-2915	QC-41 Master with RF19 module w/SIP to to BC100, (6)M8, (2)Dowel 8
9120-041M-RF19-000-SF-2907-E	QC-41 Master with RF19 module w/SIP to BC80, (6)M8, Boss 8 (Motoman UP50) with NPN quick-disconnect switch and 5m cables, Euro
9120-041M-SIP-D-2896	SIP for QC-40/41M to BC40, (4)M6, Boss 25, Dowel 6
9120-041M-SIP-D-2907	SIP w/ PNP Sensors for QC-41M to BC80, (6)M8, Recess 50, Dowel 8, PNP and 5m cables
9120-041M-SIP-D-2915	QC-41M SIP w/PNPqk discst.snsr & cble BC100,(6)M8
9120-041M-SIP-G-1171	QC-41 Blank sensor interface plate with PNP quick-disconnect switch, no cables.
9120-043M-000-000-E	QC-43 Master Assembly, Euro
9120-043M-RF19-000	QC-43 Master with RF19 module
9120-043M-RF19W-000-SG-2877	QC-43 Master with RF19W module and SIP-G-2877
9120-043T-000-000-E	QC-43 Tool Assembly, Euro
9120-043T-RF14-000	QC-43 Tool with R14 module
9120-043T-RF14-000-E	QC-43 Tool with RF14 electrical module, Euro
9120-045Z1HT-000-000-000	QC-45Z1H Modified INSPAR Tool with (9) 1/8 NPT Air Pass-Thru Ports, (8) 1/4 NPT SS Fluid Pass-Thru Ports, TDC Bearing Race

**ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024**

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-1B-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-046AM-RF19W-AH1N12-000-0-SM	QC-46 Master, PNP Sensors with RF19W, AH1N12 modules
9120-046AM-RF19W-P188E-X7D0X7D-X7D-SM-E	QC-46 Master with RF19W, P188E, (3) X7D Modules, PNP Sensors, Euro
9120-046JT-0-0-JPC00-JJ32R14ZC2RE5	QC-46 Tool 63mm recess with R14ZC2 and RE5 modules and JPC cover
9120-046JT-P188E-0-X7G00-JJ32R14ZC2JPC	QC-46 Tool, 63mm recess with P188 Euro, X7G, and R14ZC2 modules and JPC cover
9120-046JT-RF14-AH1N12-000-0	QC-46 Base Tool Assembly, 63mm recess with RF14, AH1N12 modules
9120-046JT-RF19-P188E-X7D0X7D-X7D	QC-46 Base Tool Assembly with 63mm recess, RF19, P188E, (3) X7D Modules, Euro
9120-060BL-M-D15BLA-000	QC-60 Master, Rc Ports with D15 module w/ M2.6 screw locks
9120-060M-000-000-R	QC-60 Master no options with R Ports
9120-060M-000-000-SD-1186	QC-60 Master, no options with SIP-D to BC100, (6)M8, (2)Dowel 8 Equally spaced.
9120-060M-000-000-SD-1186-E	QC-60 Master, no options with SIP-D to BC100, (6)M8, (2)Dowel 8 Equally spaced, Euro
9120-060M-000-000-SD-1790	QC-60 Master no options, with SIP to BC 100, (6)M10, Boss 63, Dowel 8 with PNP switch & straight cables
9120-060M-000-P38AR32-SD-1790	QC-60 Master w/P38A & R32 modules w/BC 100, (6)M10, Boss 63, Dowel 8 w/PNP switch & straight cables
9120-060M-000-R32-SD-1790	QC-60 Master with R32 module w/BC 100, (6)M10, Boss 63, Dowel 8 w/PNP switch & straight cables
9120-060M-D15-000-SD-0000	QC-60 Master, D15 electrical module with SIP-D, no plate
9120-060M-D15-FN4-SD-1790	QC-60 Master with D15 and FN4 modules, SIP to BC 100, (6)M10, Boss 63, Dowel 8 with PNP quick disconnect switch & straight cables
9120-060M-K19-000-SD-1186	QC-60 Master w/K19 SIP-D to BC100, (6)M8, (2)Dowel 8
9120-060M-K26-000-SD-1186	QC-60 Master with K26 and -1186 SIP
9120-060M-K26-000-SD-1186-R	QC-60 Master with R Ports, K26 module and SIP-D to BC100, (6)M8, (2)Dowel 8 Equally spaced
9120-060M-KM14-000-SD-0000-E	QC-60 Master w/ KM14 and SIP-D Type Sensors, No Plate, Euro
9120-060M-L19-000	QC-60 Master, L19
9120-060M-SIP-A-1316	QC-60 Blank Interface Plate, robot side
9120-060M-SIP-D-0000	QC-60 Lock/unlock Sensor Interface Plate System with "D" Type (PNP) Sensors, no Interface Plate, 5m Cables
9120-060M-SIP-D-1790	SIP for QC-60M to BC 100, (6)M10, Boss 63, Dowel 8 with PNP switch & straight cables
9120-060MZZ-000-G26-E	QC-60 Master, Euro w/ B1, F1, G1, T1 Options, standard G26 Module
9120-060MZW17-000-000-E	QC-60 Master Assembly, M6 Axial Port Option, Euro
9120-060T-KG19-000-R	QC-60 Tool w/ R ports with KG19 adjustable module
9120-060T-KG19-P186R-R	QC-60 Tool, with R Ports with KG19, P186R modules
9120-060T-L19-000	QC-60 Tool, L19 Elec. module
9120-060T2-000-G21-E	QC-60T Tool w/F1, T1, W9 Options, standard G21 module, Euro
9120-061T-PORT-KIT	QC-61 Tool Checkport Kit
9120-062M-000-000-000-000-SG-1865	QC-62 Master with SIP to BC100, (6)M10, Boss 63, (2) Dowel 8 with PNP switch
9120-062M-R19WZC2RE5-P188E-000-000-SG-0000	QC-62 Master Assembly with R19WZC2, RE5, and P188E modules with SIP with "G" Type (PNP) Sensors, No Interface Plate/No Cables
9120-062M-SIP-G-0000	QC-62 PNP SIP system, no plate
9120-062M-SIP-G-1865	SIP for QC-62M to BC100, (6)M10, Boss 63, (2) Dowel 8
9120-062T-R14ZC2RE5-000-000-JPC0	QC-62 Tool side with R14ZC2 and RE5 modules, and JPC cover
9120-062T-R14ZC2RE5-000-000-JPCJPC	QC-62 Tool side with R14ZC2 and RE5 modules, and (2) JPC cover
9120-062T-R14ZC2RE5-000-000-XSCXSC	QC-62 Tool with R14ZC2 and RE5 modules and (2) XSC covers
9120-062T-R14ZC2RE5-000-JL2ER8-JPCJPC	QC-62 Tool side with R14ZC2, RE5, and ER8 modules, and (2) JPC cover
9120-062T-R14ZC2RE5-P188E-000-JPCJPC	QC-62 Tool side with R14ZC2, RE5, and P188E modules, and (2) JPC covers
9120-062T-R14ZC2RE5-P188E-000-X7G0	QC-62 Tool side with R14ZC2, RE5, P188E, X7G modules
9120-062T-R14ZC2RE5-P188E-000-X7GJPC	QC-62 Tool side with R14ZC2, RE5, P188E, X7G modules and JPC cover
9120-062T-R14ZC2RE5-P188E-000-X7GX7G	QC-62 Tool side with R14ZC2, RE5, P188E, (2) X7G modules
9120-062T-R14ZC2RE5-P188E-000-X7GXSC	QC-62 Tool side with R14ZC2, RE5, P188E, X7G and XSC cover
9120-062T-R14ZC2RE5-P188E-JL2ERC-X7GJPC	QC-62 Tool side with R14ZC2, RE5, P188E, ERC, X7G Modules and JPC Cover
9120-062T-R14ZC2RE5-P188E-JL2ERC-X7GX7G	QC-62 Tool side with four flats, R14ZC2, RE5, P188E, JL2, ERC, (2) X7G Modules
9120-062T-SE22-000-000-FR4	QC-62 Tool with SE22 and FR4 modules
9120-071M-000-000-SD-1736	QC-71 Master with No Modules, -1736 SIP
9120-071M-000-000-SD-1796	QC71 Master with no options and SIP w/PNP/ to BC160, (10) M12, Boss 100, Dowel 12
9120-071M-000-000-SD-2887	QC71 Master with no options and SIP w/PNP/ to BC 125, (6) M10, Boss 80
9120-071M-000-000-SD-4967	QC-71 Master with no options, with SIP-D to BC100, (6)M8, Recess 63, D8 with PNP lock/unlock sensors, 5m cables
9120-071M-000-D15-SD-2852	QC-71 Master with D15 module SIP and cables to ISO 100mm BC, (6) M8, NS (2) 8mm
9120-071M-D25-000-SD-2887	QC71 Master with D25 module and SIP w/PNP/ to BC 125, (6) M10, Boss 80
9120-071M-D25-X7C-SD-2887	QC-71 Master with D25, X7C Modules and SIP-D to BC125, (6) M10, Boss 80, 10 Dowel
9120-071M-D25-X7G-SD-2887	QC-71 Master with D25, X7G Modules and SIP-D to BC125, (6) M10, Boss 80, 10 Dowel
9120-071M-D25-X7G-SD-4967	QC-71 Master with D25, X7G Modules, and SIP-D to BC100, (6)M8, Recess 63, D8
9120-071M-G19-000-SD-2887	QC-71 Master with G19 module and sensor Interface Plate to BC 125, (6) M10, Boss 80
9120-071M-R19-000-SD-0000-E	QC-71 Euro Master with R19 with SIP-D no plate
9120-071M-R26-R26-SD-2852	QC-71 Master with (2) R26 electrical modules with SIP and cables to ISO 100mm BC, (6) M8, NS (2) 8mm
9120-071M-RF19-000-SD-3025	QC-71 Master with RF19 module w/ PNP sensors w/ cables, to BC90, (6) M10, (2) Dowel 10
9120-071M-RF19-000-SD-4967	QC-71 Master with RF19 and SIP to BC100 (6)M8, Recess 63, D8
9120-071M-RF19-P05-SD-4967	QC-71 Master with RF19, P05 modules, SIP-D to BC100, (6)M8, Recess 63, D8
9120-071M-RX12-RF19W	QC-71 Master with RX12, RF19W modules
9120-071M-SIP-D-0000	SENSOR COMPONENTS/ WITH D TYPE SENSORS
9120-071M-SIP-D-1199	QC-71 Master Sensor Interface Plate PNP to BC100, (6)M10, Boss 63, Dowel 8
9120-071M-SIP-D-1736	QC-71 SIP w/PNP/ to BC 80, (6) M8, Boss 50, Dowel 8
9120-071M-SIP-D-4967	SIP for BC100, (6)M8, Recess 63, D8 with PNP lock/unlock sensors, 5m cables
9120-071M-SIP-N-2925	QC-71 Master SIP to BC92, (6)M10, (2) Dowel 9 with KTH 2-wire Omron sensor
9120-071T-RF19A-000	QC-71 Tool with RF19 electrical module with the connector rotated 90 degrees.
9120-071T-RF19-RX12	QC-71 Tool with RF19 and RX12 modules
9120-071T-RX12-RF19	QC-71 Tool with RX12, RF19 modules
9120-071T2-PG1ZW13-FG2V-E	QC-71Z2 Tool with PG1ZW13, FG2V modules, Euro
9120-072BM-0000-0000-0000-SP-0000	QC-72 Master rail changer with (2) 3/8 NPT axial pass-thru ports, PNP Sensor Assy with Pico Conn
9120-072BT-0000-0000-0000	QC-72 Tool rail changer (2) 3/8 NPT axial pass-through ports in the body and no options
9120-072M-SIP-D-6487	QC-72 Master SIP with PNP quick disconnect w/5m cables to (4)M8 at 63.5 x 50, (2)Dowel 8 at 86
9120-073M-SP32W-0-PWT1-0-SG	QC-73 Master with SP32W, PWT1 Modules and PNP Lock/Unlock/RTL sensors wired
9120-075T-1585	QC-75 Laser Scanner Tool
9120-076AM-000-R26R-SE-8622-R	QC-76 Master with no Boss, Rc Ports with R26R Module and NPN Sensors with IP to BC80, (6)M8, Boss 50, Dowel 8
9120-076AM-ES6RF19R-ES7-SG-4492	QC-76 M w/no Boss w/ ES6, RF19R and ES7, PNP lock/unlock sensors with IP to BC100, (6)M8, Boss 63, Dowel 8
9120-076AM-FR4-000-SFR-R	QC-76 Rc Master, FR4, Q/D NPN Lock/UnLock Sensors with 5M 90 Degree Cables
9120-076AM-P05-R32-SFR-R	QC-76 Master Assembly with Rc Ports, P05, R32 modules, Q/D NPN Lock/UnLock Sensors with 5M 90 Degree Cables
9120-076AM-R19MT9-000-SDR-7625	QC-76 Master, No Boss with R19 and MT9 modules and IP, PNP Lock/UnLock sensors with 5m cables
9120-076AM-RF19W-000-SG-E	**SPECIAL PART CONFIGURATION** - This is non standard and the cable extension is required! (9120-C-3PM-3PF90-0025 Included) Please discuss with Apps before quoting -- QC-76 Master Assembly with no boss, RF19W Module, Q/D PNP Lock/UnLock Sensors (Wired Modules Only), Euro
9120-076FM-000-R19PD-SDR	QC-76 Master Assembly with 80mm boss, with R19PD Module and Q/D PNP Lock/UnLock Sensors with 5M 90 Degree Cables
9120-076FM-TB-000-SDR	QC-76 Master Assembly with 80mm boss, TB module, Q/D PNP Lock/UnLock Sensors with 5M 90 Degree Cables
9120-076FM-TB-000-SG-E	QC76 Master with 80mm Boss, PNP Lock/Unlock (Wired Modules Only), w/ TB, Euro
9120-076FM-TB-FN2-SDR	QC-76 Master Assembly with 80mm boss, with TB, FN2 Modules and Q/D PNP Lock/UnLock Sensors with 5M 90 Degree Cables
9120-076FMZ3-RF19PD-000-SG-E	QC-76 Master Euro, 80mm Boss, with RF19PD Module, PNP L/U (Wired Modules Only), Tungsten Carbide Balls, Stainless Steel Fasteners, TDC Locking Mechanism and Alignment Pins, Viton Seals

### ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TB-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-076M-ZB1F2T1-000-000-SDR-E	QC76M, 80mm Boss, Carbide Balls, SS Fast., TDC, PNP Quick-Disconnect 5M 90 Degree cables Euro
9120-076FT-000-R19PD	QC-76 Base Tool Assembly, NPT, 80mm Recess, with R19PD
9120-076FT-ES6RF19-ES7	QC-76 Tool with 80mm Recess with ES6, RF19, and RF19
9120-076FT-FR4-000-R	QC-76 Rc Tool, FR4
9120-076FT-R19MT9-000	QC-76 Tool, 80mm Recess, R19 and MT9 electrical modules
9120-076FT-TB-000	QC-76 Base Tool Assembly, 80mm Recess, TB
9120-076FT-TB-000-E	QC-76 Base Tool Assembly, 80mm Recess, TB, Euro
9120-076FT-TB-FN2	QC-76 Base Tool Assembly, 80mm Recess with TB, FN2 Modules
9120-076FTZF2T1-TB-P48-E	QC-76 Base Tool Assembly, 80mm Recess, SS Fast. TDC, TB and P48 modules, Euro
9120-076FTZT1-000-RF19PD-R	QC-76 Base Tool Assembly with TDC with RF19PD, 80mm Recess with R Ports
9120-077Z1-FG4	QC-77Z1 Tool Assembly, No Ports, TDC Bearing Race, 303 SS Body, FG4
9120-078M-000-000	QC-78 Master, (16) 1/8 NPT Air Ports, No Options
9120-078M-000-TP-SD-1796-E	QC-78 Euro Master, TP, PNP sensors w/ 5m cables, to with SIP BC160, (10)M12, Boss 100, Dowel 12
9120-078M-TP-000-SG-9186-E	QC-78 Euro Master, TP on Flat A, PNP sensors w/ no cables to BC160, (11)M12, Boss 100, Dowel 12 w/ prox clearance
9120-078M-TPD-000-SG-9186-E	QC-78 Master with TPD module, PNP sensors with IP-9186, Euro
9120-078T-000-000-E	QC-78 Tool, (16) 1/8 BSPP Air Ports, No Options, Euro.
9120-078T-000-TPZC7-E	QC-78 Euro Tool with TPZC7 module
9120-078T-TPD-000-E	QC-78 Tool with TPD module, Euro
9120-078T-TPZC7-000-E	QC-78 Euro Tool, TPZC7 on A Flat
9120-100BL-M-000-000	QC-100BL Master, no options
9120-100BL-M-J16A-J16B	QC-100BL Master with J16A, J16B Modules
9120-100BL-T-000-000	QC-100BL Tool, no options
9120-100M-000-000	QC-100 Master, No Options, Orange
9120-100M-000-000-E	QC-100 Master, Euro, No Options
9120-100M-000-000-E-V	QC-100 Master, No Opt., Euro, Viton Seals
9120-100M-000-000-I	QC-100 Master "I", rubber bushings on master, no options
9120-100M-C5-000-I	QC-100 Master w/C5 Electrical Module, Extrusion
9120-100M-C5-000-I-SG-1382	QC-100 "I" Master, C5, PNP sensors w/ no cables with IP to BC125, (6) M10, Boss 80, Dowel 10
9120-100M-IP-1119	IP Ass'y for 100M to BC125, (6)M10 Low-head, (2)D 10
9120-100M-L26-000	QC 100 Master w/ L26 elec. mod.
9120-100M-M19-000	QC-100 Master, M19 Elec. Module
9120-100M-R18LW-000-I	QC100MI w/ (AR) R18LW, Lock Cable Only
9120-100M-R19-000-E	QC-100 Master w/ R19 Elect. Mod., Euro
9120-100M-R19-000-SD-1145	QC-100 Master with R19 module with SIP-D to ISO 125 mm BC, (6) M10, and (2) 10mm dowel pins
9120-100M-R19W-000-SG-2820	QC-100 Master with R19W Module, Lock/unlock SIP with PNP quick-disconnect prox. sensors to BC100, (5)M8, Boss63, Dowel 8mm
9120-100M-R26-000	QC-100 Master w/ R26 electrical module
9120-100M-R26-R26	QC-100 Master with (2) R26 modules
9120-100M-R26W-000-SG-1382	QC100 Master w/R26 mod. lock/unlock sensor cables, SIP to BC125(6)M10 Boss 80 D10
9120-100M-S19-000	QC-100 Master w/ S19 module
9120-100M-S19-000-I	QC-100 "I" Master w/ S19 module
9120-100M-SEALS	QC100 Master Seal Kit
9120-100M-SEALS-E	QC100 Master Seal Kit Euro
9120-100M-SIP-0-0000	QC-100 Sensor Plate w/o sensors/IP
9120-100M-SIP-0-0000-V	QC-100 Sensor Plate w/o sensors/IP with Viton seals
9120-100M-SIP-C-0000	QC-100 Lk/Unlk Sensor C, no plate
9120-100M-SIP-D-1145	QC-100 Lk/Unlk PNP, 125BC (6) M10, (2) 10mm dowel
9120-100M-SIP-E-1145	QC-100 Lock/Unlock SIP, NPN qk. disconnect, no cable
9120-100M-SIP-G-0000	SIP with PNP sensors, no cables, no interface plate
9120-100M-SIP-G-1382	QC100 SIP, PNP to 125mm BC
9120-100M-SIP-G-2820	QC-100 Lock/unlock SIP with PNP quick-disconnect prox. sensors to BC100, (5)M8, Boss63, Dowel 8mm
9120-100M-T19-000	QC-100 Master with T19 electrical module
9120-100M-T19-000-I	QC-100 "I" Master with T19 electrical module
9120-100M-T19-000-SG-2830	QC-100 Master with T19 electrical module with SIP-G to Kuka robot #KR210L150
9120-100M-T19-FN2-I	QC-100 Master w/T19 and FN2 modules, "I" version
9120-100M-T19W-000-I	QC-100 "I" Master with T19W module
9120-100T-000-000	QC-100 Tool no options
9120-100T-000-000-C	QC-100 Tool "C" Style
9120-100T-000-000-E	QC-100 Tool, no options, Euro
9120-100T-000-000-I4	QC-100 Tool, no options, Extrusion ISA 4 pin
9120-100T-C10I-000-C	QC-100 "C" Tool w/ 2 C5 elect conn w/ int jumper (C3)
9120-100T-C3-000-I4	QC-100 Tool I4 Version with C3 Module
9120-100T-C5-000-I4	*QC-100 "I4" Tool w/ 5-pin output to 5-pin connect
9120-100T-FN2-000	QC-100 Tool with FN2 pneumatic module
9120-100T-L26-000	QC-100 Tool w/ L26 module
9120-100T-M19-000	QC-100 Tool, MS 19-pin electrical module
9120-100T-R13-000	QC-100 Tool with R13 module
9120-100T-R17-000	QC-100 Tool with R17 Module
9120-100T-R18-000-C	QC-100 "C" Tool with (AR) R18 Module
9120-100T-R19-000	QC-100 Tool w/ R19 module
9120-100T-R19-000-E	QC-100 Tool w/ R19 Elect. Mod., Euro
9120-100T-R26-000	QC-100 Tool w/ R26 electrical module
9120-100T-R26-H10-E	QC-100 Tool with R26 and H10 modules, Euro
9120-100T-R26-R13	QC-100 Tool with R26 & R13 electrical modules
9120-100T-S14-000-C	QC-100 "C" Tool w/ S19 Elect.Mod.w/Tool-ID inside
9120-100T-S19-000	QC-100 Tool w/ S19 Electrical Module
9120-100T-SEALS	QC100 Tool Seal Kit
9120-100T-T10-000-C	QC-100"C" Tool w/T19 w/ 2 internal Tool-ID
9120-100T-T10-000-I4	QC100 "I4" Tool w/T19 mod (2) Tool-ID button, 10 pin
9120-100T-T14-000	QC-100 Tool w/ 19 pin, 3A/250V, int. Tool-ID
9120-100T-T19-000	QC-100 Tool side with T19 electrical module
9120-100T-T19-000-C	QC-100 Tool "C" style w/ 19-pin, 5A/250VAC
9120-100T-T19-000-E	QC-100 Tool w/ T19 electrical module, Euro
9120-110AM-000-000-ST-4556	QC-110 NPT Master, no boss, PNP sensors w/ cables & IP to BC160,(9)M12,Boss100,Dowel 12 (with flats)
9120-110AM-0G19RMT9-FN2-SM	QC-110 NPT Master, no boss, w/G19R, MT9, FN2 modules, PNP sensors
9120-110AM-GB8AGB8AS26W-S26S26MTR14-SM1	QC-110 Master with no Boss with (2)GB8A, S26W, (2)S26, MTR14 modules, and PNP Sensors with 0.2m Hardwired, Straight M8 Connector
9120-110AM-MT8-TPS-S0	QC-110 NPT Master, no boss with MT8, TPS modules, dummy plugs
9120-110AM-MT8-TPS-SM	QC-110 NPT Master, no boss with MT8, TPS modules, PNP sensors
9120-110AM-R19R32R-000-SP-R	QC-110 Master Assembly with No Boss, R19 and R32R Modules, NPN Sensors, Rc 1/4 Ports
9120-110AM-R19R-GB8-SM-8756	QC-110 Master with R19R and GB8 modules, lock/unlock sensor cables attached, PNP sensors, IP to BC100, (4)M10, Boss 40, Dowel 10 (Omega160-Standard TAP)
9120-110AM-R26R-000-SM-R	QC-110 Master, no boss, R26 Module and PNP sensors with R Ports
9120-110AM-RE5R19R-FR2-SM-R	QC-110 Master with no Boss, RE5, R19R, FR2 modules, PNP sensors with R Ports

## ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TB-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-110AM-RF19R-000-SM-4333	QC-110 NPT Master, no boss, w/RF19R, Robot interface plate, PNP sensors
9120-110AM-RF19R-000-SM-4556	QC-110 Master with no boss, RF19R module, PNP sensor to BC 160, (9) M12, Boss 100, Dowel 12
9120-110AM-RF19R-000-SM-R	QC-110 Master with no Boss, R19R module, PNP and BSPT ports
9120-110AM-RF19R-000-SP-R	QC-110 Master with RF19R module, NPN lock/unlock sensors and BSPT ports
9120-110AM-RF19R-MT9-SM	QC-110 master with PNP lock/ unlock sensors, RF19R and MT9 modules
9120-110AMZU1-R19RVS-000-SM	QC-110 Master with no boss, Viton Seals, R19RVS module and PNP Sensors
9120-110FM-000-000-ST-R	QC-110 Master with 80mm Boss and PNP lock/unlock Sensors with 5m cable with R ports
9120-110FM-JJ91MT9R19R0JL1ES19S1-JJ48TMB0JL1ES19S1-SM	QC-110 Master with 80mm Boss, JJ91, MT9, R19R, (2) JL1, (2) ES19-S1, JJ48 and TMB Modules, and PNP lock/unlock sensors
9120-110FM-MTA5-000-ST	QC-110 Master with 80mm Boss, MTA5, Module and PNP lock/unlock sensors with 5m cables
9120-110FM-MTB8RB26-RD26-ST-E	QC-110 Master with 80mm Boss, w/MTB8, RB26, RD26 and PNP lock/unlock sensors with 5m cables
9120-110FM-R19R-JL1ES9Z2-SM	QC-110 Master w/80mm Boss, R19R, ES9Z2 Modules and PNP lock/unlock sensors, no cables
9120-110FM-R19R-TB-SM	QC-110 Master with 80mm Boss w/R19R, TB modules, PNP lock/unlock sensors no cables
9120-110FM-R19RVS-000-V-SM	QC-110 NPT Master, Viton, 80mm boss, with R19RVS, PNP sensors
9120-110FM-R32R-TB-SM	QC-110 Master with 80mm Boss, R32R, TB modules, PNP lock/unlock sensors no cables and no other options
9120-110FM-T19RVS-000-SM	QC-110 Master w/80mm Boss, T19R module w/Viton seals & Teflon jacket wires, PNP sensors
9120-110FM-TB-000-ST	QC-110 Master w/80mm Boss with TB module and PNP lock/unlock sensors with 5m cables
9120-110FM-TB-FN2-ST	QC-110 Master w/80mm Boss with TB and FN2 modules and PNP lock/unlock sensors with 5m cables
9120-110FM-TB-P38AEP38AE-SM-E	QC-110 Master w/80mm Boss, w/ TB, P38A, P38A, PNP lock/unlock sensors no cables
9120-110FM-TPD-TB-ST	QC-110 Master with 80mm Boss, TPD and TB modules, and PNP lock/unlock sensors with 5m cables
9120-110FMZG2-000-R26-SM-E	Custom QC-110 Master with 80mm Boss, Food Grade Grease (DuPont Molykote G-4500), no Boss, R26 module, and PNP Sensors, Euro G 3/8" (BSPP)
9120-110FT-000-000-R	QC-110 Tool with 80mm Recess; Rc(BSPT) ports; no other options
9120-110FT-000-TPS	QC-110 Tool, 80mm Recess with TPS module
9120-110FT-JJ110DB10-C15C	QC-110 Tool with 80mm Recess, JJ110, DB10 and C15C modules
9120-110FT-JJ91MT9R19R0JL1ES19S1-JJ48TMB0JL1ES19S1	QC-110 Tool with 80mm Recess with JJ91, MT9, R19, (2) JL1, (2) ES19-S1, JJ48 and TMB modules
9120-110FT-MT8-TPS	QC-110 Tool, 80mm Recess, MT8 & TPS modules
9120-110FT-MTA5-000	QC-110 Base Tool Assembly, NPT, MTA5 Module
9120-110FT-R19-JL1ES9Z1	QC-110 Base Tool Assembly, NPT, 80mm Recess, R19, ES9Z1 Modules
9120-110FT-R19PD-RE10	QC-110 Tool with 80mm recess and R19PD and RE10 module
9120-110FT-R19R32-000-R	QC-110 Tool with 80mm Recess, R19 and R32 Modules, Rc (BSPT) ports
9120-110FT-R19-TB	QC-110 Tool with 80mm Recess with R19, TB Modules
9120-110FT-R26-000-R	QC-110 Base Tool Assembly, NPT, 80mm Recess with R26 Module Tool Side, R Ports
9120-110FT-R32-TB	QC-110 Base Tool Assembly, NPT, 80mm Recess with R32 and TB Modules
9120-110FT-RE5R14-FR2-R	QC-110 Tool with 80mm recess, RE5, R14 and FR2 modules with R Ports
9120-110FT-RF19-000-R	QC-110 Tool with 80mm Recess; Rc BSPT) ports with RF19 module
9120-110FT-RF19-MT9	QC-110 Tool with 80mm Recess with RF19, MT9 modules
9120-110FT-RW10-000	QC-110 Tool with 80mm Recess and RW10 electrical module
9120-110FT-TB-000	QC-110 Tool with 80mm Recess with TB module
9120-110FT-TB-FN2	QC110 Tool with 80mm Recess with TB and FN2 modules
9120-110FT-TB-P38AEP38AE-E	QC-110 Base Tool Assembly, NPT, 80mm Recess, Euro w/TB, (2)P38AE modules
9120-110FT-TPD-TB	QC-110 Tool with 80mm Recess, TPD and TB modules
9120-110M-IP-4333	QC-110 Robot Interface Plate to BC160, (6) or (10)M10, Boss 100, (2) D10
9120-110M-IP-4540	QC-110 Robot Interface Plate Kit. IP. QC-110M to BC160, (6)M10, Boss 80, (2)Dowel 10
9120-110M-IP-4556	QC-110 IP to B.C. 160, (9) of (11)M12, Boss 100, Dowel 12 (with flats)
9120-110M-IP-4788	QC-110 Robot Interface Plate to BC 160mm, (6)M10, Boss 100, (2) Dowel 10 and Flat for MT8 module
9120-110M-IP-5990-IP65	Interface plate Kit from Omega160-IP65 TAP to QC-110 Master
9120-110M-IP-8756	IP for QC-110M to BC100, (4)M10, Boss 40, Dowel 10 (Omega160-Standard TAP)
9120-150BL-M-000-000	QC-150BL Master, R 3/8 Ports, no options.
9120-150BL-M-000-H19	QC-150BL Master, R 3/8 Ports with H19 module
9120-150BL-M-KF38D37-000	QC150BL Master with (2) KF19 on adaptor plate
9120-150BL-M-R4-000	QC-150BL Master, R 3/8 Ports, with R4 module
9120-150BL-T-000-000	QC-150BL Tool, R 3/8 Ports, no options
9120-150BL-T-000-H19	QC-150BL Tool, R 3/8 Ports with H19 module
9120-150BL-T-KF38D37-000	QC-150BL Tool Side, with (2)KF19s on Adaptor
9120-150BL-T-R4-000	QC-150BL Tool, R 3/8 Ports, with D37 module
9120-150M-000-000	QC-150 Master, no options
9120-150M-000-000-E	QC-150 Master, no options, Euro
9120-150M-000-000-SD-1198	QC-150 Master with SIP D to BC 125, (6) M10, Boss 80, Dowel 10
9120-150M-000-000-SD-1721	QC-150 Master with SIP 1721
9120-150M-000-000-SD-1783	QC-150 Master w/SIP PNP Assembly w/5m cbils to BC160, (10)M12, Boss 100, Dowel 12
9120-150M-000-000-SD-2947-E	QC-150 Master, Euro w/ SIP-D to BC160 (11)M12, Boss 100, D12
9120-150M-000-000-SG-0000	QC-150 master, no options, Lock/Unlock Sensor G(PNP), no interface plate, no cables
9120-150M-000-000-SG-0000-E	QC-150 master, no options, Lock/Unlock Sensor G(PNP), no interface plate, no cables, Euro
9120-150M-000-000-SG-1198	QC-150 Master with SIP-G to BC125, (6)M10, Boss80, Dowel 10
9120-150M-000-000-SG-1783	QC-150 Master with SIP to BC160, (10)M12, Boss 100, Dowel 12, PNP sensors and no cables
9120-150M-000-000-V	QC-150 Master, no options, Viton
9120-150M-000-D25	QC-150 Master with D25 Master Signal Module
9120-150M-000-R19W-SG-1169-E	QC-150 Master with R19W Module and LUL Sensing Kit, Euro with SIP 1169, PNP, No Cables
9120-150M-000-RF19W-SG-1704-E	QC-150 Master with RF19W with SIP to BC200,(6)M12,Boss125,D12, Euro
9120-150M-000-TB-S0-0000-E	QC-150 Master with TB module, Sensor Plate without sensors, Euro
9120-150M-0-V200AFN2-SG-1721	QC-150 Master with V200A, FN2 modules and PNP LUJ sensor interface plate
9120-150M-E50Z-J16	QC-150 Master w/BLA E50Z Earth contact, 16-pin, 5A/250VAC, miniature MS quick-disconnect connector
9120-150M-E50Z-J16-SD-4998	QC-150 Master with E50Z and J16 w/SIP to BC85, (6)M10, (2)Dowel 10
9120-150M-FN2-R26W	QC150 Master w/26-pin mod wired for lock/unlock & SS fluid/air mod w/(2) 3/8 NPT self-seal ports
9120-150M-G19-000	QC-150 Master with G19 electrical module
9120-150M-G19-FN2	QC-150 Master with G19 module with 5 position swivel and FN2 Stainless steel fluid/air module.
9120-150M-G19W-000-SG-1721	QC-150 Master with G19W and SIP to BC160, (9) of (11)M12, Boss 100, D12
9120-150M-G26-G26-SD-0000-E	QC-150 Master with (2) G26 electrical modules, with PNP sensors 5m cables, No SIP plate, Euro
9120-150M-G26-G26-SD-1870-E	QC-150 Master with (2) G26 electrical modules, SIP D to BC80, (6)M8, Boss 50, Dowel 8, Euro
9120-150M-G26-RE10	QC-150 Master with G26 and RE10 modules
9120-150M-J16-000	QC-150 Master w/ J16 electrical module
9120-150M-J16-000-SD-4998	QC-150 Master w/ J16 electrical module with SIP Assy to BC85, (6)M10, (2)Dowel 10
9120-150M-JJ55R32WR26-P16M5-SG-0000	QC-150 Master with Lock/Unlock SIP G(PNP), no interface plate, JJ55, R32W, R26, P16M5 Modules
9120-150ML1	Manual Lifting Connector for QC-150 or QC-210
9120-150M-M19-000-E	QC-150 Master, M19 Euro
9120-150M-R19-000	QC 150 Master w/ R19 elec mod.
9120-150M-R19-000-E	QC-150 Master Euro w/ 19 pin 5A/250V elect. mod.
9120-150M-R19-000-SG-0000-E	QC-150 master, R19 module, Lock/Unlock Sensor G(PNP), no interface plate, no cables
9120-150M-R19-R19	QC 150 Master w/ (2) R19 electrical modules
9120-150M-R19W-000-SE-1149	QC-150 Master with R19W with SIP-E to BC125, (6) M10, Boss 63, Dowel 10 (UP200)
9120-150M-R19W-R32-SE-1149	QC-150 Master with R19W, R32 Modules and SIP 1143
9120-150M-R26-000-SD-1198	QC-150 Master, R26, PNP sensors with 5m cables and plate to BC125, (6) M10, Boss 80, Dowel 10
9120-150M-R26-000-SD-1782	QC-150 Master, R26, PNP sensors with 5m cables and plate to BC100, (6)M10, Boss 63, Dowel 8

## ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TE-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-150M-R26-000-SD-5032	QC-150 Master with and SIP to BC150, (7) of (8)M10, PNP Sensors w/ 5M cables
9120-150M-R26W-000	QC-150 Master w/ MS 26-pin 3A/250VAC elect
9120-150M-R26W-000-SG-0000-E	QC-150 Master with R26W Module and lock/unlock Sensing Kit, Euro
9120-150M-R26W-000-SG-1198	QC-150 Master with R26W module and SIP-G to BC125, (6)M10, Boss80, Dowel 10
9120-150M-R26W-000-SG-1721	QC-150 Master with R26W Module and SIP-G to BC160,(9)M12,Boss100,D12
9120-150M-R26W-000-SG-1757	QC150 Master with R26W module and SIP to BC160, (6)M10, Boss 100, D10
9120-150M-R26WR32-000-SG-1721	QC-150 Maser with R26W, R32 modules with SIP to BC160,(9)M12,Boss100,D12
9120-150M-R32S1-000-SF-1198	QC-150 Master w/R32-S1 with SIP-F to BC 125, (6) M10, Boss 80, Dowel 10
9120-150M-R32W-000-SE-1198	QC-150 Master with R32 module and SIP to BC 125, (6) M10, Boss 80, Dowel 10 NPN
9120-150M-R32W-R19-SG-1198	QC-150 Master with R32W, R19 Modules and SIP-G to BC125, (6)M10, Boss80, Dowel 10
9120-150M-R32ZC5PD-000-SF-1198	QC-150 Master w/R32ZC5PD module w/SIP-F to BC 125, (6) M10, Boss 80, Dowel 10
9120-150M-R52W-FN2	QC150 Master w/(1) R26 module, (1) R26 module wired for lock/unlock sensors.FN2 SS fluid/air mod
9120-150M-R52W-FN2-SG-2903	QC150 Master w/ R26W, R26, and FN2 modules with SIP to BC 125 w/ (10) M10 SHCS, boss 10
9120-150M-RE5RF5-FN2-SG-1721	QC-150 Master w/RE5, RF5, FN2 and SIP-G to BC160, (9) of (11)M12, Boss100, Dowel 12
9120-150M-RF19-000	QC-150 Master with RF19 Electrical Module
9120-150M-RF19W-000	QC-150 Master with RF19 wired for L/U sensors
9120-150M-RF19W-000-SG-1721	QC-150 Master with RF19W with SIP to BC160, (9) of (11)M12, Boss 100, D12
9120-150M-SEALS	QC150 Master Seal Kit
9120-150M-SEALS-E	QC150 Master Seal Kit Euro
9120-150M-SIP-0-0000	QC-150 Sensor Plate w/o sensors/IP
9120-150M-SIP-D-0000-A	QC-150 Lock/Unlock Sensor D(PNP), no interface plate, Prox in flat A
9120-150M-SIP-D-1721	QC-150 Master Lock/Unlock sensor interface plate PNP Quick Disconnect to BC160, (9)M12, Boss100,D12
9120-150M-SIP-D-1782	QC-150M (US) SIP to BC100, (6)M10, Boss 63, Dowel 8 with PNP Quick-Disconnect switch with 5m cables
9120-150M-SIP-D-1783	QC-150M (US) SIP to BC160, (10)M12, Boss 100, Dowel 12 with PNP Quick-Disconnect switch w/5m cables
9120-150M-SIP-G-0000	QC-150M SIP COMPONENTS, NO CABLES
9120-150M-SIP-G-0000-B	QC-150 Lock/Unlock Sensor G(PNP), no interface plate, no cables, Prox in flat B
9120-150M-SIP-G-1721	SIP PNP Ass'y-QC150M to BC160,(9) of (11)M12,Boss100,D12
9120-150M-SIP-G-1783	QC-150M (US) SIP to BC160, (10)M12, Boss 100, Dowel 12 w/ PNP sensors wired into signal module/No Cables
9120-150M-SIP-G-1826	QC-150 SIP to BC200, (12)M16, Boss 125, D12 with PNP sensors wired into signal module
9120-150M-SIP-G-2808	QC-150 SIP BC160, (6) M10, Boss 100, D10
9120-150M-SIP-P-0000	SIP Assembly for QC-207, No Plate, PNP Sensors with 2m Cable and M8 Connectors
9120-150M-T19-000	Quick Change 150 Master w/ T19 elec. mod.
9120-150M-T19V-000-V	QC-150 Master w/Viton seals & w/T19 w/Viton seals
9120-150M-T19W-000	QC-150 Master w/ 19 pin, 5A/250 VAC module
9120-150M-T19W-000-SG-1149	QC 150 Master with T19W module, PNP sensors and SIP-1149
9120-150M-TB-000-SD-1149	QC-150 Master, TB module,with SIP to BC125mm, (6)M10, Boss 63, PNP
9120-150M-TE-000	QC-150 Master with TE module
9120-150M-TE-000-S0-0000-E	QC-150 Master with TE module w/ Sensor Plate w/o sensors/IP, Euro
9120-150T-000-000	QC-150 Tool, no options
9120-150T-000-000-E	QC-150 Tool, no options, Euro
9120-150T-000-000-V	QC-150 Tool, no options, Viton
9120-150T-000-BPS26-E	QC-150 Tool with BPS26 module, Euro
9120-150T-000-D25	QC-150 Tool with D25 Tool Signal Module
9120-150T-000-J16	QC150 Tool with J16, 16-pin 5A/250V electrical module on B Flat
9120-150T-000-R19-E	QC-150 Tool with R19 module on flat B, Euro
9120-150T-000-R26-E	QC-150 Tool, R26 modules, Euro
9120-150T-000-RF19-E	QC-150 Tool with RF19 electrical module, Euro
9120-150T-000-TB-E	QC-150 Tool with TB module, Euro
9120-150T-E50Z-J16	QC-150 Tool w/E50Z and J16
9120-150T-G19-000	QC-150 Tool and G19 electrical module with five position swivel.
9120-150T-G19-FN2	QC-150 Tool with G19 module with 5 position swivel and FN2 Stainless steel fluid/air module.
9120-150T-G26-000	QC-150 Tool with G26 Electrical Module
9120-150T-G26-R17-E	QC-150 Tool with G26 & R17 modules, Euro
9120-150T-G26-RE10	QC-150 Tool with G26 and RE10 modules
9120-150T-GF14-G5	QC-150 Tool with GF14 and G5 Modules
9120-150T-J16-000	QC-150 Tool, w/ J16 electrical module
9120-150T-JJ55R32R26-P16M5	QC-150 Tool with JJ55, R32, R26 and P16M5 Modules
9120-150T-JL7ES8-JJ32R26JPC-E	QC-150 Tool, ES8, and R26 modules, JPC cover, Euro
9120-150T-JL7ES8-R26-E	QC-150 Tool, ES8 and R26 modules, Euro
9120-150T-JL7ESC-JJ32R26JPC-E	QC 150 Tool with ESC cover, R26 module and JPC cover, Euro
9120-150T-JL7ESC-JJ32R26R32-E	QC-150 Tool, ESC cover and R26 and R32 module, Euro
9120-150T-JL7ESC-R26-E	QC-150 Tool, ESC cover and R26 module, Euro
9120-150T-JPC0-TB-E	QC-150 Tool with JPC Protective Cover, TB module, Euro
9120-150T-M19-000-E	QC-150 Tool, M19 Euro
9120-150T-R14-000	QC 150 Tool w/ R14 electrical module.
9120-150T-R14-R32	QC 150 Tool w/ R14 and R32 Electrical Modules
9120-150T-R17-000	QC-150 Tool with R17 electrical module
9120-150T-R17-FG2-E	QC-150 Tool with R17 & FG2 modules, Euro
9120-150T-R19-000	QC-150 Tool with R19 module
9120-150T-R19-000-E	QC-150 Tool Euro w/ 19 pin 5A/250V elect. mod.
9120-150T-R19FG2-000-E	QC-150 Tool Euro with R19 and FG2 modules
9120-150T-R19-R19	QC-150 Tool with (2) R19 modules
9120-150T-R19-R19-E	QC-150 Tool with (2) R19 modules, Euro
9120-150T-R19R19-JPCJPCJPC-E	QC-150 Tool Euro w/ (2) R19 and (3) JPC modules
9120-150T-R21R32-000	QC-150 Tool with R21, R32 modules
9120-150T-R21R32-MT8	QC 150 Tool with R21, R32 & MT8 modules
9120-150T-R26-000	QC-150 TOOL WITH R26 MODULE
9120-150T-R26-000-E	QC-150 Tool w/ R26 Module Euro
9120-150T-R26R26-000	QC150 Tool Side with (2) R26 Modules
9120-150T-R26-R26-E	QC-150 Tool with (2) R26 Modules, Euro
9120-150T-R26VL-R19VLMT8V-E	QC-150 Tool with R26VL, R19VL, MT8V Modules, Euro
9120-150T-R32-000	QC 150 Tool with32-pin, 5A/250VAC, Ms miniature MS quick-disconnect connector
9120-150T-R32-R19	QC-150 Tool with R32, R19 Modules
9120-150T-R32-R26	QC-150 Tool, no options, with R32 and R26 modules
9120-150T-R32S1-000	QC-150 Tool with R32-S1 module
9120-150T-R32ZC6A-000	QC-150 Tool with R32ZC6A module
9120-150T-R4-000	QC-150 Tool with R4 electrical module
9120-150T-R47-FN2	QC150 Tool with R21 with Tool-ID 0-9 and R26 module and FN2 stainless steel fluid/air module
9120-150T-R52-000-R	QC-150 Tool with R Ports and R52 module
9120-150T-R52-P186R-R	QC-150 Tool with R Ports and R52, P186R modules
9120-150T-RE5RF5-FN2	QC-150 Tool with RE5, RF5, FN2 modules
9120-150T-RF10-000	QC-150 Tool with RF10 module with M16 connector & Tool-ID 0-99
9120-150T-RF19-000	QC-150 Tool with RF19 Module
9120-150T-RF19RF19-000-R	QC-150 Tool with (2) RF19 modules and R Ports

## ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TE-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-150T-SE24-V200AFN2	QC-150 Tool with SE24, V200A and FN2 modules
9120-150T-SEALS	QC150 Tool Seal Kit
9120-150T-T14-000	QC-150 Tool w/ 19 pin 3A/250VAC module, Tool-ID
9120-150T-T14-000-V	QC150T w/ T14 mod w/ int Tool-ID & viton seals
9120-150T-T14-TD	QC-150 Tool with T14 and TD
9120-150T-T19-000	Quick Change 150 Tool w/ T19 elec. mod.
9120-150T-TB-000	QC-150 Tool, TB module
9120-150T-TE-000	QC-150 Tool with TE Module
9120-150T-TE-000-E	QC-150 Tool with TE Module, Euro.
9120-160AMZB1F1T1-000-000-S0-E	(USE 9120-160AMZW25-000-000-SM-E FOR NEW CUSTOMERS OR APPLICATIONS) QC-160 Master, Carbide Locking Balls, Stainless Steel Fasteners, TDC Locking Mechanism and Alignment Features, Euro, Dummy Sensors
9120-160AMZB1F1T1-000-000-ST-E	QC-160 Master, Carbide Locking Balls, Stainless Steel Fasteners, TDC Locking Mechanism and Alignment Features, Euro., PNP Sensors, 5m Cables
9120-160FM-0MTC90-0TP0-SM	QC-160 Master Base Assembly with 80mm Boss w/MTC9, TP modules and PNP sensors
9120-160FM-0TPS0-0P1860-ST	QC-160 Master Base Assembly, 80 mm Boss, TPS, P186 modules and PNP Sensors with 5m Cables
9120-160FM-TPS00-000-ST	QC-160 Master Base Assembly, 80 mm Boss, TPS module, PNP Sensors with 5m Cables
9120-160FT-0MTC90-0TP0	QC-160 Tool Base Assembly, 80mm Recess, NPT with MTC9, TP modules
9120-160FT-0R320-0JL7ES80-E	QC-160 Tool Base Assembly, Euro with 80mm Recess, BSPP with R32, JL7, ES8 modules
9120-160FT-0R320-0JL7ESCO-E	QC-160 Tool Base Assembly, Euro with 80mm Recess, BSPP with R32, JL7, ESC modules
9120-160FT-0TB0-000	QC-160 Tool Base, 80 mm Recess w/TB Module
9120-160FT-0TB0-000-E	QC-160 BSPP Tool with 80mm recess and TB module
9120-160FT-0TPS0-0P1860	QC-160 Tool Base Assembly, 80mm Recess, with TPS, P186 Modules
9120-160FT-R14ZC20RE5-JPC00	QC-160 Tool Base Assembly with R14ZC2, RE5 and JPC Cover
9120-160FT-R14ZC20RE5-JPC0JPC	QC-160 Tool with 80mm recess, R14ZC2, and RE5 modules, and (2) JPC covers
9120-160FT-R14ZC20RE5-X7G00	QC-160 Tool Base Assembly with R14ZC2, RE5 and X7G Modules.
9120-160FT-R14ZC20RE5-X7G0X7G	QC-160 Tool with 80mm recess, R14ZC2, RE5, and X7G modules
9120-160FT-TPS00-000	QC-160 Tool Base Assembly, 80mm Recess, TPS module
9120-160FTZF1T1-0NS120-000-E	QC-160 Tool Base Assembly, Stainless Steel Fasteners, TDC Bearing Race and Alignment Bushings, NS12 module, Euro.
9120-160M-IP-4540	QC-160 Robot Interface Plate Kit for BC160, (6)M10, Boss 80, Dowel 10
9120-204H3M-000-000-000-000	QC-204 Master, (3) Hydraulic Fittings
9120-207BM-0000-0000-0000-0000-SP-0000	QC-207B Master with PNP sensor assembly with Pico Connector
9120-207M-0000-0000-0000-0000-SP-0000	QC-207 Master w/(5) 1/4NPT. Larger alignment pins, PNP SIP Cable, Pico Conn Ass'y, NoPlate
9120-300M-000-000-000-000-E0	QC-300 Master with no options and no electrical or ready-to-lock sensor
9120-300M-000-000-000-000-E0-B	QC-300 MASTER FOR EUROPE
9120-300M-000-000-000-000-E0-B-V	QC-300 Master black body with viton seals rated to 125 degrees C
9120-300M-000-EL8-R26VL-R26VL-E0-B-V-S0-0000-V	QC-300 Master black body with viton seals, EL8, (2)R26VL modules w/SIP Assembly
9120-300M-000-TP-000-000-E0-B-V-S0-0000-V	QC-300 Master with viton seals, TP module w/SIP Assembly, black body
9120-300M-EL8-000-R26VL-0-E0-B-V	QC-300 Master black body with viton seals, EL8 and R26VL modules
9120-300M-SIP-0-0000	QC-300 Sensor Plate w/o sensors/IP
9120-300M-SIP-0-0000-V	QC-300M SIP Assembly with no sensors, cables and interface plate, viton seals, 125 degree C max temp
9120-300T-000-000-000-000-B	QC-300 Tool, no options, Black
9120-300T-000-000-000-000-E0-B	QC-300 Tool Assembly Black No Options
9120-300T-R19-000-000-000-B	QC300 Tool w/built-in 5 pin elec mod, RTL & 19-pin elec mod w/mini MS quick-disc conn, Black
9120-300T-R26-000-000-000-E0-B	QC-300 Tool with R26, without std 5 pin Black
9120-60C-M-S90	BLA QC-60C-S90 Master
9120-A15-T-S2	A15 Tool Electrical module Euro, M3 Screw Locks with mechanical components, no wiring
9120-AH1N12-M	** Engineering Test Only. Not for Quote or Sale** High Temp Air Master Module with (1) 1/2" NPT Self-Sealing Port
9120-AH1N12-T	** Engineering Test Only. Not for Quote or Sale** High Temp Air Tool Module with (1) 1/2" NPT Self-Sealing Port
9120-AP-60B-M-2322	Master side adapter plate for QC-60 flat B for J16 pattern
9120-AP-60B-T-2323	Tool side adapter plate for QC-60 flat B for J16 pattern
9120-BLA-150B-M-DXXN-M19Z-SX	BLA QC-150B Master with DxxN and M19Z
9120-BLA-150B-T-DXXN-M19Z	BLA QC-150B Tool with DxxN and M19Z.
9120-BLA-20D-M-DAPA	BLA QC-20D Master with Pneumatic ports M5x8 contacts with D-Sub 15 contacts
9120-BLA-60D-S78-M	BLA QC-60D S78, Master Side w/ J16-S1 module
9120-BLA-A16A(S)-M	Contact block for Flex-70 Master
9120-BLA-A16A-M	BLA A16A electrical module, Master side
9120-BLA-A16A-T	BLA A16A electrical module, Tool side
9120-BLA-AT02372	Plug for Cooling Water Port for Tool Side
9120-BLA-B15D-T	BLA Non-Contact Electric Signal Block Tool Side
9120-BLA-B15N-M	BLA Non-Contact Electric Signal Block Master Side (NPN Output)
9120-BLA-CJ2-S28-T01	BLA Couple Joint, Tool Side
9120-BLA-E50Z-M	BLA E50-Z Earth contact, Master side
9120-BLA-J16Z-M	BLA J16Z Electrical Signal Contact Block, Master
9120-BLA-LIGHT-5A-M-H20A-XXXB	Light-5A Master with H20A electrical module
9120-BLA-M19(S2)-M	BLA M19(S2) Master Contact Block
9120-BLA-M19(S2)-T	BLA M19(S2) Tool Contact Block
9120-BLA-PC3DSS5-M	BLA Primary Current Module to GC-150C-S77 Master.
9120-BLA-QC-20D-T-DAPB	BLA QC-20D Tool with Pneumatic ports M5x12 contacts with D-Sub 15 contacts
9120-BLA-SC06S3-M	Special BLA Servo Module of GC (SC06S3-M)
9120-BPS26-T	Tool PROFIBUS pass-through module with 26-pin, 4 Amp/250VAC with MS connector
9120-BP-T-VL	BP Tool Electrical Module, Viton Seals and Teflon wires
9120-C-0811108-2816108-00-15	Ethernet Jumper Cable, 8-Pin X-Coded M12 Male Connector, 8-Pin RJ45 Male Connector, 15 Meters
9120-C-12M16M-12WL-0100	Cordset, Straight Male M16 Connect, 12 pin, to Wired Leads, 1 meter long
9120-C15-M	C15 CONNECTOR ASSEMBLY MASTER
9120-C15-M-2229	C15 Master attached to adap. plate 2229 to QC-100
9120-C-3PF90-3PM90-0041	(DO NOT REORDER - ref ECO 14350) Picofast Cordset, 3-Pin Right Angle Female Threaded to 3-Pin Male Right Angle LED Threaded, 0.41 m
9120-CF5-M	CF5-M Master Module Blue
9120-D15-M-BLA	D15 master module w/ M2.6 screw locks
9120-D15UA-T	D15A Tool Module with Adapter to USP-100T
9120-D15U-M	D15 Master Module with adapter to USP-100-M
9120-DC-201-2	QC-200 Series Stand Alone Tool Cover for Welding Applications
9120-DC-300-12	QC-300 Series Stand Alone Cover, 20" with flat, Alignment Pin & Boss
9120-DU3SWITCHKIT	DU3 TSI Cable Adapter Kit for Series Connection of Safety Switches
9120-E20M-005	E20 MASTER FOR QC-5
9120-E20T-005	E20 TOOL ELECTRICAL MODULE FOR QC-5
9120-EP18-M	Master E18 Module with (6) 5Amp Pins, (12) 3 Amp Pins, Solder Connections
9120-EP75-1585	Electrical Panel Assembly, Laser Scanner Tool
9120-ES13-M	ES13 Master Servo Module with Desoutter 4m Pigtail Cable
9120-ES13-T	ES13 Tool Servo Module with Desoutter 0.58m Pigtail Cable
9120-ES13Z1-T	ES13Z1 Tool Servo Module with Desoutter 0.69m Pigtail Cable
9120-ES13Z2-T	ES13Z2 Tool Servo Module with Desoutter 0.86m Pigtail Cable
9120-ES15-T	ES15 Tool Servo Module with Desoutter 0.69m Pigtail Cable
9120-ES15Z1-T	ES15Z1 Tool Servo Module with Desoutter 0.86m Pigtail Cable



## ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-1B-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-ES15Z2-T	ES15Z2 Tool Servo Module with Desoutter 0.91m Pigtail Cable
9120-ES1-M	Servo Master Module w/M23 8-Pin Servo Power, M23 12-Pin Encoder Signal, &M8 3-Pin sensor signal conn
9120-ES7-M	ES7 Servo Power Master Module
9120-ES7-T	ES7 Tool Servo Power Module
9120-ES8A-M	Souriau UTG Series, Insert 20-20, Male (1) Panel Mount Receptacle, Master
9120-ES9Z1-T	ES9Z1 Servo Tool Module
9120-FN2A-T	Stainless Steel Pneumatic Tool Module with (2) 3/8" NPT pass-thru ports
9120-FN4V-M	Stainless Steel Fluid/Air Master module with (4) 3/8" NPT self-sealing ports, Viton
9120-FN4V-T	Stainless Steel Fluid/Air Tool module with (4) 3/8" NPT self-sealing ports, Viton
9120-FR2-M	Stainless Steel Fluid/Air Master module with (2) 3/8" R thread self-sealing ports
9120-FR2-T	Stainless Steel Fluid/Air Tool module with (2) 3/8" R thread self-sealing ports
9120-FR4-M	Stainless Steel Fluid/Air module with (4) 3/8" BSPT (R) self-sealing ports - Master
9120-FR4-T	Stainless Steel Fluid/Air module with (4) 3/8" BSPT (R) self-sealing ports - Tool
9120-G17-T	G17 Electrical Module - Tool Side
9120-G19-M-S1	G19 Master Assembly without Connector or Wires
9120-G19-T-S1	G19 Tool Assembly without Connector or Wires
9120-G4D-UCT-0-00-0-00	See 9123-GK2T-0-00-0-00-N* Utility Coupler Tool for G4D Master, (2) Integrated CHECKED 3/8â€š Air Ports
9120-GE5-T-V	Ethernet Pass-Through Tool Module, Adjustable, Viton Seals
9120-H03-M	H03 Master Module with 3 pins w/hardwire connection rated to 1500V @1A
9120-H03-T	H03 Tool Module with 3 pins w/hardware connection rated to 1500V @1A
9120-H06-M-1583	H06 Master Module Assembly with Adapter to QC-21
9120-H06-M-6177	H06 Master Module Assembly with Adapter to J16 Pattern
9120-H06-T-6177	H06 Tool Module Assembly with Adapter to J16 Pattern
9120-HA6-M	High-Power Master module with 600 Amp and (2) Contacts
9120-J16-T-S2	J16 Tool Assembly with Connector and 3.2â€š +/- .2â€š cable length
9120-K12-M-V	K12-M Master Module (Potted) with Viton Seals
9120-KF10-T	KF10 Electrical Module with 0-99 Tool-ID
9120-KF14-T-CV	KF14 Tool Module (16 Tool ID) with Viton Seal
9120-KF6-M	KF6 Electrical Master Module, M12, 6-Pin Murr Connector
9120-KF6-T	KF6 Electrical Tool Module, M12, 6-Pin Murr Connector
9120-KG19-M	KG19 adjustable master module
9120-KG19-T	KG19 adjustable tool module
9120-KJ19A-M	KJ19A Electrical Module, Master
9120-KM14-M-S1	Master side 14-pin module with (12) pins at 5 amps and (2) pins at 13 amps, without connector and wires
9120-KM14-T-S1	KM14-T-S1 Tool Module without Connector or Wires
9120-KR5A-M	KR5A Master Module
9120-KR5C-M	KR5C Master Module
9120-L19-M	L19 Master electrical module
9120-L19-T	L19 Tool electrical module
9120-L26-M	26-pin, 3A/50V, miniature MS quick-disconnect connector - Master
9120-L26-T	26-pin, 3A/50V, miniature MS quick-disconnect connector - Tool
9120-M19-M	M19 Master Electrical Module
9120-M19-T	M19 Tool Electrical Module
9120-M19-T-S1	Special M19 Tool electrical module for Schunk w/o connector or wiring.
9120-M8T-011-S1	1.5A/30VAC Electrical module No Connector - Tool for QC-11
9120-MST19-M	19-pin, 3A/250V Electrical Module with Screw Terminal Connection (Master side)
9120-MT14B-T	14-pin high current module, ITT Cannon connector, shell size 20, tool
9120-MT6-T	MT6 Tool Electrical Module
9120-MT8-M-V	MT8 Master Power Module with Viton Seals
9120-MT8-M-V-S1	MT8 Master Power Module with Viton Seals without Connector or Wires
9120-MT9-M	28-amp 9-pin Electrical Module 500VAC/700VDC - Master side
9120-MT9-M-S1	28-amp electrical module 500VAC/700VDC without Connector or Wires, 10-Pin Block - Master side
9120-MT9-T	28-amp 9-pin Electrical Module 500VAC/700VDC - Tool side
9120-MT9-T-S1	28-amp electrical module 500VAC/700VDC without Connector or Wires, 10-Pin Block - Tool side
9120-MTA4-M	MTA4 Master Power Pigtail Module, 45A, 4-Conductor 10AWG 20m Cable, Potted
9120-MTA4-T	MTA4 Tool Power Pigtail Module, 45A, 4-Conductor 10AWG 5m Cable, Potted
9120-MTA5-M	(PHASING OUT, ONLY SELL/QUOTE SPARES OR REPLACEMENTS; USE MTA6 FOR NEW APPLICATIONS) 5-Contact, 30A Power Module with Harting Connector - Master
9120-MTA5-T	(PHASING OUT, ONLY SELL/QUOTE SPARES OR REPLACEMENTS; USE MTA6 FOR NEW APPLICATIONS) 5-Contact, 30A Power Module with Harting Connector - Tool
9120-MTB8L-M	13-amp 8-pin electrical module 500 VAC 700 VDC w/8-Pin Burndy connector @ 180 Degrees - Master side
9120-MTB8L-M	8-Pin Block Electrical Module, 13 Amp/500, VAC 700 VDC with 23-Pin Burndy Connector @ 180 Degrees - Master side
9120-MTB8L-T	8-Pin Block Electrical Module, 13 Amp/500, VAC 700 VDC with 23-Pin Burndy Connector @ 180 Degrees - Tool side
9120-MTC6-M	High Current 75A Master Module, 3 power + PE + 2 brake pins, M40 connector, radial exit, partially potted
9120-MTC6-T	High Current 75A Tool Module, 3 power + PE + 2 brake pins, M40 connector, radial exit, partially potted
9120-MTC9-M	MTC9 Pigtail Master Module, 9-Conductor 12AWG 14m Pigtail Power Cable
9120-MTC9-T	MTC9 Pigtail Tool Module, 9-Conductor 12AWG 2m Pigtail Power Cable
9120-MTS10-T	MTS10 Tool Power Module, Potted
9120-NF12-M	NF12 Master Inductive Coupler Module, PNP-Compatible Power Transmitter, 12 Sensor Signal Pass Thru with Male VersaFast M16 19-Pin Connector. Mates with NF12-T.
9120-NF12-T	NF12 Tool Inductive Coupler Module, PNP-Compatible Power Receiver, 12 Sensor Signal Pass Thru with Female VersaFast M16 19-Socket Connector. Mates with NF12-M.
9120-NS12-T	NS12 Tool Inductive Coupler Module, PNP-Compatible Power Receiver, 12 Sensor Signal Pass Thru with IP69K-Rated Souriau UTS-Series Female 19-Socket Connector. Mates NS12-M.
9120-P205-M	Pneumatic Module with (2) M5 Pass-Through Ports, Master
9120-P205-T	Pneumatic Module with (2) M5 Pass-Through Ports, Tool
9120-P38A-T-V	Pneumatic Tool module with (4) 3/8" NPT pass-through axial ports and Viton seals
9120-PC20M-238V-1C5S	QC20 Press Changer Master, (2) 3/8 NPT Vacuum Ports, 5 Pin Signal Pass Through
9120-PG12W13-T	High Current Tool Module, Single Contact, #2 Wire, 200A, SS, Euro
9120-PV1-T	PV1 tool module with (4) 3/8 G pass-through and (2) 1/4 G vacuum only
9120-PV2-M	PV2 master module with (6) 3/8 BSPP ("G") pass-through ports and (2) 3/8 BSPP ("G") self-sealing ports
9120-PV2-T	PV2 tool module with (8) 3/8 BSPP ("G") pass-through ports
9120-PWT1-M	5-Thru-Port, Rc1/8 Axial Air Module, Master
9120-R14ZC2-T	R14 Electrical Module, (0-9)Tool ID, Connector 90A°
9120-R19A-M	R19A Fluid Resistant Signal Module, Master
9120-R19A-T	R19A Fluid Resistant Signal Module, Tool
9120-R19PD-M	R19 Electrical Module, Master side, Potted
9120-R19PD-T	R19 Tool Electrical Module, Potted
9120-R19R3-M	R19R3-M Master Module with Lock/Unlock/RTL Cables
9120-R19R-M-VS	R19R Master Module with Right Angle Connectors, High Temp. App. (Teflon Wires)
9120-R19-T-SH	R19 Electrical Module - Tool Side with SST mounting bolts
9120-R26-M-SH	R26 Electrical Master Module with SST Hardware
9120-R26RZC1-M	Master Electrical Module with Right Angle Cables, 2 M8, 3-Pin cables
9120-R32P-M	32-pin, 3A/250VAC, MS miniature MS quick-disconnect connector with pico connectors, master side

### ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TC-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-R4PD-M	4A/250VAC electrical module potted with 4-pin Euro connector - Master side-Potted
9120-R4PD-T	4A/250VAC electrical module potted with 4-pin Euro connector - Tool side - Potted
9120-RA26W-M	Master side MS 26-pin 3 Amp/250VAC module with special Lock/unlock wiring
9120-RB26-M	23-pin Burndy Style, 5A/250VAC, MS miniature MS quick-disconnect connector
9120-RD26-M	R26 Master Module with 5-pin DeviceNet Pass-through
9120-REP7-M	4-pin MS Power, 3-pin MS Brake Module - Master
9120-REP7-T	4-pin MS Power, 3-pin MS Brake Module - Tool
9120-RES10A-T	Servo Signal Module, Tool with 10-pin JAE, and 3-pin M8 Turk connectors
9120-RF10ZC2L-T	NO QUOTE/SALE, REFERENCE ECO 21295, REPLACED BY 9120-RF10-T RF10 Electrical Module, Tool side with M16 connector & Tool-ID 0-99
9120-RF14-T-V	RF19-Pin Electrical Module with M16 Connector and 0-9 Tool ID-Tool side with viton seals
9120-RF19RA-T	RF19 Tool Electrical Module with rotated M16 Connector
9120-RJ419M8-T	RJ419M8-T Electrical Module, Junction Box with (4) M8, 3-Pin Connectors, 2AMPS / 60 VAC
9120-RJ526PDA-T	RJ526PDA Electrical Tool Module, Junction Box with (5) M12, 5-Pin Connectors, Potted
9120-RJ526PD-T	RJ526PD Electrical Tool Module, Junction Box with (5) M12, 5-Pin Connectors, Potted
9120-RK19A-M	Electrical module with M23 using Female threads, 19-Pin Connector, 3 Amps/150 VAC - Master
9120-RM19PD-T-V	RM19 Tool Electrical Module with M16 Connector, Viton Seals, Potted
9120-RSM10-M	RSM10 Electrical Module, Master Side, 17-Pin MS3102 for Signal
9120-RW10-T	RW10-T Tool Module 0-99 Tool ID
9120-RX11-M-7221	RX11 Vision Module, Master Side w/ Hirose Connector
9120-RX12-M	Master, Sony XC Series Camera Module with Hirose 12 Pin Connector
9120-RX12-T	Tool, Sony XC Series Camera Module with Hirose 12 Pin Connector
9120-S17-T	S17 Electrical Tool Module
9120-S19W-M	S19W-M Master Module Assembly
9120-S21-T	S21 Electrical Module - Tool side
9120-S32A-M	S32A Master Electrical Module
9120-S32A-T	S32A Tool Electrical Module
9120-SE25-M	PushCorp Router Module, Master
9120-SE25-T	PushCorp Router Module, Tool
9120-SE28Z1-T	SE28 Electroimpact Servo Module, Tool, Modified
9120-SE29-M	SE29 Servo Master Module
9120-SE30-T	SE30 Tool Module, Tool ID and I/O Pass Thru
9120-SE31-M	SE31 Master Module, (5X) M12 Connectors
9120-SE31-T	SE31 Tool Module, (5X) M12 Connectors
9120-SE32-M	PushCorp Servo w/Pigtail Cables, Master
9120-SE32-T	PushCorp Servo w/M12 D-Coded Connector, Tool
9120-SF0APD-T	SF0A Tool Module Assembly, 0-99 Tool ID, Potted, Radiation
9120-SF0PDV-T	SF0 Tool Electrical Module, Viton Seals, Potted, 0-9 Tool ID
9120-SF9PD-M	Signal Module 10-Pin M12, Potted, Radiation, Master
9120-SF9PD-T	Signal Module, QC500 Tool to QC300 Master, Potted, Radiation
9120-ST5-M	Master Bolt Feed Module, Rigid Mount, 14mm ID, 16mm OD for Hose Clamp Tube Connection
9120-ST5-T	Tool Bolt Feed Module, Rigid Mount, 14mm ID, 16mm OD for Hose Clamp Tube Connection
9120-T19R-M-VS	T19R Master Module with Right Angle Connectors, High Temp. App.
9120-TA6-M	Fiber Optic Module Master, J16 Mount, 2x SMA Connectors and cable gland provided, 400 ð€ 2400nm wavelength, 980/1000 micron POF supported
9120-TA6-T	Fiber Optic Module Tool, J16 Mount, 2x SMA Connectors and cable gland provided, 400 ð€ 2400nm wavelength, 980/1000 micron POF supported
9120-TB-M	Discrete PROFIBUS Pass-Through Master Module
9120-TB-T	Discrete PROFIBUS Pass-Through Tool Module
9120-TDPD-M	10-pin, 5 Amp/24VAC electrical master module with pass-through DeviceNet and Aux power, Potted
9120-TDPD-T	10-pin, 5 Amp/24VAC electrical tool module with pass-through DeviceNet and Aux power, Potted
9120-TDR-M	TDR Pass-Through Master Module with 4-Pin M12
9120-TDR-T	TDR Pass-Through Tool Module with 4-Pin M12
9120-TDS-M	DeviceNet Pass-Through Master Module W/ Axial Straight Connectors
9120-TDS-T	DeviceNet Pass-Through Tool Module W/ Axial Straight Connectors
9120-TP-M-VL	PROFINET Pass Through Master module with connectors for PROFINET and Aux Power, Viton Seals, Teflon Wires
9120-TPS-M	Combination PROFIBUS and PROFINET Pass-through Electrical Module with Aux Power - Master side
9120-TPS-T	TPS Tool Electrical Module
9120-TSL-ASY-7694	TSL Dual Stand ð€ Hooks, DSA, DSA-AK, DS, SS ð€ 72ð€ High
9120-TSL-CMB-C500	DO NOT QUOTE OR SELL WITHOUT APPS INPUT. RIGID IS PREFERRED. TSL Pin & Bushing Module. Compliant to 500 lbs
9120-TSL-CM-C500	Note: Existing applications only. Check with apps. TSL Compliant Interface Module (no weldment) with 500 psi pre-set spring
9120-TSL-DSA-AK-8797	Debris Shield Vertical Actuator Mounting Kit for NAAMS 50/63mm Power Clamp ð€ No Clamp Included
9120-TSL-HBC-7571	TSL Tooling Interface Plate for QC-210 with BC 125, (6) M10 Thru, (4) Dowel 10
9120-TSL-HBC-9962	TSL Tooling Interface Plate for QC-160/210 with 160mm B.C., (1) H7 Dowel 10, 100mm H7 Recess, (11) M10 Thru - Gussets
9120-TSL-HBC-9963	TSL Tooling Interface Plate for QC-160/210 with 160mm B.C., (2) H7 Dowel 10, 100mm H7 Recess, (10) M10 Thru - Gussets
9120-TSL-PM-148B-C500	TSL Post Module, (1) Compliant Pin & Bushing Module, 500 lbs, 48" Tall
9120-TSL-PM-248B-C500	TSL Post Module, (2) Compliant Pin & Bushing Modules, 500 lbs, 48" Tall
9120-TSL-SS-6889	TSL Tool Stand Interlock Switch Assembly
9120-TSL-SS-8077	TSL TSI Trip Doo ð€ Vertical ð€ Right
9120-TSL-TP-4104	TSL Tooling Interface Bracket Blank
9120-TSL-TP-5025	TSL Tool Plate Assembly for QC-210, Custom Pattern
9120-TSM-AM-9982	TSM Adapter Module - Mounting Module to TSM HE
9120-TSM-DP-4204	TSM Dowel Bracket Assembly ð€ Right Angle for Module-Rail Connection
9120-TSM-HBC-9751	TSM Tooling Interface Plate - 2" Longer - Blank
9120-TSM-HBQ-9360	TSM Tooling Interface Plate for QC-71 - Blank
9120-TSM-HE-3321	TSM Horizontal Extension 10"
9120-TSM-HVQ-4055	TSM Tooling Interface Plate for QC-40 - Blank
9120-TSM-HVQ-4056	TSM Tooling Interface Plate for QC-41 - Blank
9120-TSM-HVQ-4058	TSM Tooling Interface Plate for QC-71 - Blank
9120-TSM-HVQ-6624	TSM Tooling Interface Plate for QC-76 - Blank
9120-TSM-HVQ-8812	TSM Tooling Interface Plate for QC-40- 8.26" OAL - Blank
9120-TSM-HVQ-9012	TSM Tooling Interface Plate for QC-40 - 10" OAL - Blank
9120-TSM-MM-5165	QC40 Docking Ring Module
9120-TSM-MM-7171	TSM Mounting Block, Locking, SS, for Dual Pin Hanger
9120-TSM-MT-5166	QC40 Mounting Table Module
9120-TSM-SM-5167	Docking Ring Sensor Module
9120-TSM-TH-5891	Tool Hanger Module for QC20/21 Flat A
9120-TSM-TH-7172	Tool Hanger, J16, Stainless Steel, Double Pin Assy
9120-TSM-TP-4060	TSM QC-150 TIP, Blank
9120-TSM-TP-6624	(Replaced by 9120-TSM-HVQ-6624) TSM-QC-76 TIP Blank

**ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024**

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TE-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9120-TSM-VBBL-8441	TSM Vertical Tooling Interface Plate - Blank - Locking
9120-TSS-1020	OBSELETE - DO NOT QUOTE/SELL/PURCHASE, REFERENCE EC 21356 (Replaced by 9005-20-2226) TSS Rail Assembly 610mm Long
9120-TSS-3575	Small Tool Stand Rear Adaptor Plate for Flexdeburr 150, 300 and 340 to a QC21 Tool Side, 3 mounting pins, Clamping Collar Kit
9120-TSS-4170	TSS TIP Assembly Blank for QC 5, 10, 11 (Small OD)
9120-TSS-5028	Locking TSS Mounting Block Assembly
9120-TSS-5029	Locking TSS Tooling Interface Plate Blank QC 5, 10, 11
9120-TSS-MS-10032	MC-16 Manual Tool Storage
9120-TSS-TP-8026	TSS Pin and Bushing Vertical Tooling Plate with J16 Pattern
9120-TSS-VBQ-7190	*** REPLACED BY 9120-TSS-VBQ-8206, BACKWARDS COMPATIBLE *** TSS Vertical Tooling Interface Plate - J16 Pattern
9120-TW19-M	SW-150A Master TW19-M Safety Signal Module
9120-V300-M	1 Port Vacuum Master Module with 3" PMA Flange Mount
9120-V300-T	1 Port Vacuum Tool module with 3" PMA Flange Mount
9120-VSTW10-M	Master side 10-pin electrical module with spring probes and M16, 19-Pin male cordset
9120-X7D-M	X7D-M - Coax Master Power Module with BNC Connectors
9120-X7D-T	X7D-T - Coax Tool Power Module with BNC Connectors
9120-XG7G-T	XG7G Tool Module
9121-1210AM-JF3SC9-0-JJ2MT9R32-0-AK2-0-SL	QC-1210 Master Base Assembly with JF3, SC9, JJ2, MT9, R32, AK2 modules and PNP lock/unlock and ready-to-lock sensing with LED Cables
9121-1210AM-JU3VB11Z1-JJ30GB80-AM2-0-0-HB3-SL	QC-1210 Master with VB11Z1, JJ3, GB8, AM2, HB3 modules and PNP lock/unlock sensors with LED cables
9121-1210AT-0-0-JJ20TE0-0-AH3-0	QC-1210 Tool with no recess, JJ2 with TE, AH3
9121-1210AT-SC9-0-JJ2MT9R32-0-AK2-0	QC-1210 Tool Base Assembly with SC9, JJ2, MT9, R32, AK2 modules
9121-1210AT-VB11-JJ30GB80-AM2-0-0-HB3	QC-1210 Tool with VB11, JJ3, GB8, AM2 and HB3 modules
9121-210AM-JA2SA15-FS2-JJ21X7DX7DX7D-0-SM	QC-210 Master with no boss, SA15, FS2, JJ21, (4) X7D modules, PNP lock/unlock sensors with LED cables
9121-210AM-JB10R4-JJ3TDR-DT2-AM2-SM	QC-210 Master with no Boss with R4,TDR, DT2 and AM2 modules, and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JB18R4-JJ30TDR0-DT2-AM2-SMA	QC-210 Master with no Boss with JB2, JJ14, MT9, (2)R26, FC2, AS4, JJ12, (2)EN44, EN38 modules and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JB2JJ14MT9R26R26-FC2-AS4-JJ12EN44EN44EN38-SM	QC-210 Master, no boss, SA2, (2) AN3, R19 modules and lock/unlock, ready-to-lock sensing with LED cables
9121-210AM-JB2SA2-AN3-JJ20R190-AN3-SM	QC-210 Master with no boss, MT9S1, V114, AF2 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JF2JJ20MT9S10-JJ20V1140-0-AF2-SM	QC-210 Master with no boss, MT9S1, V114, PG0, AF2 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JF2JJ20MT9S10-JJ20V1140-JM2PG0-AF2-SM	QC-210 Master with no Boss w/JT2, DKG, FF3, PA2, ED8 and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JT2DKG-FF3-PA2-ED8-SM	QC-210 Master with no Boss, JT2, DL10, (2) JJ2, RF8, MTA5, TP Modules, PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JT2DL10-JJ2RF80MTA5-0-JJ20TP0-SM	QC-210 Master w/no Boss, Double Solenoid NPT Valve Adapter w/ Valve Pass Thru, VL1, FF4, PA2 Modules, ED8 Master Servo Module and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JT2VL1-FF4-PA2-ED8-SM	QC-210 Master with no Boss w/JU2, VB7, FH6, PA2, ED8 and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JU2VB7-FH6-PA2-ED8-SM	QC-210 Master with no boss, JU4, DL12, AK2, (2) JJ2, RE5, MTA5 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JU4DL12-AK2-JJ2RE500-JJ20MTA50-SM	QC-210 Master with no Boss, DL5, and AM2 modules, and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JU4DL5-AM2-0-0-SM	QC-210 Master with 80mm boss, JA2, TDPD, AE2 modules, PNP lock/unlock sensors with 5m cables, no RTL
9121-210AM-JA2-JJ20TDPD0-0-AE2-SRA	QC-210 Master with 80mm boss, SA15, FS2, JJ21, (4) X7D modules, PNP lock/unlock sensors with LED cables
9121-210AM-JA2SA15-FS2-JJ21X7DX7DX7D-0-SM	QC-210 Master with 80mm boss, SA3, AB2, R19PD modules, PNP lock/unlock sensors with LED cables
9121-210AM-JA2SA3-AB2-JJ20R19PD0-0-SM	QC-210 Master with 80mm boss, REP10, REP7, AS6, ED9 modules, PNP lock/unlock and RTL sensors with LED cables
9121-210AM-JB10-JJ2REP100REP7-AS6-ED9-SM	QC-210 Master with 80mm Boss w/JB10, (3) R26, AQ2, TB, RE5 and PNP lock/unlock and RTL Sensing with LED Cables
9121-210AM-JB10R26-JJ2R260R26-AQ2-JJ2TB0RE5-SM	QC-210 Master with 80mm Boss, SA2, AF2 and HB3 modules
9121-210AM-JB2SA2-AF2-HB3-0-SM	QC-210 Master with 80mm Boss, SA2(2) AS4 modules & PNP lock/unlock & RTL Sensing with cables
9121-210AM-JB2SA2-AS4-0-AS4-SM	QC-210 Master with 80mm Boss with JB2, SA2, JJ2, TB, AK2 modules, and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JB2SA2-JJ20TB0-AK2-0-SM	QC-210 Master with 80mm Boss w/JB9, RF19, FS2, JJ2, (2)X7D, and PNP lock/unlock and ready-to-lock sensors with LED cables
9121-210AM-JB9RF19-FS2-JJ2X7D0X7D-0-SM	QC-210 Master with 80mm boss w/JD2, DB2 modules; PNP lock/unlock sensors with LED cables
9121-210AM-JD2DB2-0-0-0-SM	QC-210 Master with 80mm boss, DB2 & AM2 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JD2DB2-0-AM2-0-SM	QC-210 Master with 80mm Boss w/ JD2, VA2, AM2, JM4, PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JD2VA2-AM2-JM4-0-SM	QC-210 Master with 80mm Boss, VB2, TA6 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JF2VB2-0-JJ20TA60-0-SM	QC-210 Master with 80mm boss, VH15, AM2 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JQ4VH15-0-AM2-0-SM	QC-210 Master with 80mm boss, VH15, AM2 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JQ4VH15-AM2-0-0-SM	QC-210 Master with 80mm Boss with JQ4, VH15, FH6, PA6, EL3 modules, and PNP lock/unlock and RTL sensors with LED cables
9121-210AM-JQ4VH15-FH6-PA6-EL3-SM	QC-210 Master with 80mm boss, DL10, (2) JJ2, RF19, MTA5, JJ13, (4) EN57, (2) RE5, PNP lock/unlock sensors with LED cables
9121-210AM-JT2DL10-JJ2RF190MTA5-JJ13EN57EN57EN57EN57-JJ2RE50RE5-SM	QC-210 Master with 80mm boss, JT2 with VB11, AM2, JJ2 with TB, PNP lock/unlock and RTL sensors with LED
9121-210AM-JT2VB11-AM2-0-JJ20TB0-SM	QC-210 Master w/ 80mm Boss VB11, FH6, PA2, RES10, REP7 modules & PNP lock/unlock sensors with LED
9121-210AM-JT2VB11-FH6-PA2-JJ2RES10REP7-SM	QC-210 Master, 80mm boss, DB10Z1, (2) EN22, (2) K12, FG2, JM4V3, PNP sensors w/ LED cables
9121-210AM-JU2DB10Z1-JJ12EN220EN22-JJ14K12FG2K12-JM4V300-SM	QC-210 Master w/ 80mm Boss VB11, FH6, PA2, RES10, REP7 modules & PNP lock/unlock sensors with LED
9121-210AM-JU2VB11-FH6-PA2-JJ2RES10REP7-SM	QC-210 Master with 80mm Boss, VB22, (2) AS4, JJ14, (3) R19 modules, PNP lock/unlock sensors with LED cables
9121-210AM-JU2VB22-AS4-JJ14R19R19R19-AS4-SM	QC-210 Master with 80 mm Boss, DL5, and AM2 modules, and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JU4DL5-AM2-0-0-SM	QC-210 Master with 80mm Boss, DL5, AM2, and R19 modules, and PNP lock/unlock and RTL Sensing, LED Cables
9121-210AM-JU4DL5-AM2-JJ20R190-0-SM	QC-210 Tool with 80mm recess, (2) AH3, JJ2 and (2) R26 modules
9121-210BT-0-AH3-JJ2R260R26-AH3	QC-210 Tool with 100mm recess, EL9 and FC2 modules
9121-210CT-0-EL9-FC2-0	QC-210 Tool with 100mm recess, TDPD and AE2 modules
9121-210CT-0-JJ20TDPD0-0-AE2	QC-210 Tool with 100mm Recess with REP10, REP7, AS6 and UAA bracket
9121-210CT-0-JJ2REP100REP7-AS6-UAA	QC-210 Tool with 100mm recess, DA4, AH3 and EB8 modules
9121-210CT-DA4-AH3-EB8-0	QC-210 Tool, 100mm recess, DA4, AM3
9121-210CT-DA4-AM3-0-0	QC-210 Tool with 100mm Recess, DA4, FC2, and PA2 modules
9121-210CT-DA4-FC2-0-PA2	QC-210 Tool with 100mm Recess with DB13, AH3 modules
9121-210CT-DB13-0-AH3-0	QC-210 Tool with 100mm recess and DB13, EN22, ENC, KPC2, FG2, K12, JM4V300
9121-210CT-DB13-JJ12EN220ENC-JJ14KPC2FG2K12-JM4V300	QC-210 Tool with 100mm recess and DB13, ENC, EN22, K12, FG2, KPC2, JM4V300
9121-210CT-DB13-JJ12ENC0EN22-JJ14K12FG2KPC2-JM4V300	QC-210 Tool with 100mm Recess
9121-210CT-DKF-FF3-PA2-ED8	QC-210 Tool with 100mm recess, DL10, (2) JJ2, RF19, MTA5, JJ13, (4) ENC and (2) RE5 modules
9121-210CT-DL10-JJ2RF190MTA5-JJ13ENC0ENC0ENC0-JJ2RE50RE5	QC-210 Tool with 100mm Recess, DL10, (2) JJ2, RF8, MTA5, TP Modules
9121-210CT-DL10-JJ2RF80MTA5-0-JJ20TP0	QC-210 Tool with 100mm Recess with DL4, AF2, X7C, MT6 modules
9121-210CT-DL4-AF2-JJ2X7CMT6-0	QC-210 Tool with 100mm recess, DL4, PB5, MTBA8L, X7J, MTB8 and AF2 modules
9121-210CT-DL4-PB5-JJ14MTBA8LX7JMTB8-AF2	QC-210 Tool, 100mm recess, JB11, AH3, EBB
9121-210CT-JB11-AH3-EBB-0	QC-210 Tool with 100mm Recess w/ JB11, (3) R26, AQ2, TB, RE5
9121-210CT-JB11R26-JJ2R260R26-AQ2-JJ2TB0RE5	QC-210 Tool with 100mm Recess and R4, TDR, DT2, and AM2 modules
9121-210CT-JB11R4-JJ30TDR0-DT2-AM2	QC-210 Tool with 100mm Recess with JB11, RF14, FS2, JJ2 (2)X7D modules
9121-210CT-JB11RF14-FS2-JJ2X7D0X7D-0	QC-210 Tool with 100mm Recess with JJ14, MT9, (2)R26, FC2, AS4, JJ12, (2)EN44, EN38 modules
9121-210CT-JJ14MT9R26R26-FC2-AS4-JJ12EN44EN44EN38	QC-210 Tool with 100mm recess, MT9S1 and AF2 modules
9121-210CT-JJ20MT9S10-0-0-AF2	QC-210 Tool with 100mm recess, MT9S1, V114, and AF2 modules
9121-210CT-JJ20MT9S10-JJ20V1140-0-AF2	QC-210 Tool with 100mm recess, MT9S1, V114, PG0 and AF2 modules
9121-210CT-JJ20MT9S10-JJ20V1140-JM2PG0-AF2	

ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FTT000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Table with 2 columns: Column1 (part numbers) and Description (product details). Rows include various tool changer and utility coupler models such as QC-210, QC-310, and QC-310M.

### ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TC-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9121-310DT-JB11RE5-JJ21JPCJPCRE5JPC-FC2-JJ21R19R19MT9MT9	QC-310 Tool with 125mm Recess, JB11, (2) RE5, (3) JPC, (2) JJ21, FC2, (2) R19 and (2) MT9 modules
9121-310DT-JB11RE5-JJ21JPCRE5JPC-FC2-JJ21R19R19MT9MT9	QC-310 Tool with 125mm Recess, JB11, (2) RE5, (3) JPC, (2) JJ21, FC2, (2) R19 and (2) MT9 modules
9121-310DT-JB11RE5-JJ21RE5JPCJPC-FC2-JJ21R19R19MT9MT9	QC-310 Tool with 125mm Recess, JB11, (2) RE5, (3) JPC, (2) JJ21, FC2, (2) R19 and (2) MT9 modules
9121-310DT-JB11RF19-JM4V300-AQ2-JM4V300	QC-310 Tool with 125mm Recess with JB11, RF19, (2)JM4 (2)JV300, AQ2 modules
9121-310DT-JJ20R260-AM3-0-0	QC-310 Tool with 125mm recess, R26, AM3 modules
9121-310DT-JQ4UAB-FH3-PA6-EL3	QC-310 Tool with 125mm Recess with JQ4, UAB, FH3, PA6, EL3 modules
9121-310DT-JR4DL12-0-JJ2RE500-JJ2MTA50MTA5	QC-310 Tool with 125mm recess, JR4, DL12, (2) JJ2, RE5, (2) MTA5 modules
9121-310DT-JR4DL12-AK2-JJ2RE500-JJ2MTA50MTA5	QC-310 Tool with 125mm recess, JR4, DL12, AK2, (2) JJ2, RE5, (2) MTA5 modules
9121-310DT-JR4DL12-JJ2RE50MTA5-0-0	QC-310 Tool with 125mm recess, JR4, DL12, JJ2, RE5, and MTA5 modules
9121-310DT-JR4DL5-0-AM2-0	QC-310 Tool with 125mm Recess and DL5 and AM2 modules
9121-310DT-SA18-JJ150R19SH0-AV7-0	QC-310 Tool with 125mm recess with SA18, R19SH, and AV7
9121-310DT-SA28-FH10-JJ14RSM7RSM10ST5-PA11	QC-310 Tool, 125mm recess, SA28, FH10, RSM7, RSM10, ST5, and PA11 module
9121-310DT-SA2-AH4-HB3-0	QC-310 Tool with 125mm Recess with SA2, AH4, HB3 modules
9121-310DT-SA2-AM2-JJ2R190MT6-0	QC-310 Tool with 125mm Recess SA2, AM2, R19 and MT6 modules
9121-310DT-SA2-AQ2-ED8-0	QC-310 Tool with 125mm Recess w/ SA2, AQ2 and ED8 modules
9121-310DT-SA2-FH6-JJ14PG1MTA6RP5-JJ12EN44EN440	QC-310 Tool with 125mm Recess, SA2, PG1, MTA6, RP5, and (2) EN44 modules
9121-310DT-SA2-JJ200MT9-FC4-0	QC-310 Tool with 125mm recess, SA2, MT9, and FC4 modules
9121-310DT-SA2-JJ2P186EOP186E-JJ14X7CR26X7C-JJ13EN6EN6EN6EN6	QC-310 Tool with 125mm Recess W/ SA2 module, (2) P186E, X7C, R26, X7C and (4) EN6 modules
9121-310DT-SA3-AH2-0-0	QC-310 Tool with 125mm Recess, SA3 and AH2 modules
9121-310DT-SA3-JJ10AM2VG3-EN6EN6EN6EN6-0	QC-310 Tool with 125mm recess, SA3, AM2, VG3 and (4) EN6 modules
9121-310DT-SA3-JJ10AM2VG3-JJ13EN44EN44EN44EN44-0	QC-310 Tool with 125mm recess with SA3, AM2, VG3, and (4) EN44 modules
9121-310DT-SA3-JJ14FG20TP-JJ13EN44EN44EN44EN44-0	QC-310 Tool with 125mm recess with SA3, FG2, TP, and (4) EN44 modules
9121-310DT-SC9-AK2-JJ20R320-JJ20MT90	QC-310 Tool with 125mm Recess with SC9, AK2, (2)JJ2, R32, MT9 modules
9121-310DT-UAB-FH6-PA6-EL3	QC-310 Tool with 125mm recess, UAB, FH6, PA6 and EL3 Modules
9121-310DT-VB12-AH2-0-0	QC-310 Tool with 125mm recess, VB12, AH2
9121-310DT-VB18-FH6-PA2-JJ2RES100REP7	QC-310 Tool w/125mm Recess w/VB18, FH6, PA2, RES10, REP7
9121-310DT-VB3-JJ21RESR19F2MT8-JJ21X7DX7D0V200A-0	QC-310 Tool with 125mm recess, VB3, (2) JJ21, RE5, RF19, FN2, MT8, (2) X7D, V200A modules
9121-310DT-VB3-SN2-AM3-0	QC-310 Tool with 125mm Recess, VB3, SN2 and AM3 modules
9121-310DT-VB3-UAA-AM3-JJ3R260R26	QC-310 Tool with 125mm Recess, VB3, UAA, AM3, JJ3 and (2) R26 modules
9121-310DT-VH6-ED8-AE2-JJ14X7BX7BMT8	QC-310 Tool with 125mm Recess, VH6, ED8, AE2, (2) X7B and MT8 modules
9121-310EM-JT3DB12-JJ20RK160-JJ6EC6-AA2-SM	QC-310 Master w/160mm Boss w/JT3, DB12, JJ2, RK16, JJ6, EC6, AA2 and PNP lock/unlock and RTL sensors w/LED Cables
9121-313AM-JD3-JJ2F2HG14A00AN3-JJ17-JJ8GB8AGB8AGB8A0JJ3GB8A00-SM	QC-313 Master with no Boss, F2HG14A, AN3, and (4) GB8A, modules and PNP lock/unlock and RTL sensing, LED cables
9121-313AM-JD3JJ3300000-JJ20F2HG14A0AN3-JJ1700000-JJ8GB8AGB8AGB8AGB8A0JJ3GB8A0	QC-313 Master with no Boss, F2HG14A, AN3, and (4) GB8A, modules and PNP lock/unlock and RTL sensing, LED cables
9121-313DM-JU3VL1-FS2JJ12EN820EN83-JJ21GB8AGB8AX7SCX7SC-JJ3RES10B0MTC6JM4V300-SM	QC-313 Master with 125mm Boss with JU3, VL1, FS2, JJ12, EN82, EN83, JJ21, (2)GB8A, (2)X7SC, JJ3, RES10B, MTC6, JM4, V300 modules and PNP lock/unlock and ready-to-lock sensors with LED cables
9121-313DT-0-JJ2F2HG14A00AN3-JJ17-JJ8GB8AGB8AGB8A0JJ3GB8A00	QC-313 Tool with 125mm Recess with F2GH14A, AN3, (4) GB8A, modules
9121-313DT-JJ170ENC000-JJ2000AN3-JJ17000ENCENC-JJ8GB8AGB8AGB8A0-JJ3GB8A0JPC	QC-313 Tool with 125mm Recess, (2) JJ17, (3) ENC, JJ2, AN3, JJ8, (4) GB8A, JJ3, and JPC modules
9121-313DT-JJ3300000-JJ20F2HG14A0AN3-JJ1700000-JJ8GB8AGB8AGB8AGB8A0JJ33000	QC-313 Tool with 125mm Recess with F2GH14A, AN3, (4) GB8A, modules
9121-313DT-VL1-FS2JJ12EN820EN83-JJ21GB8AGB8AXSCXSC-JJ3RES10B0MTC6JM4V300	QC-313 Tool with 125mm Recess with VL1, FS2, JJ12, EN82, EN83, JJ21, (2)GB8A, (2)XSC, JJ3, RES10B, MTC6, JM4, V300 modules
9121-510DM-JA6ASF9PD-HB11-AF4-HB11-S0	QC-510 with 125mm Boss w/SF9PD, (2) HB11, AF4 modules, with plugs in sensor holes
9121-510DM-JB13R26-JJ20MT90-JJ20P12AE0-0-SM	QC-510 Master with 125mm Boss, JB13, R26, MT9 and P12A modules with PNP Lock/Unlock/RTL sensors
9121-510DM-JB3JJ2G190G19S1-G190MT8-AQ2-G19S10MT8-SM3	QC-510 Master with 125mm Boss with JB3, JJ2, (2)G19, (2)G19S1, (2)MT8, AQ2 modules, and Screw Connect PNP lock/unlock and RTL Sensing with LED Cables
9121-510DM-JB3JJ2R32P00-AM2-0-0MT14-SM	QC-510 Master with 125mm Boss, R32P, AM2, MT14 modules, PNP lock/unlock sensors with LED Cables
9121-510DM-JB3JJ2R32P00-AM2-0-0-SM	QC-510 Master with 125mm Boss with JB3, R32P, AM2 & PNP lock/unlock, ready-to-lock sensing, LED cables
9121-510DM-JU3VB17-VG3-AS4-AS4-SP	QC-510 Master with 125mm boss, JU3, VB17, VG3, (2) AS4, NPN lock/unlock and RTL sensors with LED cables
9121-510DM-JU3VB18-AF2-JJ17EN79EN79EN79EN80EN80-JJ21MT8LP3RP5MT8-SM	QC-510 Master with 125mm Boss with JU3, VB18, AF2, JJ17, (3)EN79, (2)EN80, JJ21, MT8L, PG3, RP5, MT8 modules and PNP lock/unlock and RTL Sensing with LED Cables
9121-510DM-JU3VB7-FG400-HB3-0-SM	QC-510 Master with JU3, VB7, FG400 and HB4 Modules
9121-510DT-JB11R26-JJ20MT90-JJ20P12AE0-0	QC-510 Tool with 125mm Recess w/ R26, MT9, and P12A modules
9121-510DT-JB11RF14V-0-0-0	QC-510 Tool with 125mm Recess, JB11 spacer and RF14-V module
9121-510DT-JJ2G190G19S1-G190MT8-AQ2-G19S10MT8	QC-510 Tool with 125mm Recess with JJ2, (2)G19, (2)G19S1, (2)MT8, AQ2 modules
9121-510DT-SA2-0-AH2-0	QC-510 Tool with 125mm Recess with SA2 and AH2 modules
9121-510DT-VB18-AF2-JJ17EN79EN79EN79EN80EN80-JJ21MT8LP3RP5MT8	QC-510 Tool with 125mm Recess with VB18, AF2, JJ17, (3)EN79 (2)EN80, JJ21, MT8L, PG3, RP5, MT8 modules
9121-510DT-VB3-FC2-0-0	QC-510 Tool with 125mm recess VB3 and FC2 module
9121-510DT-VB3-FG400-HB3-0	QC-510 Tool, 125mm recess, VB3, FG4, HB3 modules
9121-AH2-T	Pneumatic Tool Module with (8) G 3/8 Ports, 4 self-sealing/4 pass-through ports Engineering
9121-AH3-T	Pneumatic tool module with (8) 3/8 G pass-through ports
9121-AS4-M	Pneumatic Master module with (24) 1/4" G pass-thru ports - shim kit included
9121-DA2-M	SEM Quick Connect Capable DeviceNet master module with TSI
9121-DA2-T	SEM Quick Connect Capable DeviceNet tool module with paired Tool-ID
9121-DL5-M	DL5 Master Profinet Module Assembly
9121-DL5-T	DL5 Tool Assembly
9121-ED4-M	ED4 Servo, Master, TOX
9121-ED4-T	ED4 Servo, Tool, TOX
9121-ED8-M	Master Servo Module with M23 Motor and Resolver Connections
9121-ED8-T	Servo module with M23 Motor and Resolver Connections - Tool
9121-EL3-M	Master Servo Module with (3) Hummel 90 degree M23 Connectors
9121-EL3-T	Tool Servo Module with (3) Hummel 90 degree M23 Connectors
9121-EL9-M	Master Servo Module with 3 M23 Connectors (Siemens Servo)
9121-EN44-M	Siemens 1FT7 Servo Master module with (1) 8-Pin M12, (1) 6-Pin M23
9121-EN44-T	Siemens 1FT7 Servo Tool module with (1) 8-Pin M12, (1) 6-Pin M23
9121-EN66-T	Servo Power and Signal Tool Module with Flying Leads, two (4) 1mm2, (2) 0.75mm2, (2) 22AWG Power/Signal Cables to Tool
9121-EN67-T	Servo Power and Signal Tool Module with Flying Leads, one (4) 1.5mm2, (2) 0.75mm2, (2) 22AWG Power/Signal Cable to Tool
9121-EN6-M	Siemens Rail Mount Master Module
9121-EN6-T	Siemens Rail Mount Tool Module
9121-EN79-M	Servo Signal Master Module with (2) Bayonet Shell Size 20, 12 Male Pins
9121-EN79-T	Servo Signal Tool Module with (2) Bayonet Shell Size 20, 12 Female Sockets
9121-EN80-T	Servo Signal Tool Module with (2) Intercontec M23, 19-Pin Signal Connectors
9121-ER11-M	Misc Signal Master Module #1 for Oxford Telescope

### ATI Tool Changer & Utility Coupler Products Going Obsolete in 2024, with Last Buy opportunity until July 1, 2024

\*\*\* NOTE: Many configurations are included on this list because they include a utility pass-through module that is going obsolete, therefore the configuration is also going obsolete. For example, although the QC-76 Tool Changer is not obsolete, the specific configuration 9120-076FT-TB-000 is going obsolete because it includes the obsolete 9120-TB-T ProfiBus pass-through module. \*\*\*

Column1	Description
9121-ER11-T	Misc Signal Tool Module #1 for Oxford Telescope
9121-ER12-M	Misc Signal Master Module #2 for Oxford Telescope
9121-ER12-T	Misc Signal Tool Module #2 for Oxford Telescope
9121-ER13-M	Misc Signal Master Module #3 for Oxford Telescope
9121-ER13-T	Misc Signal Tool Module #3 for Oxford Telescope
9121-ER14-M	Misc Signal Master Module #4 for Oxford Telescope
9121-ER14-T	OBSOLETE - last buy until July 1, 2024; REFERENCE EC 21469Misc Signal Tool Module #4 for Oxford Telescope
9121-ER4-M	Compact Rail Mount Servo module with M23 connector/cable - Master side
9121-FC2-T	Stainless Steel Fluid/Air Tool Module with (8) 3/8 G ports, 4 self-sealing/4 pass-through
9121-FH3-M	Stainless Steel Fluid/Air module with (4) 1/2 BSPP self-sealing ports with SST mounting SHCS - Master
9121-FH3-T	Stainless Steel Fluid/Air module with (4) 1/2 BSPP self-sealing ports with SST mounting SHCS - Tool
9121-HB3-M	Hydraulic Module with (2) 2300 PSI G 3/8 - Master
9121-HB3-T	Hydraulic Module with (2) 2300 PSI G 3/8 - Tool
9121-JD2-M	Valve Adapter, Single Solenoid, G, QC-210
9121-JJ27-M	J16 Master Mounting Adapter Assembly(Offset) With 24 x 58mm Customer Pattern
9121-JQ4-M	Valve Adapter, Dual Single Solenoid Valves, G (BSPP), QC-210, SST Mounting Bolts
9121-SA18-T	Discrete Signal tool module w/19-pin Amphenol, 19-pin Block, 7 Pass-Thru™s, 0-999 Tool-ID, with SST
9121-UA11-M	Master Module with (2) Stud Welding Extensions, (2) RB26 Modules, 1/4-Turn Feed Connection, (2) M6 Stud
9121-UA8-M	(2) Stud Welding Extensions (Short Stud), (2) RB26 Modules, 1/4-Turn Feed Connection
9122-036RMZG2-000-000-E	MC-036R Master Assembly - Euro with food grade grease (DuPont Molykote G-4500)
9122-DC-36-01	MC-36 Series Stand Alone Dust Cover
9123-GH1M-JJX1RF5RE50-00-00-SG-N	GH1 Manual Utility Coupler Master, (4) 3/8" NPT Checked Ports, Adaptor w/ RF5, RE5, PNP sensors
9123-GH1T-JJX1RF5RE50-00-00-N	GH1 Tool Base Assembly, NPT, with adaptor with RF5 and RE5
9123-GK2CM-0-0RF19-0-0TPS-SG-N	GK2 Compliant Utility Coupler Master, (2) 3/8" NPT Checked Air Ports, (2) DC PNP Tool Presence Sensors, with RF19, TPS Modules
9123-GK2CM-0-RN50-TA6-00-SG-E	GK2 Utility Coupler Tool for Master, w/RN5, TA6, (2) Integrated CHECKED 3/8" BSPP Air Ports
9123-GK2CM-0-TB0-0-00-SG-N	GK2 Compliant Utility Coupler Master w/TB Module, (2) DC PNP Tool Presence Sensor
9123-GK2CM-0-TPS0-0-00-SG-N	GK2 Compliant Utility Coupler Master with TPS module
9123-GK2T-0-0RF19-0-0TPS-N	GK2 Utility Coupler Tool for Master, (2) Integrated checked 3/8" NPT Air Ports w/RF19, TPS Modules
9123-GK2T-0-RN50-TA6-00-E	GK2 Utility Coupler Tool for Master, w/RN5,TA6, (2) Integrated CHECKED 3/8" BSPP Air Ports
9123-GK2T-0-TB0-0-00-N	GK2 Utility Coupler Tool for Master w/TB Module, (2) Integrated checked 3/8" NPT Air Ports
9123-GK2T-0-TB0-0-TB0-N	GK2 Utility Coupler Tool with (2) TB Modules, and (2) Integrated checked 3/8" NPT Air Ports
9123-GK2T-0-TPS0-0-00-N	GK2 Utility Coupler Tool for Master with TPS module
9123-GL2CM-DT2-0-JM4V300-JJ3R260MT8-N	GL2 Compliant Utility Coupler Master +/-4mm X-Y, 3 Degrees Angular, (2) 3/4" NPT Checked Ports, DT2, JM4, V300, JJ3, R26, MT8 modules
9123-GL2PCM-0-0-JJ30TDS0-JJ30TDS0-E	GL2P Compliant Utility Coupler, (2) JJ3 mounting blocs with TDS modules, Euro
9123-GL2PT-0-0-JJ30TDS0-JJ30TDS0-E	GL2P Utility Coupler Tool with (2) JJ3 adaptors and (2) TDS modules
9123-GL2T-DT2-0-JM4V300-JJ3R170MT8-N	GL2 Utility Coupler Tool with (2) 3/4" NPT Ports, DT2, JM4, V300, JJ3, R17, MT8 modules
9123-GL5CM-JJ20TB0-0-0-0-SG-E	GL5 Compliant Utility Coupler Master w/JJ2 Adapter and TB Module
9123-GL5T-JJ20TB0-0-0-0-E	GL5 Utility Coupler Tool with JJ2 Adapter and TB Module