

Notes:

- Switch, actuator and fasteners shipped loose. To be installed by customer.
 Customer to install pre-applied fasteners and tighten SHCS to contact plus 1/4 turn. DO NOT OVERTIGHTEN.
- 3. Isolator pads included with switch and actuator.4. Do not exceed a Dynamic bend radius of 10X cable diameter or a static bend radius of 5x.

NOTES: UNLESS OTHERWISE SPECIFIED.

DO NOT SCALE DRAWING. ALL DIMENSIONS ARE IN MILLIMETERS.



1031 Goodworth Drive, Apex, NC 27539, USA Tel: +1.919.772.0115 Email: info@ati-ia.com Fax: +1.919.772.8259 www.ati-ia.com ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.

3rd ANGLE PROJECTION

HECKED BY:	D. Norton, 9/29/15

DRAWN BY: J. Winterroth, 9/25/15

TSL Non-Contact TSI Switch Assembly - Actuator and Switch


SCALE PROJECT # 141006-2 SHEET 1 OF 2 1:2


DRAWING NUMBER 9630-20-TSL-SS-9015

02


REVISION

Approach directions and minimum distance CES-I-AP-.-C04





Pin	Desig	Wire color	
1	UB	Power supply DC 24 V	BN
2	FO1A	Safety output channel 1	WH
3	OV	Ground DC 0 V	BU
4	F01B	Safety output channel 2	BK
5	OD/ n.c.	Monitoring output	GY



In combination with actuator CES-A-BBN-C04-115271		Approach directions A and B (see page 111)			
Operating distance for center offse	et m = 0				
- Switch-on distance		-	15	-	
- Assured switch-on distance s _{ao}		10	-	-]
- Switching hysteresis 2)		1	2		mm
- Assured switch-off distance s _{ar}	in x/z direction	-	-	40	
_	in y direction	-		60	1
In combination with actuator CES-A-BBN-C04-115271		Approach directions C and D (see page 111)			
Operating distance for center offse	et m = 0				
- Switch-on distance		-	11	-	
- Assured switch-on distance sao		6	-	-	
- Switching hysteresis 2)		1	2	-	mm
- Assured switch-off distance s _{ar}	in x/z direction	-	-	40]
	in y direction	-		60	1

NOTES: UNLESS OTHERWISE SPECIFIED.

DO NOT SCALE DRAWING. ALL DIMENSIONS ARE IN MILLIMETERS.



1031 Goodworth Drive, Apex, NC 27539, USA Tel: +1.919.772.0115 Email: info@ati-ia.com Fax: +1.919.772.8259 www.ati-ia.com ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.

3rd ANGLE PROJECTION

1	CHEC
+	
\neg	

ECKED BY: D. Norton, 9/29/15

DRAWN BY: J. Winterroth, 9/25/15

TSL Non-Contact TSI Switch Assembly - Actuator and Switch

 PROJECT #
 141006-2
 SHEET 2 OF 2
 SCALE
 SIZE
 DRAWING NUMBER

 B
 9630-20-TSI

9630-20-TSL-SS-9015

REVISION 02