



Manual Addendum
Applies to the Purchase of the F/T Controller Only
and the Need to Load the Calibration File

CAUTION: This addendum is only applicable for ATI F/T sensors with serial numbers FT3400 and newer. Sensors with serial number of FT3399 or older are not compatible with current controllers unless the sensor is returned to ATI and recalibrated with the new controller.

If you purchased a 9105-CTL or 9105-CON controller only, to be used with your existing Force/Torque sensor, you will need to load your sensors matching FTxxxx.dat file in the new controller to get accurate F/T data. You will need to use the ATI Controller Demo program.

If you do not have this Demo program, please visit our website at www.ati-ia.com, select Library, Software Downloads, Stand-alone Controller Software and download the current version of our Demo program.

Once the Demo program is installed, open the Demo program, and if you are not prompted to download the calibration automatically, use the "File" -> "Load Calibration..." menu item to load in the calibration.

If you do not have the matching FTxxxx.dat file for your sensor, contact ATI and this file can be emailed to you. Have the FT serial number of your sensor when you contact us.