


A. Master Interface Race: Anodized Aluminum
B. Ball Nose Spring Plunger: Stainless Steel Ball Tip and Case
C. Debris Shield: Thin Gauge Stainless Steel
D. Skirt: EPDM Rubber w/ Retention Clips
E. Alignment Pin & Alignment Boss: Steel
F. Device Module Contact Guard: Delrin w/ Nitrile Seal
G. PA2 Contact Guard, Tool Interface Coupling & Spacer: Delrin
Ball Plungers require lubrication, Mobilgrease XHP-222 Special.
Intended to always be mounted to a tool body for alignment.
Otherwise, make provisions to use cover's alignment features.
Designed to mate specifically with tool changer 9121-210CT-DA2-FF2-PA2-0.
Shield pull-away min. force: 96 lbs from center.
Set Screws. Spring Plungers and V-Seal are the only items that are field

Set Screws, Spring Plungers and V-Seal are the only items that are field replaceable.





1031 Goodworth Drive, Apex, NC 27539, USA Tel: +1.919.772.0115 Email: info@ati-ia.com Fax: +1.919.772.8259 www.ati-ia.com ISO 9001 Registered Company

DRAWN BY: M. Gala, 6/21/07 CHECKED BY: D. Norton, 7/17/07 SCALE WEIGHT LBS: 7.36

ASSEMBLY REF:

QC 200 Series Stand Alone Tool Cover, Dynamic Application

DRAWING NUMBER 9230-20-2618-04 1:4 PRODUCT RELEASE # 070605-1 DATE: SHEET 1 OF 1