





Notes:

- Input current (Pin A of the M16 connector) is limited to 4A. Input voltage is limited to 24V +20%/-10%.
- Current and voltage on Spare Signals 1-8 are limited to 4A, 50V.
- The CV14PRx Master module is designed to work with PNP Locked and Unlocked sensors and a PNP unlatch output. The Unlatch Enabled and Tool Present inputs are also also PNP. Note: The Locked and Unlocked sensors are supplied with the Tool Changer.
- The CV14PRx Master module is equipped with a single solenoid 5port, 2-position valve with spring return. The valve's purpose is to lock and unlock the Tool Changer. Because this is a single solenoid valve, the valve will default to the lock state when electrical power is lost.
- The valve must be supplied with clean, dry air filtered to 40 microns. The air supply pressure must be between 60 and 100 psi [.41 MPa to .69 MPa]. A 6mm to 4mm reducer fitting is attached to the end of the valve air supply fitting.
- The CV14PRx Master module is designed to prevent an accidental tool unlatch. The unlatch command will only be executed if the Safety Switch inputs, SSO1 and SSO2, are both true, indicating that the Tool is in the Tool Stand.
- The CV14PR Master is equipped with a bypass circuit that will allow an unlatch command to be executed when NO TOOL is present, as indicated by the two Tool Present signals.
- Use a safety rated mechanical or magnetic limit switch with two Normally Open contacts. The contacts should only close when the Tool is nested safely in the Tool Stand. The switch must be connected as indicated in the schematic.
- The CV14PR Master is equipped with Arc Prevention circuitry that protects the electrical contacts against arcing when coupling and uncoupling. The Arc Prevention circuit will turn power on when Unlatch is true and the Tool Present 1 signal is true.
- The CV14PR Master is equipped with four LEDs indicating the following:
 - "PŎWER": Power to the Master is available
 - "TOOL POWER ON": Arc prevention has turned on power to the
 - 3. "SAFE TO UNLATCH": The conditions for a safe unlatch have
 - "UNLATCH ON": The unlatch output to the valve is active See the product manual for additional information.
- Table 1 shows a detailed pinout of the Master side M16 Male Connector.
- The Tool ID circuit is rated to 30V, 100mA. See Table 2 for Tool ID binary output. The Tool ID common is Input V+.

TABLE 1: MASTER SIDE M16 19-PIN CONNECTOR PINOUT

Connector Pin	Signal Name			
Α	Input V+ (24V)			
В	Locked			
С	Unlocked			
D	Tool Present			
E	Unlatch Enabled			
F	Tool ID1			
G	Tool ID2			
Н	Tool ID4			
	Tool ID8			
K	Unlatch			
L	Input V- (0V)			
М	Spare 1			
N	Spare 2			
0	Spare 3			
Р	Spare 4			
R	Spare 5			
S	Spare 6			
Т	Spare 7			
U	Spare 8			

TABLE 2: TOOL ID BINARY OUTPUT

Switch	Pin	Pin	Pin	Pin
Selection	I	Н	G	F
0	0	0	0	0
1	0	0	0	1
2	0	0	1	0
3	0	0	1	1
4	0	1	0	0
5	0	1	0	1
6	0	1	1	0
7	0	1	1	1
8	1	0	0	0
9	1	0	0	1
Α	1	0	1	0
В	1	0	1	1
С	1	1	0	0
D	1	1	0	1
Е	1	1	1	0
F	1	1	1	1

NOTES: UNLESS OTHERWISE SPECIFIED.

DO NOT SCALE DRAWING. ALL DIMENSIONS ARE IN MILLIMETERS.



1031 Goodworth Drive, Apex, NC 27539, USA Tel: +1.919.772.0115 www.ati-ia.com Fax: +1.919.772.8259 ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.

DRAWN BY: S. Yang, 06/28/2020 CHECKED BY: W. Berrocal, 10/26/20

Compact Discrete Control Module, PNP, Right Angle Locked-Unlocked Sensor Cables

3rd ANGLE PROJECTION

DRAWING NUMBER

REVISION 05

PROJECT # 190203-1 SHEET 4 OF 4 1:1

9630-20-CV14PRxM CV10PT

SCALE