
"DANGER!" - Electrical Shock Hazard


Description Initiator Eco 13795; Updated Tool side housing to add dowel 9/14/2015 LJH pin mounting pattern.


S26 Tool Module

This module has a Voltage of 50V or greater, NO contact should be attempted before removing power. This especially includes separation or insertion of the mating connectors or any contact with the tool changer or its components.

S26 Master Module (9120-S26-M)








	//P s	
	N a b	
	M Z ©	
14		W F///
	\mathbb{R}	(H)


 Large views of connectors are 3:1 scale.
Pin "c" on the amphenol connectors is First-to-mate Last-to-break at the Tool Changer interface. This pin is recommended for use as ground.





1031 Goodworth Drive, Apex, NC 27539, USA Tel: +1.919.772.0115 Email: info@ati-ia.com Fax: +1.919.772.8259 www.ati-ia.com ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.



SPECIFIED.

DRAWN BY: P.Sparrow, 7/15/03 CHECKED BY: B.Digeso 9/8/04

S26 Module Drawing

SCALE

DRAWING NUMBER

REVISION 06

PROJECT # 030725-3 SHEET 1 OF 1 3:4 В 9630-20-S26